IBELL IBL SS 25C

IBELL SS25C Stainless Steel Casserole User Manual

Model: IBL SS 25C

Brand: IBELL

Product Overview

The IBELL Stainless Steel Casserole (Model IBL SS 25C) is a double-wall, strong, and sturdy hot pot designed to keep food hot or cold for extended periods. It is constructed from non-magnetic, mirror-finish stainless steel with double-wall insulation and PUF coating, ensuring durability and efficient temperature retention. This casserole is made from high-quality, export-grade, corrosion-resistant material, free of any harmful coatings, making it a healthy and hygienic dinnerware option. With a capacity of 2500 ml, it is ideal for various uses including keeping food warm, serving, preserving, and even as a yogurt maker.



Figure 1: IBELL SS25C Stainless Steel Casserole with its lid securely closed, featuring a 1-year warranty sticker on the side.

Setup and First Use

1. **Unpacking:** Carefully remove the casserole from its packaging. Inspect for any damage during transit.
2. **Initial Cleaning:** Before first use, wash the casserole thoroughly with mild dish soap and warm water. Rinse completely and dry with a soft cloth. This ensures hygiene and removes any manufacturing residues.



Figure 2: The IBELL SS25C Casserole with its lid completely removed, showcasing the spacious and hygienic stainless steel interior.

Operating Instructions

The IBELL Stainless Steel Casserole is designed for optimal temperature retention of food items. Follow these guidelines for best performance:

- **Temperature Retention:** To keep food items hot or cold for several hours, always ensure the casserole is closed securely with its lid. The double-wall insulation and PUF coating work effectively when the casserole is sealed.
- **Preventing Soggy Food:** For best results, especially with items like rotis or bread, wrap food items in a clean cloth or foil before placing them into the casserole. This helps prevent condensation and keeps food from becoming soggy.
- **Versatile Use:** This casserole can be used for various purposes, including:
  - Keeping cooked food hot for serving.
  - Preserving food at desired temperatures.
  - As a yogurt maker.

- For general food serving.



Figure 3: The IBELL SS25C Casserole shown in a kitchen environment, filled with rice, demonstrating its use for serving and keeping food warm.

Maintenance and Care

Proper care will extend the life and maintain the performance of your IBELL Casserole.

- **Cleaning:** The casserole is dishwasher safe. For hand washing, use a soft sponge and mild detergent. Avoid abrasive cleaners or scourers that could scratch the stainless steel surface.
- **Drying:** After washing, dry the casserole thoroughly to prevent water spots and maintain its mirror finish.
- **Storage:** Store in a clean, dry place.

Important Warnings:

DO NOT place the casserole directly on fire or any direct heat source.

DO NOT use the casserole inside a microwave oven.

Troubleshooting

If you encounter any issues with your IBELL Casserole, consider the following common points:

Problem	Possible Cause / Solution
Food not staying warm/cold for expected duration.	• Lid not securely closed: Ensure the lid is tightly sealed to maintain insulation. • Frequent opening: Opening the lid too often will cause heat/cold loss. • Initial food temperature: Ensure food is at the desired temperature when placed in the casserole.
Water accumulation or rusting in lid handle.	• Improper drying: Ensure the lid, especially around the handle, is thoroughly dried after washing. • Avoid submerging the lid handle in water for extended periods during washing. • If rust appears, it can often be removed with a stainless steel cleaner, followed by thorough drying.

Specifications

Feature	Detail
Model Number	IBL SS 25C
Material	Stainless Steel
Capacity	2500 Milliliters (2.5 Liters)
Color	Silver
Shape	Round
Product Dimensions (W x H)	27 cm x 13 cm (10.6 in x 5.1 in)
Item Weight	1 kg 160 g
Dishwasher Safe	Yes
Microwaveable	No
Included Components	1 Casserole



Figure 4: The IBELL SS25C Casserole highlighting its 2.5 Liter capacity.




Figure 5: Dimensions of the IBELL SS25C Casserole, indicating a width of 27 cm (10.6 inches) and a height of 13 cm (5.1 inches).

Warranty and Support

Your IBELL SS25C Stainless Steel Casserole comes with a comprehensive warranty and support:

- **Warranty:** This product includes a 1-Year Warranty, comprising a 6-month standard warranty and an additional 6-month warranty upon registration. Registration must be completed within 30 days from the date of purchase to avail the extended warranty.
- **Manufacturer Contact:** For any queries, support, or warranty claims, please contact IBELL customer service.
  - Manufacturer: IBELL
  - Contact Number: 1800-2020-260

© 2025 IBELL. All rights reserved.
This manual is for informational purposes only. Product specifications are subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question