

NEDIS TWMT100SI

NEDIS Tablet Wall Mount Holder TWMT100SI Instruction Manual

Model: TWMT100SI

[Features](#) [Introduction](#) [Safety Information](#) [Package Contents](#) [Product Specifications](#) [Support](#)
[Installation](#) [Operation](#) [Maintenance](#) [Troubleshooting](#)

1. INTRODUCTION

Thank you for purchasing the NEDIS Tablet Wall Mount Holder, Model TWMT100SI. This manual provides essential information for the safe and efficient installation and operation of your new tablet wall mount. Please read these instructions carefully before use and retain them for future reference.

This wall mount is designed to securely hold iOS and Android tablets ranging from 7 to 12 inches, offering 360-degree rotation for optimal viewing in various environments such as kitchens, offices, and bedrooms.

2. SAFETY INFORMATION

- **Read all instructions:** Before installation, carefully read and understand all instructions. Incorrect installation can cause damage or injury.
- **Verify wall structure:** Ensure the mounting surface can safely support the weight of the mount and the tablet. If unsure, consult a qualified professional.
- **Use appropriate tools:** Use the correct tools for installation to prevent damage to the mount or the wall.
- **Securely fasten:** Ensure all screws and fasteners are tightened securely to prevent the mount from detaching. Do not overtighten.
- **Keep out of reach of children:** Small parts and tools can be a choking hazard.
- **Avoid over-tightening the clamp:** While securing the tablet, ensure the clamp is firm but not excessively tight to avoid damaging the tablet.
- **Regular inspection:** Periodically check the mount for any signs of wear, damage, or loose connections.

3. PACKAGE CONTENTS

Please verify that all components are present before beginning installation:

- NEDIS Tablet Wall Mount Holder (TWMT100SI)

- Mounting hardware (screws, drywall anchors, brick/concrete anchors)
- Instruction Manual



Image: Product packaging showing the NEDIS Tablet Wall Mount Holder.

4. PRODUCT FEATURES

The NEDIS Tablet Wall Mount Holder offers the following key features:

- **Universal Tablet Compatibility:** Designed to securely hold iOS & Android tablets sized 7"–12" (17.8–30.5 cm), compatible with popular models like iPad, Samsung Galaxy Tab, Lenovo Tab, and Fire HD.
- **Adjustable Clamp Opening:** Features a strong and stable clamp that adjusts between 5.7"–8.3" (14.5–21 cm) to accommodate various tablet sizes securely.
- **360° Full Rotation:** Allows for easy switching between portrait and landscape viewing modes, ideal for diverse applications such as video watching, reading, video calls, or interactive displays.
- **Charge While Mounted:** Includes a convenient charging slot within the clamp, enabling you to power your tablet

without removing it from the holder.

- **Space-Saving Wall Installation:** Mounts securely to any wall, helping to keep your desk or counter space clear and clutter-free. Suitable for kitchens, offices, bedrooms, meeting rooms, and smart home setups.



Image: A tablet securely held in the NEDIS wall mount, demonstrating its functionality.

5. INSTALLATION INSTRUCTIONS

Follow these steps to install your NEDIS Tablet Wall Mount Holder:

1. **Choose a Location:** Select a suitable wall location that is sturdy and free from electrical wires or plumbing. Consider the desired viewing height and angle.
2. **Mark Drilling Points:** Hold the mounting plate against the wall at the desired position. Use a pencil to mark the two drilling points through the holes on the mounting plate.



Image: Rear view of the tablet mount, highlighting the circular mounting plate and screw holes.




Image: Technical diagram detailing the dimensions and screw hole placement for the mounting plate.

3. **Drill Holes:** Using an appropriate drill bit for your wall type (e.g., masonry bit for brick/concrete, wood bit for studs), drill holes at the marked points. The diameter of the drill bit should match the provided anchors.
4. **Insert Anchors:** If installing into drywall or masonry, insert the appropriate wall anchors into the drilled holes until they are flush with the wall surface.
5. **Attach Mounting Plate:** Align the mounting plate with the drilled holes (and anchors, if used). Insert the provided screws and tighten them securely with a screwdriver until the plate is firmly attached to the wall. Do not overtighten.
6. **Attach Tablet Holder:** Slide the tablet holder onto the mounted plate. Ensure it clicks into place securely.

6. OPERATION

6.1 Inserting Your Tablet

1. Gently pull apart the adjustable clamps of the holder.
2. Carefully place your tablet into the holder, ensuring it is centered and the clamps securely grip the sides of the tablet. The rubber protectors on the clamps prevent scratches.

3. Ensure the tablet is stable and does not wobble before releasing your grip.




Image: Side view of the tablet mount, showing the adjustable clamps and the slim profile when mounted.

6.2 Adjusting Viewing Angle (360° Rotation)

The mount allows for 360-degree rotation to switch between portrait and landscape orientations:

- To rotate the tablet, firmly grasp both sides of the tablet.
- Gently turn the tablet in the desired direction (clockwise or counter-clockwise) until it reaches the preferred orientation. You may feel a slight click as it rotates, indicating the secure rotation mechanism.



Distance from wall

Side view




Image: Diagram illustrating the 360-degree rotation capability and key dimensions of the mount.

6.3 Charging While Mounted

A dedicated slot is integrated into the bottom clamp to allow for charging your tablet while it remains mounted. Simply connect your tablet's charging cable to the charging port and route it through the slot.

7. MAINTENANCE

- **Cleaning:** Wipe the mount with a soft, damp cloth. Avoid using abrasive cleaners or solvents, as these can damage the finish.
- **Inspection:** Periodically check all mounting screws and the tablet clamp for tightness. Re-tighten if necessary, but do not overtighten.
- **Environmental Conditions:** Avoid exposing the mount to extreme temperatures or direct sunlight for prolonged periods, which could affect material integrity.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Tablet feels loose in the mount.	Clamps not fully engaged or tablet size is outside the specified range.	Ensure the tablet is correctly positioned and the clamps are fully extended to grip it. Verify your tablet's dimensions are within 5.7"–8.3" (14.5–21 cm) width.
Mount is wobbly on the wall.	Mounting screws are loose or wall anchors are not properly installed.	Check and tighten all mounting screws. If the issue persists, re-evaluate the wall anchors and consider using more robust anchors suitable for your wall type.
Difficulty rotating the tablet.	Rotation mechanism might be stiff or obstructed.	Ensure no cables or objects are obstructing the rotation. Apply gentle, even pressure when rotating. The mechanism is designed to be firm for stability.

9. SPECIFICATIONS

Feature	Detail
Brand	NEDIS
Model	TWMT100SI
Compatible Devices	Tablets (iOS & Android)
Screen Size Compatibility	7 - 12 Inches (17.8 - 30.5 cm)
Adjustable Clamp Opening	5.7" - 8.3" (14.5 - 21 cm)
Rotation	360°
Material	Alloy Steel, Plastic
Mounting Type	Wall Mount
Product Dimensions (LxWxH)	17.5 x 8.1 x 4.8 cm
Item Weight	185 g
Color	White/Grey
Country of Origin	China

10. WARRANTY AND SUPPORT





For warranty information, technical support, or customer service inquiries, please refer to the contact details provided on the product packaging or visit the official NEDIS website. Keep your purchase receipt as proof of purchase.

Manufacturer: Nedis, BV Netherlands



Related Documents - TWMT100SI

<div data-bbox="129 230 296 609"> <div> </div> <div> <div>Quick start guide</div> <div>SEST250BK</div> </div> <div> <div>SEST250BK</div> <div> <div> </div> <div> For more information use the extended manual online: nedis.nl/user250BK </div> </div> <div> <div>Intended use</div> <div> The SEST250BK is a smartphone holder that allows you to take selfies from a greater distance. The product is not intended for professional use. Any modification of the product may have consequences for safety, warranty and proper functioning. </div> </div> <div> <div>Specifications</div> <table border="1"> <tr><td>Product</td><td>Selfie Stick</td></tr> <tr><td>Article number</td><td>SEST250BK</td></tr> <tr><td>Dimensions (L x W x H)</td><td>190 x 40 x 40 mm (folded)</td></tr> <tr><td>Max. length</td><td>200 mm</td></tr> <tr><td>Smartphone holder width</td><td>60 - 80 mm</td></tr> <tr><td>Weight</td><td>140 g</td></tr> <tr><td>Input power</td><td>3.3 V</td></tr> <tr><td>Current</td><td>1.00 mA</td></tr> <tr><td>FM frequency</td><td>2400 - 250000 Hz</td></tr> <tr><td>Antenna gain</td><td>1 dB</td></tr> <tr><td>Transmit to power</td><td>0 - 4 dBm</td></tr> <tr><td>Bluetooth version</td><td>Yes</td></tr> <tr><td>Material</td><td>Aluminum Alloy and ABS</td></tr> <tr><td>Battery type</td><td>Lithium battery cell CR1632 (included)</td></tr> </table> </div> <div> <div>Main parts (image A)</div> <div> <div> </div> <div> </div> <div> </div> <div> </div> <div> </div> </div> </div> <div> <div>Safety instructions</div> <div> <div> WARNING </div> <div> <ul style="list-style-type: none"> Always keep button cell batteries, both full and empty, out of reach of children to avoid the chance of swallowing. Dispose of used batteries immediately and safely. Button cell batteries can cause serious internal chemical burns in as little as two hours when swallowed. Keep in mind that the first symptoms may look like child diseases like coughing or choking. Seek immediate medical attention when you suspect that batteries have been swallowed. Ensure you have fully read and understood the instructions in this document before you install or use the product. Keep the packaging and this document for future reference. Only use the product as described in this document. Do not use the product if a part is damaged or defective. Replace a damaged or defective product immediately. Do not drop the product and avoid bumping. This product may only be serviced by a qualified technician for maintenance to reduce the risk of electric shock. Do not expose the product to water or moisture. Do not dismantle, open or short batteries. Do not expose batteries to heat or fire. Avoid storage in direct sunlight. Do not short circuit a battery. Do not store cells or batteries haphazardly in a box or drawer where they may short circuit each other or be short-circuited by other metal objects. Do not subject cells or batteries to mechanical shock. In the event of a cell leaking do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice. Only use the battery type(s) recommended in the document. Keep cells and batteries clean and dry. Wipe the cell or battery terminal with a clean dry cloth if they become dirty. Do not remove a battery from its original packaging until required for use. Retain the original product literature for future reference. When possible, remove the battery from the product when not in use. Observe the plus (+) and minus (-) marks on the cell, battery and equipment and ensure correct use. Dispose of the cell or battery properly. </div> </div> <div> <div>Bluetooth pairing</div> <div> <ol style="list-style-type: none"> Press and hold the photo button A for 3 seconds. <div>The status indicator LED A blinks to indicate the product is in pairing mode.</div> <ol style="list-style-type: none"> Enable Bluetooth on the device you want to pair the product with. Select "SEST250BK" from the list of available Bluetooth devices on your device. <div>A lights up green when pairing is successful.</div> </div> <div> <div>Using the product</div> <div> <ol style="list-style-type: none"> Place your smartphone into the smartphone holder A. Press A to take a picture. <div>You can detach A and use it as a remote control.</div> <ol style="list-style-type: none"> Press and hold A for 3 seconds to switch off the product. </div> </div> <div> <div>Declaration of Conformity</div> <div> We, Nedis B.V., declare as manufacturer that the product SEST250BK from our brand Nedis, produced in China, has been tested according to all relevant CE standards and regulations and that all tests have been passed successfully. This includes, but is not limited to the RED 2014/53/EU regulation. </div> <div> The complete Declaration of Conformity (and the safety data sheet if applicable) can be found and downloaded via nedis.com/user250BKsupport. </div> <div> For additional information regarding the compliance, contact the customer service. Web: www.nedis.com E-mail: sales@nedis.com Nedis B.V., de Tweedeling 28 5215 MC 's-Hertogenbosch, the Netherlands </div> </div> </div></div></div></div>	Product	Selfie Stick	Article number	SEST250BK	Dimensions (L x W x H)	190 x 40 x 40 mm (folded)	Max. length	200 mm	Smartphone holder width	60 - 80 mm	Weight	140 g	Input power	3.3 V	Current	1.00 mA	FM frequency	2400 - 250000 Hz	Antenna gain	1 dB	Transmit to power	0 - 4 dBm	Bluetooth version	Yes	Material	Aluminum Alloy and ABS	Battery type	Lithium battery cell CR1632 (included)	<div data-bbox="339 931 1042 960"> <h2>Nedis SEST250BK Selfie Stick: Quick Start Guide & Features</h2> </div> <div data-bbox="339 969 1436 1043"> <p>Learn how to use your Nedis SEST250BK Selfie Stick with this quick start guide. Includes setup, safety instructions, Bluetooth pairing, and product specifications.</p> </div>	<div data-bbox="129 1798 296 2045"> <div> </div> <div> <div>SmartLife RGB LED-Stripa Wi-Fi Kyllia Valkonen / Lemminkäinen RGB 5 m IP65 2700 - 6500 K 405</div> <div> </div> </div> <div data-bbox="339 1836 836 1865"> <h2>Nedis SmartLife RGB LED Strip - Wi-Fi, 5m</h2> </div> <div data-bbox="339 1874 1457 2027"> <p>Discover the Nedis SmartLife RGB LED Strip, a 5m Wi-Fi enabled LED strip offering customizable colors, dimming, and scheduling via the Nedis SmartLife app. Control with voice commands and integrate into your smart home. Features IP65 rating, 2700-6500K color temperature, and 405 lumens.</p> </div> </div>
Product	Selfie Stick																													
Article number	SEST250BK																													
Dimensions (L x W x H)	190 x 40 x 40 mm (folded)																													
Max. length	200 mm																													
Smartphone holder width	60 - 80 mm																													
Weight	140 g																													
Input power	3.3 V																													
Current	1.00 mA																													
FM frequency	2400 - 250000 Hz																													
Antenna gain	1 dB																													
Transmit to power	0 - 4 dBm																													
Bluetooth version	Yes																													
Material	Aluminum Alloy and ABS																													
Battery type	Lithium battery cell CR1632 (included)																													

 <p>Zigbee Radiator Thermostat Installation ZBHTR20WT</p>	<p>Nedis Zigbee Radiator Thermostat ZBHTR20WT Installation Guide</p> <p>Step-by-step installation guide for the Nedis Zigbee Radiator Thermostat (model ZBHTR20WT). Learn how to install, set up, and connect your smart thermostat using the Nedis SmartLife app for efficient home heating control.</p>
 <p>nedis WIFICO20CWT</p> <p>Quick Start Guide (EN) Verwijzen in de handleiding (NL) Kortlezing (DE) Code de mise en service (FR) Guide de démarrage rapide (PT) Guia rápido (ES) Guia de instalação rápida (PT) Handboek (NL) Handboek (NL)</p> <p>Outdoor IP camera</p>	<p>Nedis WIFICO20CWT Outdoor IP Camera Quick Start Guide</p> <p>A quick start guide for the Nedis WIFICO20CWT Outdoor IP Camera, detailing setup, usage, safety, and maintenance in multiple languages.</p>
	<p>Nedis ZBSM10WT Zigbee Motion Sensor Quick Start Guide</p> <p>Quick start guide for the Nedis ZBSM10WT Zigbee motion sensor, covering setup, installation, and automation with the Nedis SmartLife app.</p>
 <p>Zigbee Radiator Thermostat Safety instructions ZBHTR20WT</p>	<p>Nedis Zigbee Radiator Thermostat ZBHTR20WT Safety Instructions</p> <p>Safety instructions and user guide for the Nedis Zigbee Radiator Thermostat (ZBHTR20WT), covering intended use, warnings, and disposal.</p>