

ARCADE1UP 815221025172

Arcade1Up Deluxe Edition 12-in-1 Arcade Cabinet

Model: 815221025172

Brand: ARCADE1UP

INTRODUCTION

Welcome to the classic arcade experience at home. The Arcade1Up Deluxe Edition 12-in-1 Arcade Cabinet is designed to look, feel, and play just like the arcade games you remember. This 3/4 scale cabinet includes a riser, allowing for both seated and standing play.

SETUP

Unpacking and Assembly

The Arcade1Up cabinet requires simple assembly. Please ensure all components are present before beginning. Refer to the included assembly guide for detailed step-by-step instructions. It is recommended to assemble the unit in the location where it will be used.

The cabinet is designed for easy setup and plugs directly into a standard AC outlet using the included power adapter.

Riser Installation

The included riser allows for improved standing play. Attach the cabinet securely to the riser following the assembly instructions to ensure stability.



Image: The Arcade1Up cabinet shown both with and without its included riser, demonstrating the height difference for standing or seated play.

OPERATING INSTRUCTIONS

Powering On

Connect the included power adapter to the cabinet and then to a standard AC outlet. The unit will power on automatically or via a designated power button (refer to the assembly guide for exact location).

Game Selection

This cabinet features 12 classic games. Use the joystick and control buttons to navigate the game selection menu. The included games are:

- Asteroids
- Centipede
- Major Havoc
- Missile Command
- Lunar Lander
- Crystal Castles

- Tempest
- Millipede
- Gravitar
- Liberator
- Asteroids Deluxe

Authentic Controls

The cabinet features authentic controls, including a knob wheel, track wheel, and control buttons, providing a genuine arcade experience. Adjust the volume using the dedicated volume control.



Image: A person actively playing the Arcade1Up cabinet, demonstrating the use of the joystick and buttons.



Image: Front view of the Arcade1Up cabinet featuring Centipede artwork on the side panels and marquee, showcasing the control panel and screen.

MAINTENANCE

Cleaning

To clean the cabinet, use a soft, damp cloth. Avoid abrasive cleaners or solvents that may damage the finish or screen. For the screen, use a screen-specific cleaner and a microfiber cloth.

General Care

Keep the cabinet in a dry environment, away from direct sunlight and extreme temperatures. Ensure proper ventilation around the unit.

TROUBLESHOOTING

No Power

Ensure the power adapter is securely connected to both the cabinet and a working electrical outlet. Check the power cord for any visible damage.

Display Issues

If the screen is blank or flickering, try unplugging and re-plugging the power cord. Ensure the cabinet is not exposed to excessive glare.

Control Malfunctions

If controls are unresponsive, power cycle the unit. Ensure no debris is obstructing the joystick or buttons. For persistent issues, contact customer support.

For further assistance, please refer to the manufacturer's official support channels.

SPECIFICATIONS

Feature	Detail
Product Dimensions (H x W x D)	51.18 x 27.56 x 9.84 inches (with riser)
Item Weight	15.4 pounds
Screen Size	17-inch Color LCD
Included Games	Asteroids, Centipede, Major Havoc, Missile Command, Lunar Lander, Crystal Castles, Tempest, Millipede, Gravitar, Liberator, Asteroids Deluxe
Power Source	AC Power Adapter (Included)
Manufacturer	Arcade 1Up
Model Number	815221025172

WARRANTY AND SUPPORT

For warranty information, technical support, or replacement parts, please contact Arcade1Up customer service directly. Refer to the packaging or the official Arcade1Up website for the most current contact details.

Official Brand Store: [ARCADE1UP Store on Amazon](#)