**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



**Yamazaki 4081**

# Yamazaki Smart Pole Hanger Model 4081 Instruction Manual

Model: 4081 | Brand: Yamazaki

## 1. Product Overview

The Yamazaki Smart Pole Hanger Model 4081 is a slim and stable coat hanger designed for efficient clothing storage. Its design allows for hanging multiple garments side-by-side, similar to a hanger rack, and includes an integrated hook for bags or other accessories. This pole hanger is suitable for various types of clothing, including long coats and dresses.



Image 1.1: The Yamazaki Smart Pole Hanger 4081, showcasing its capacity for hanging a jacket and a bag.

### Key Features:

- **Space-Saving Design:** Slim profile for efficient use of space.
- **High Capacity:** Allows hanging multiple garments side-by-side.
- **Integrated Hook:** Convenient hook for hanging bags, hats, or other accessories.
- **Stable Base:** Designed with a heavy base to prevent tipping, even when loaded unevenly.
- **Durable Construction:** Made from steel with a powder coating for longevity.

## 2. Assembly Instructions

The Yamazaki Smart Pole Hanger Model 4081 requires assembly. Please follow these steps carefully. An included hex wrench is the only tool required.

### Components:

- Base (1)
- Main Pole (1)
- Hanger Bar (1)
- Accessory Hook (1)
- Hex Wrench (1)
- Screws (various, pre-attached or in a small bag)

### Step-by-Step Assembly:

1. **Attach Main Pole to Base:** Carefully align the bottom end of the main pole with the central hole in the base. Insert the pole and secure it using the provided screws and hex wrench. Ensure it is tightened firmly for stability.
2. **Install Accessory Hook:** Locate the designated slot or hole on the main pole for the accessory hook. Insert the hook and secure it, typically by twisting or using a small screw.
3. **Attach Hanger Bar:** Position the hanger bar onto the top of the main pole. It should slide into place or be secured with screws. Ensure it is level and firmly attached.





Image 2.1: A diagram illustrating the assembled pole hanger with its dimensions (140cm height, 36.5cm base diameter).

After assembly, gently test the hanger's stability before loading it with items.

## 3. Operating Instructions

The Yamazaki Smart Pole Hanger is designed for convenient and stable storage of your garments and accessories.

### Hanging Garments:

- Use standard hangers to place your clothes on the horizontal hanger bar. The design allows for multiple hangers to be placed side-by-side, making it easy to organize and access your items.
- Distribute the weight evenly across the hanger bar to maintain optimal stability. While the heavy base provides excellent stability, excessive weight on one side should be avoided.
- The hanger can accommodate long garments such as coats and dresses without them touching the floor, thanks to its 140 cm height.




Image 3.1: Demonstrating how to hang clothes on the pole hanger.

## Using the Accessory Hook:

- The integrated hook on the main pole is ideal for hanging bags, scarves, hats, or other accessories.
- Ensure items hung on the hook do not exceed the specified load capacity to prevent damage or instability.




Image 3.2: The accessory hook in use, holding a bag.

## Load Capacity:

- Hanger Bar: Approximately 10 kg (22.0 lbs)
- Per Hook: Approximately 2 kg (4.4 lbs)

Do not exceed these weight limits to ensure the stability and longevity of the product.

## 4. Maintenance

Proper maintenance will help preserve the appearance and functionality of your Yamazaki Smart Pole Hanger.

### Cleaning:

- Wipe the steel frame with a soft, damp cloth. For stubborn marks, a mild soap solution can be used, followed by wiping with a clean, dry cloth.
- Avoid using abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the powder-coated finish.

### Care:

- Regularly check all screws and connections to ensure they remain tight. Re-tighten with the hex wrench if necessary.
- Avoid placing the hanger in areas with extreme humidity or direct prolonged sunlight, which could affect the finish over time.

## 5. Troubleshooting

If you encounter any issues with your pole hanger, refer to the following common solutions.

### Hanger feels unstable or wobbly:

- **Check Assembly:** Ensure all screws connecting the main pole to the base and the hanger bar to the main pole are securely tightened. Refer to the assembly instructions.
- **Weight Distribution:** Verify that the weight of the hung items is distributed as evenly as possible. While the hanger is designed for stability, extreme uneven loading can affect balance.
- **Exceeding Load Capacity:** Confirm that the total weight on the hanger bar and hooks does not exceed the specified load capacities (10 kg for the bar, 2 kg per hook).




Image 5.1: The pole hanger demonstrating its stability with items hung on one side.

### Scratches on the floor:

- The base of the hanger is designed to be stable. If you are concerned about floor scratches, especially on delicate surfaces, consider placing a protective mat or felt pads under the base.

## 6. Specifications

| Attribute | Detail |
|---|---|
| **Brand** | Yamazaki |
| **Model Number** | 4081 |
| **Colour** | Black |
| **Material** | Body: Steel (powder coating); Cap: Polypropylene |
| **Product Dimensions (D x W x H)** | 36.5D x 36.5W x 140H centimetres (Approx. 14.4 x 14.4 x 55.1 inches) |
| **Item Weight** | 5.2 Kilograms |
| **Installation Type** | Free Standing |
| **Hanger Bar Load Capacity** | Approx. 10 kg (22.0 lbs) |
| **Accessory Hook Load Capacity** | Approx. 2 kg (4.4 lbs) per hook |
| **Required Assembly** | Yes |
| **Included Components** | Hex Wrench |

## 7. Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the retailer where the product was purchased or visit the official Yamazaki website. Keep your proof of purchase for any warranty claims.

© 2026 Yamazaki. All rights reserved.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question



**Open the live page**

**https://manuals.plus/asin/B07HG33HLQ**

More documents and user manuals: **https://manuals.plus/**