

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

DGT 156898

DGT3000 LE Limited Edition Chess Timer User Manual

Brand: DGT | Model: 156898

1. PRODUCT OVERVIEW

The DGT3000 LE (Limited Edition) Chess Timer is a FIDE-approved digital chess clock designed for serious chess players. This special edition celebrates DGT's 25th anniversary, featuring a unique wooden aesthetic while retaining all the advanced functionalities of the popular DGT3000 model. It offers a larger display, precise timekeeping, and a wide array of pre-set and customizable timing options.

Key features include:

- Larger display with enhanced information visibility.
- Seconds are always shown from the start of the game.
- 25 pre-set timing systems to accommodate various game formats.
- 5 customizable slots for personalized time settings.
- Supports US delay and Bronstein delay.
- Fully compliant with FIDE rules and regulations.

2. SETUP

2.1 Battery Installation

The DGT3000 LE requires **2 AA batteries** for operation. Ensure the batteries are inserted correctly according to the polarity indicators.

1. Locate the battery compartment on the underside of the chess timer.
2. Open the battery compartment cover.
3. Insert 2 AA batteries, matching the positive (+) and negative (-) terminals with the indicators inside the compartment.
4. Close the battery compartment cover securely.

Figure 2.1: Front view of the DGT3000 LE Chess Timer, displaying its large screen and control buttons. This image shows the timer in its operational state, ready for use.

3. OPERATING INSTRUCTIONS

3.1 Powering On/Off

To power on the DGT3000 LE, ensure batteries are installed. The device typically powers on automatically when a button is pressed or when the lever is toggled. To power off, hold the power button (if available) or allow the device to enter a low-power state after a period of inactivity.

3.2 Selecting Timing Systems

The DGT3000 LE offers 25 pre-set timing systems and 5 customizable slots. The pre-set options are conveniently marked on the bottom of the clock for quick reference, eliminating the need to consult the manual for common tournament settings.

1. Press the 'Menu' or 'Option' button to cycle through available timing systems.
2. Use the arrow buttons to navigate between the pre-set options (1-25) or the customizable slots (26-30).
3. Press 'Enter' or the central button to confirm your selection.

3.3 Customizing Settings

For the 5 customizable slots, you can manually set specific time controls, delays, and other parameters to suit your preferences. Refer to the detailed instructions in the full manual (available on the DGT website) for step-by-step guidance on programming custom settings.

Figure 3.1: Close-up view of the DGT3000 LE's display, highlighting the clear numerical readouts and the intuitive button layout for setting and controlling game time.

4. CARE AND MAINTENANCE

To ensure the longevity and optimal performance of your DGT3000 LE Chess Timer, follow these care guidelines:

- **Cleaning:** Wipe the surface with a soft, dry cloth. Avoid using abrasive cleaners or solvents, which may damage the finish or display.
- **Storage:** Store the timer in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Replacement:** Replace batteries promptly when the low battery indicator appears to prevent potential leakage and damage to the device. If storing for extended periods, remove the batteries.
- **Handling:** Handle the timer with care to avoid dropping it or subjecting it to strong impacts, which could damage internal components or the display.

5. TROUBLESHOOTING

This section addresses common issues you might encounter with your DGT3000 LE Chess Timer.

Problem	Possible Cause	Solution
Timer does not power on.	Dead or incorrectly inserted batteries.	Check battery polarity or replace with new AA batteries.
Display is dim or flickering.	Low battery power.	Replace batteries.

Problem	Possible Cause	Solution
Buttons are unresponsive.	Temporary software glitch or physical obstruction.	Remove and reinsert batteries to reset the device. Ensure no debris is lodged around buttons.
Time settings are incorrect.	Incorrect pre-set option selected or custom settings misconfigured.	Verify the selected timing system. Re-enter custom settings if applicable. Refer to the bottom of the clock for pre-set option details.

6. TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	DGT
Model Number	156898
Color	Brown (wood effect)
Material	Wood effect plastic
Product Dimensions (DxWxH)	12.7" x 17.78" x 7.62" (approx. 32.26 cm x 45.16 cm x 19.35 cm)
Item Weight	16 ounces (approx. 0.45 kg)
Number of Pre-set Settings	25
Customizable Settings	5 slots
Screen Size	322.6 Millimeters
Batteries Required	2 AA batteries
Manufacturer Recommended Age	12 months and up

7. WARRANTY INFORMATION


The DGT3000 LE Chess Timer comes with a **5-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For detailed terms and conditions, refer to the official DGT website or contact customer support.

8. CUSTOMER SUPPORT

For further assistance, technical support, or inquiries regarding your DGT3000 LE Chess Timer, please visit the official DGT website or contact their customer service department. You may find additional resources, FAQs, and updated manuals online.

DGT Official Website: www.dgtclocks.com

Related Documents

	<p><u>DGT3000 Game Timer: Quick Guide and Features</u></p> <p>Explore the DGT3000, a FIDE-approved digital chess clock. This quick guide covers its features, timing systems (Time, Bonus, Delay, Byo-yomi, Fischer, US-Delay), manual settings, computer/internet connectivity, and technical specifications for chess and other board games.</p>
	<p><u>DGT2500 Official FIDE Chess Clock User Manual</u></p> <p>Comprehensive user manual for the DGT2500 Official FIDE Chess Clock, detailing setup, modes, features, glossary, warranty, and technical specifications for chess players and tournament organizers.</p>
	<p><u>DGT USB e-Board User Manual: Features, Setup, and Specifications</u></p> <p>Comprehensive user manual for the DGT USB e-Board, detailing its features, setup instructions, usage for game recording, broadcasting, online play, and technical specifications.</p>
	<p><u>DGT 2010 Chess Clock User Manual</u></p> <p>Comprehensive user manual for the DGT 2010 chess clock, detailing its features, operation, and various time control settings for chess and other board games.</p>