Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- , JVD /
- > JVD N9360.3 Classic Wall Clock Instruction Manual

JVD N9360.3

JVD N9360.3 Classic Wall Clock Instruction Manual

Model: N9360.3

Introduction

Thank you for choosing the JVD N9360.3 Classic Wall Clock. This manual provides essential information for the proper setup, operation, and maintenance of your new clock. Please read these instructions carefully before use and retain them for future reference.





Image: The JVD N9360.3 Classic Wall Clock, featuring a dark wooden frame, a white analog dial with black numerals, and a visible brass-toned pendulum.

SAFETY INFORMATION

- Ensure the clock is securely mounted to a sturdy wall surface to prevent falling.
- · Keep batteries out of reach of children.
- Do not mix old and new batteries, or different types of batteries.
- Dispose of used batteries according to local regulations.
- Avoid exposing the clock to extreme temperatures, direct sunlight, or high humidity.

PACKAGE CONTENTS

Please check that all items are present in the package:

- JVD N9360.3 Wall Clock Unit
- Pendulum
- Instruction Manual (this document)

Note: Batteries are not included and must be purchased separately.

SETUP

1. Unpacking

- · Carefully remove the clock from its packaging.
- Inspect the clock for any signs of damage.

2. Battery Installation

- Locate the battery compartment on the back of the clock mechanism.
- Insert one (1) AA battery, ensuring the polarity (+/-) matches the indicators inside the compartment.
- · Close the battery compartment cover securely.

3. Setting the Time

- Turn the time-setting knob (usually a small wheel) located on the back of the clock mechanism in the direction indicated until the hands display the correct time.
- Do not move the clock hands directly, as this may damage the mechanism.

4. Attaching the Pendulum

- Gently hook the pendulum onto the pendulum hanger located below the clock mechanism.
- Ensure the pendulum swings freely without obstruction.

5. Mounting the Clock

- Choose a suitable location on a sturdy wall.
- Use appropriate wall anchors and screws (not included) to securely hang the clock. The clock features a keyhole slot on the back for mounting.
- Ensure the clock is level for optimal pendulum operation and aesthetic appeal.

OPERATING INSTRUCTIONS

Once the battery is installed, the time is set, and the pendulum is attached, the clock will begin to operate. The pendulum is decorative and does not affect the timekeeping accuracy of the quartz movement.

- To adjust the time, repeat step 3 from the Setup section.
- The clock operates continuously until the battery power is depleted.

MAINTENANCE

Cleaning

- Wipe the clock casing with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or chemical sprays, as these may damage the finish.
- For the glass, use a glass cleaner applied to a cloth, not directly to the clock.

Battery Replacement

- Replace the battery annually or when the clock begins to lose time or stops functioning.
- Follow the battery installation steps outlined in the Setup section.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clock not running	Dead or incorrectly installed battery	Replace battery with a fresh AA battery, ensuring correct polarity.
Clock losing or gaining time	Weak battery	Replace battery with a fresh AA battery.
Pendulum not swinging	Pendulum not properly attached or obstructed	Ensure pendulum is correctly hooked and swings freely.

SPECIFICATIONS

• Brand: JVD

• Model Number: N9360.3

• Material: Wood

Display Type: AnalogShape: Round (dial)Frame Material: Wood

• Mounting Type: Wall Mount

• Alarm: No

• Operation Mode: Quartz Wall Clock

• Batteries Required: 1x AA (not included)

WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support, please refer to the documentation provided at the point of purchase or contact your retailer. JVD is committed to providing quality products and customer satisfaction.

Related Documents - N9360.3



JVD WAVE Stereo Alarm Clock, Bluetooth, Black - Model 8661691

Discover the JVD WAVE Stereo Alarm Clock (Model 8661691) in Black. Features wireless & USB charging, Bluetooth connectivity, FM radio, light dimming, and hotel mode functions. Compact dimensions and versatile features make it ideal for various settings.




JVD WAVE Stereo Alarm Clock, Bluetooth, White (Model 8661692) - Datasheet

Detailed product information for the JVD WAVE Stereo Alarm Clock (Model 8661692). This white alarm clock offers Bluetooth, wireless & USB charging, FM radio, AUX, TF card support, and hotel mode features. View detailed specifications, dimensions, and advantages.



JVD High Speed Automatic Hand Dryer - Operating Instructions and Parts Manual

Comprehensive guide for the JVD High Speed Automatic Hand Dryer (Model JVD-HC120), including installation, operation, maintenance, safety warnings, technical specifications, and a detailed parts list for troubleshooting and repairs.



Manuel d'utilisation JVD Shield : Purificateur d'air

Guide complet pour l'installation, l'utilisation et l'entretien du purificateur d'air JVD Shield. Découvrez les modes de fonctionnement, les précautions de sécurité et les caractéristiques techniques.



JVD EXP'AIR Hand Dryer Installation and User Manual

Official installation and user manual for the JVD EXP'AIR hand dryer. Includes safety, installation, operation, maintenance, and technical specifications for commercial use. Available in multiple languages.

JVD BRITTONY PRISE 230V Hair Dryer - Instructions and Safety

Official instructions and safety precautions for the JVD BRITTONY PRISE 230V hair dryer, designed for hotel use. Includes installation, maintenance, and technical specifications.