

Manuals.plus /

› Miady /

› Miady Clip-on Lamp Model LDL04 User Manual

Miady LDL04

Miady Clip-on Lamp Model LDL04 User Manual

Battery Powered Reading Light with 3 Brightness Levels and USB Rechargeable Functionality

1. INTRODUCTION

Thank you for choosing the Miady Clip-on Lamp Model LDL04. This versatile and portable reading light is designed to provide comfortable, adjustable illumination for various activities such as reading, studying, and working. Featuring a flexible gooseneck, three brightness levels, and a built-in rechargeable battery, it offers convenience and eye-friendly lighting wherever you need it.





Image 1.1: The Miady Clip-on Lamp Model LDL04, showcasing its flexible neck and clip base.

2. PACKAGE CONTENTS

- 1 x Miady Clip-on Lamp Model LDL04
- 1 x USB Charging Cable
- 1 x User Manual

3. SETUP

3.1 Initial Charging

1. Locate the USB charging port on the lamp base.
2. Connect the included USB charging cable to the lamp's charging port.
3. Plug the other end of the USB cable into a standard USB power adapter (not included) or a computer's

USB port.

4. The indicator light on the lamp base will illuminate red during charging.
5. Charging is complete when the indicator light turns yellow. A full charge typically takes approximately 3 hours.

3.2 Attaching the Lamp

The lamp features a sturdy clip-on base for easy attachment to various surfaces.

1. Open the clip by pressing the handles together.
2. Attach the clip to a stable surface such as a desk, headboard, shelf, or book. Ensure the surface thickness is within the clip's capacity for a secure grip.
3. Release the handles to secure the lamp in place.



Image 3.1: The Miady Clip-on Lamp securely attached to a wooden shelf, demonstrating its versatility.

3.3 Adjusting the Gooseneck

The flexible gooseneck allows for 360-degree adjustment of the light direction.

- Gently bend and twist the gooseneck to position the light head as desired.
- Ensure the lamp head is directed to illuminate your task area effectively.

4. OPERATING THE LAMP

4.1 Power On/Off and Brightness Adjustment

The lamp is controlled by a touch-sensitive switch located on the base.

1. **To Power On:** Lightly touch the power symbol on the lamp base. The lamp will turn on at the lowest brightness setting.
2. **To Adjust Brightness:** Continue to lightly touch the power symbol to cycle through the three available brightness levels (Low, Medium, High).
3. **To Power Off:** After cycling through all brightness levels, the next touch will turn the lamp off.




Image 4.1: A hand demonstrating the touch control for power and brightness adjustment on the lamp base.

4.2 Battery Life

The built-in 1200mAh rechargeable battery provides approximately 3 hours of illumination on the highest brightness setting when fully charged. Battery life will be longer on lower brightness settings.

5. MAINTENANCE

5.1 Cleaning

- Ensure the lamp is turned off and unplugged before cleaning.
- Wipe the lamp's surface with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals, as these may damage the finish.

5.2 Battery Care

- To prolong battery life, avoid fully discharging the battery frequently.
- If the lamp will not be used for an extended period, charge it fully before storage and recharge every 3-6 months.
- Do not attempt to replace the internal battery yourself. Contact customer support if battery issues arise.

6. TROUBLESHOOTING

- **Lamp does not turn on:**

Ensure the lamp is charged. Connect it to a USB power source and check if the charging indicator light illuminates. If the battery is completely depleted, it may take a few minutes for the indicator to appear.

- **Light flickers or is dim:**

The battery may be low. Recharge the lamp fully.

- **Touch control is unresponsive:**

Ensure your finger is making full contact with the touch sensor. If the issue persists, try restarting the lamp by fully charging it.

- **Lamp does not hold a charge:**

The battery may have reached the end of its lifespan. Contact customer support for assistance.

- **Clip is not secure:**

Ensure the surface you are clipping the lamp to is within the appropriate thickness range for the clip. Avoid clipping to very thin or excessively thick objects.

7. SPECIFICATIONS

Feature	Specification
Model Number	LDL04
Brand	Miady
Light Source Type	LED (18 bulbs)
Brightness	18 Lumen (3 adjustable levels)
Power Source	Battery Powered (USB Rechargeable)
Battery Capacity	1200mAh Lithium Ion
Voltage	5 Volts
Wattage	2.5 watts
Control Method	Touch
Mounting Type	Clip On
Material	Acrylonitrile Butadiene Styrene
Product Dimensions	5"D x 3"W x 6.5"H
Item Weight	9.9 ounces
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

8. WARRANTY AND SUPPORT

Miady provides a 12-month warranty for the Clip-on Lamp Model LDL04. This warranty covers manufacturing defects and issues arising from normal use.

For warranty claims, technical support, or any questions regarding your product, please contact Miady customer support through the retailer's platform or the official Miady website. Please have your purchase details and model number (LDL04) ready when contacting support.