



Manuals.plus /

› OEMTOOLS /

› OEMTOOLS 24994 Workshop Creeper Seat Instruction Manual

OEMTOOLS 24994

OEMTOOLS 24994 Workshop Creeper Seat

Instruction Manual

1. SAFETY INFORMATION

Read and understand all instructions before assembling and using this product. Failure to follow these instructions may result in injury or property damage.

- **Weight Capacity:** Do not exceed the maximum weight capacity of 280 lbs (127 kg).
- **Stable Surface:** Use the creeper seat on a flat, level, and hard surface. Avoid uneven terrain or soft surfaces that could cause instability.
- **Proper Use:** This product is designed for sitting while working on vehicles or other low-level tasks. Do not stand on the seat or use it as a step stool.
- **Caster Safety:** Ensure all four casters are in good working order and roll freely. Avoid sudden movements or excessive force that could cause the seat to tip.
- **Tool Storage:** Distribute tools and items evenly in drawers and trays to maintain balance. Do not overload storage compartments.
- **Children and Pets:** Keep children and pets away from the creeper seat during use and assembly.

2. PRODUCT OVERVIEW

The OEMTOOLS 24994 Workshop Creeper Seat is designed to provide comfort and convenience for various workshop and garage tasks. It features a padded seat, integrated storage, and smooth-rolling casters for easy maneuverability.

Key Features:

- Comfortable vinyl foam padded seat.
- Two sliding drawers with ball-bearing slides for small tools and parts.
- Under-seat storage tray for larger items.
- Three integrated can holders for sprays, fluids, or beverages.
- Four 2-inch smooth-rolling swivel casters for 360-degree movement.
- Durable alloy steel construction.

Components:

- Padded Seat Top
- Frame Assembly
- Sliding Drawers (x2)
- Bottom Storage Tray
- Can Holder Attachment
- Caster Wheels (x4)
- Assembly Hardware (bolts, nuts, washers)



Image 2.1: The creeper seat with its two sliding drawers extended, showcasing storage for small tools like pliers and screwdrivers. The drawers feature ball-bearing slides for smooth operation.

**11.76 INCH
WIDE SEAT**

**FOAM PADDED
SEAT FOR
MAXIMUM
COMFORT**

**16.68 INCH
TALL**



**UNDER SEAT
STORAGE FOR
TOOLS, PARTS &
ACCESSORIES**

Image 2.2: Side view illustrating the seat's dimensions (11.76 inches wide, 16.68 inches tall) and highlighting the foam-padded seat for comfort and the under-seat storage area for tools, parts, and accessories.



CAN HOLDER FOR 3 CANS

Image 2.3: A view from below the seat, clearly showing the integrated can holder designed to accommodate up to three cans, such as spray lubricants or cleaning agents.



Image 2.4: Close-up of one of the 2-inch smooth-rolling caster wheels, emphasizing its design for easy and fluid movement across workshop floors.

3. SETUP AND ASSEMBLY

The OEMTOOLS 24994 Workshop Creeper Seat is designed for straightforward assembly. Follow the included instructions and use the provided tools to ensure proper and secure construction.

Assembly Steps:

1. Unpack all components and verify against the parts list.
2. Attach the caster wheels to the base of the frame using the provided hardware. Ensure they are securely fastened.
3. Install the bottom storage tray into the designated slots on the frame.
4. Slide the two drawers into their respective tracks on the frame. Verify smooth operation.
5. Attach the can holder to the side of the frame.
6. Secure the padded seat top to the top of the frame using the remaining hardware.
7. Before first use, double-check all connections to ensure they are tight and secure.

4. OPERATION

To use the OEMTOOLS 24994 Workshop Creeper Seat, simply sit on the padded cushion. The four swivel casters allow for 360-degree movement, enabling you to easily roll around your work area without needing to stand up. Utilize the sliding drawers and bottom tray to keep your tools and parts organized and within reach. The integrated can holders provide convenient access to spray cans or beverages.

Your browser does not support the video tag.

Video 4.1: This video demonstrates the features of the OEMTOOLS Workshop Creeper Seat, including its comfortable padded seat, tool storage options, and smooth-rolling casters, highlighting its utility in a garage or workshop environment.

5. MAINTENANCE

Regular maintenance will extend the life and performance of your creeper seat.

- **Cleaning:** Wipe down the seat and frame with a damp cloth and mild detergent as needed. Avoid abrasive cleaners that could damage the finish or upholstery.
- **Casters:** Periodically check the caster wheels for debris, hair, or other obstructions that may hinder smooth rolling. Clean as necessary. Ensure the caster mounting bolts remain tight.
- **Drawer Slides:** Keep drawer slides clean and free of dirt. Lubricate with a light oil if they begin to stick or operate roughly.
- **Hardware:** Regularly inspect all bolts, nuts, and other fasteners to ensure they are tight. Re-tighten if any looseness is detected.
- **Storage:** Store the creeper seat in a dry, clean environment when not in use to prevent rust or damage.

6. TROUBLESHOOTING

If you encounter issues with your OEMTOOLS 24994 Workshop Creeper Seat, refer to the following common problems and solutions:

- **Difficulty Rolling:** Check casters for obstructions (debris, hair) and ensure they are securely attached and not damaged. Clean or replace casters if necessary.
- **Drawers Sticking:** Inspect drawer slides for dirt or damage. Clean and lubricate the slides. Ensure drawers are not overloaded or unevenly weighted.
- **Seat Instability/Wobbling:** Verify that all assembly hardware (bolts, nuts) is securely tightened. Ensure the seat is being used on a flat, level surface. Do not exceed the weight capacity.
- **Missing Parts:** If any parts are missing upon unboxing, contact OEMTOOLS customer support immediately.

7. SPECIFICATIONS

Feature	Specification
Model Number	24994
Brand	OEMTOOLS
Weight Capacity	280 Pounds (127 kg)
Item Weight	17.6 Pounds (7.98 kg)
Item Dimensions (L x W x H)	13.8" x 13.3" x 10.1" (35.05 cm x 33.78 cm x 25.65 cm)
Material Type	Alloy Steel
Color	Black
Caster Size	2 inches
Special Feature	Built-in Organization (drawers, tray, can holders)

8. WARRANTY AND SUPPORT

This OEMTOOLS 24994 Workshop Creeper Seat is covered by the **OEMTOOLS Limited One Year Warranty**. This warranty covers defects in material and workmanship under normal use and service.

For warranty claims, technical support, or to inquire about replacement parts, please contact OEMTOOLS customer service:

- **Website:** www.oem-tools.com
- **Phone:** Refer to the OEMTOOLS website for current contact numbers.
- **Email:** Refer to the OEMTOOLS website for current contact email.

Please have your model number (24994) and proof of purchase available when contacting support.