

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [IKEA](#) /

› [IKEA Svalnas 003.228.97 Wall-Mounted Cabinet with 2 Sliding Doors Instruction Manual](#)

IKEA 003.228.97

IKEA Svalnas 003.228.97 Wall-Mounted Cabinet with 2 Sliding Doors Instruction Manual

INTRODUCTION

Thank you for choosing the IKEA Svalnas 003.228.97 Wall-Mounted Cabinet. This cabinet features two sliding doors and is crafted from durable bamboo, offering a practical and stylish storage solution for your home. This manual provides essential information for safe assembly, proper use, and effective maintenance of your new cabinet.

The sliding doors allow you to choose between concealing or displaying your belongings, and they do not require extra space when opened. The cabinet includes one adjustable shelf for flexible storage.

IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Keep this manual for future reference.

- This product is designed for **indoor use only**.
- **Wall Fasteners:** Different wall materials require different types of fastening devices. Use fastening devices suitable for the walls in your home. If you are unsure, consult a professional.
- **Glass Handling:** The cabinet includes a tempered glass shelf. Handle with care. A damaged edge or scratched surface can cause the glass to crack or break suddenly. Avoid impacts from the side, as this is where the glass is most vulnerable.
- Ensure the cabinet is securely mounted to the wall to prevent tipping and potential injury.

SETUP AND ASSEMBLY

This product requires assembly. Follow the instructions provided in the separate assembly guide that came with your product. Ensure all components are present before beginning assembly.

Key Assembly Steps:

1. Unpack all parts and verify against the parts list in your assembly guide.
2. Assemble the cabinet frame according to the step-by-step illustrations.
3. Install the adjustable shelf at your desired height.
4. Attach the sliding doors to the designated tracks.

5. Mount the cabinet securely to the wall using appropriate fasteners for your wall type. **Do not use the cabinet until it is firmly secured to the wall.**



This image illustrates the overall dimensions of the IKEA Svalnas wall-mounted cabinet, showing a width of 61 cm, a height of 39 cm, and a depth of 33 cm.

OPERATING INSTRUCTIONS

The IKEA Svalnas cabinet is designed for simple and functional use.

- **Sliding Doors:** Gently slide the doors along their tracks to open or close. The sliding mechanism allows for easy access to your stored items without requiring outward swing space.
- **Adjustable Shelf:** The cabinet includes one adjustable shelf. To change its height, carefully remove the shelf, reposition the shelf supports to the desired level, and then place the shelf back onto the supports. Ensure the shelf is level and securely seated before placing items on it.
- **Weight Capacity:** The maximum load for the cabinet is 5 kg (11 lbs). Do not exceed this weight to ensure stability and prevent damage.

CARE AND MAINTENANCE

Proper care will help maintain the appearance and longevity of your IKEA Svalnas cabinet.

- **Cleaning:** Wipe clean with a damp cloth and a mild cleaner. Dry with a clean cloth immediately after cleaning to prevent moisture damage, especially to the bamboo surfaces.

- **Glass Shelf:** For the tempered glass shelf, use a glass cleaner and a soft cloth. Avoid abrasive cleaners or scouring pads that could scratch the surface.
- **Avoid Harsh Chemicals:** Do not use strong chemical cleaners, as they may damage the finish of the bamboo or other materials.
- **Environmental Conditions:** Avoid placing the cabinet in areas with extreme humidity or direct sunlight, which can affect the bamboo and finish over time.

TROUBLESHOOTING

If you encounter any issues with your cabinet, consider the following common solutions:

- **Doors not sliding smoothly:** Check the tracks for any obstructions or debris. Ensure the doors are correctly seated in their tracks.
- **Cabinet feels unstable:** Verify that the wall fasteners are securely tightened and appropriate for your wall type. Re-check the assembly of the cabinet frame.
- **Shelf not level:** Ensure the shelf supports are inserted correctly and are at the same height on both sides.

For persistent issues or if you require further assistance, please contact IKEA customer support.

PRODUCT SPECIFICATIONS

Model Number	003.228.97
Brand	IKEA
Dimensions (Width x Depth x Height)	61 cm x 33 cm x 39 cm (24" x 13" x 15.4")
Weight	Approximately 4.99 kg (11 lbs)
Max. Load per Shelf	5 kg (11 lbs)
Materials	<ul style="list-style-type: none"> • Top/Bottom Panel: Bamboo, Paper, Clear Acrylic Lacquer • Side Panel: Bamboo, Cardboard, Paper, Clear Acrylic Lacquer • Back Panel: Cardboard • Door/Support: Steel, Epoxy/Polyester Powder Coating • Shelf: Tempered Glass
Color	White (doors) with Bamboo frame
Assembly Required	Yes
Included Components	1 adjustable shelf



A close-up view of the IKEA Svalnas cabinet, demonstrating its sliding door mechanism and the interior storage space with an adjustable shelf, holding various items.

WARRANTY INFORMATION

IKEA products typically come with a limited warranty. Please refer to the warranty information provided with your purchase or visit the official IKEA website for details regarding the specific warranty terms and conditions for the Svalnas series.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact IKEA customer service. You can find contact information on the official IKEA website or in the documentation included with your product.

Online Resources: For additional support, assembly videos, and FAQs, visit the official IKEA website and search for "Svalnas 003.228.97".