

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TableTop King](#) /

› [TableTop King WGR140 Electric Countertop Griddle 17-inch, 120V User Manual](#)

## TableTop King WGR140

# TableTop King WGR140 Electric Countertop Griddle 17-inch, 120V User Manual

Model: WGR140

## IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions thoroughly before operating this appliance to ensure safe and efficient use. Retain this manual for future reference.

- Always connect the griddle to a grounded 120V AC electrical outlet.
- Do not immerse the griddle, cord, or plug in water or other liquids.
- Ensure the griddle is placed on a stable, level, heat-resistant surface.
- Keep hands and utensils away from the hot cooking surface during operation.
- Unplug the griddle from the outlet when not in use and before cleaning. Allow to cool completely before handling or cleaning.
- Do not operate the griddle with a damaged cord or plug, or if the appliance malfunctions or has been damaged in any manner.
- This appliance is intended for commercial use.

## SETUP AND INSTALLATION

1. **Unpacking:** Carefully remove the griddle from its packaging. Inspect for any shipping damage. Report any damage immediately to the carrier and supplier.
2. **Placement:** Position the griddle on a sturdy, level, non-combustible surface. Ensure adequate clearance (at least 6 inches) from walls and other equipment for proper ventilation. Do not place near flammable materials.
3. **Electrical Connection:** Connect the griddle to a dedicated 120V AC, 60Hz grounded electrical outlet. Ensure the electrical supply matches the appliance's requirements.
4. **Initial Cleaning:** Before first use, wipe down the griddle surface and exterior with a damp cloth and mild detergent. Rinse thoroughly and dry completely.



Figure 1: Angled view of the TableTop King WGR140 Electric Countertop Griddle, showing the stainless steel construction and side handles.

## OPERATING INSTRUCTIONS

---

- 1. Power On:** Plug the griddle into a suitable electrical outlet. The "POWER" indicator light (red) will illuminate.
- 2. Set Temperature:** Turn the temperature control knob to the desired cooking temperature. The available temperature range is typically from MIN to 490°F (280°F, 350°F, 420°F, 490°F are marked on the knob).
- 3. Preheating:** Allow the griddle to preheat. The "READY" indicator light (green) will illuminate when the set temperature is reached. This may take 10-15 minutes depending on the desired temperature.
- 4. Cooking:** Once preheated, place food directly onto the griddle surface. Adjust the temperature as needed during cooking.
- 5. Grease Management:** Excess grease and food debris will drain into the removable grease tray located at the front of the griddle. Empty the grease tray regularly, especially after each use.
- 6. Power Off:** After use, turn the temperature control knob to the "MIN" position. Unplug the griddle from the electrical outlet and allow it to cool completely before cleaning.



Figure 2: Front view of the TableTop King WGR140 Electric Countertop Griddle, highlighting the power and ready indicator lights, and the temperature control knob with marked settings.

## MAINTENANCE AND CLEANING

---

Regular cleaning and maintenance will extend the life of your griddle and ensure optimal performance.

- 1. Always unplug the griddle and allow it to cool completely before cleaning.**
- 2. Daily Cleaning:**
  - Remove the grease tray and empty its contents. Wash the tray with warm, soapy water, rinse, and dry thoroughly.
  - Scrape any food residue from the griddle surface using a griddle scraper or spatula.
  - Wipe the griddle surface with a damp cloth and mild detergent. For stubborn residue, a non-abrasive griddle cleaner may be used. Rinse thoroughly with a clean, damp cloth to remove all detergent residue.
  - Wipe down the exterior stainless steel surfaces with a damp cloth. Dry with a soft, clean cloth to prevent water spots.
- 3. Deep Cleaning:** Periodically, a more thorough cleaning may be required. Follow daily cleaning steps, and for heavily soiled surfaces, consider using specialized griddle cleaning pads or stones as directed by their manufacturers. Always ensure the griddle is cool.
- 4. Do NOT use abrasive cleaners, steel wool, or sharp objects** that could scratch or damage the griddle

surface or exterior.

5. Do NOT use water jets or immerse the griddle in water.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
Griddle does not heat up.	Not plugged in. Power outlet malfunction. Circuit breaker tripped. Temperature knob set to "MIN".	Ensure the power cord is securely plugged into a grounded outlet. Test the outlet with another appliance. Reset the circuit breaker. Turn the temperature knob to a desired setting.
Uneven heating.	Griddle not fully preheated. Griddle not on a level surface.	Allow sufficient time for the griddle to reach the set temperature (until "READY" light illuminates). Ensure the griddle is placed on a perfectly level surface.
Excessive smoke during operation.	Food residue or grease buildup on the griddle surface. Grease tray is full.	Clean the griddle surface thoroughly. Empty and clean the grease tray.

If troubleshooting steps do not resolve the issue, contact customer support.

## SPECIFICATIONS

Feature	Detail
Model	WGR140
Brand	TableTop King
Type	Electric Countertop Griddle
Voltage	120 Volts
Wattage	150 watts ( <i>Note: This value is provided by the manufacturer. Typical commercial griddles may have higher wattage.</i> )
Material	Metal (Stainless Steel)
Color	Silver
Special Feature	Electric
Included Components	1 x Grill Mat ( <i>Note: This may refer to a non-stick mat for cooking or a protective mat for the countertop.</i> )
UPC	738577064391
ASIN	B07HMLSQDC

## WARRANTY INFORMATION

TableTop King products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the warranty card included with your product or contact TableTop King customer service. Keep your purchase receipt as proof of purchase for any warranty claims.


## CUSTOMER SUPPORT

For technical assistance, parts, or service inquiries, please contact TableTop King customer support. Refer to the contact information provided in your product packaging or visit the official TableTop King website for current support details.

**Online Resources:** [TableTop King Store on Amazon](#)

### Related Documents - WGR140

 PRODUCT ACCESSORIES INSTALLATION STEPS Step 1: Place the glass window on the lid. Step 2: Place the lid on the griddle. Step 3: Insert the screw into the hole. Step 4: Tighten the screw. Done!	<p><a href="#">BBQ Future Griddle Clear View Lid Installation Guide</a></p> <p>Step-by-step guide for installing the BBQ Future Griddle Clear View Lid on Blackstone 22-inch griddles, featuring a glass window hood for enhanced visibility during cooking.</p>
 BLACKSTONE 22" TABLETOP GRIDDLE Owner's Manual MODEL 1665	<p><a href="#">Blackstone 22" Tabletop Griddle Owner's Manual (Model 1665) - Assembly, Use, and Care</a></p> <p>Comprehensive owner's manual for the Blackstone 22" Tabletop Griddle, Model 1665. It covers safety precautions, assembly, operation, maintenance, troubleshooting, and griddle seasoning to ensure safe and optimal use.</p>
 Weber TRAVELER REGISTER TODAY OWNER'S MANUAL 17" & 22" TABLETOP GRIDDLE	<p><a href="#">Weber Traveler 17"/22" Tabletop Griddle LP Owner's Manual</a></p> <p>Comprehensive owner's manual for the Weber Traveler 17"/22" Tabletop Griddle. Includes installation, operation, safety, maintenance, and troubleshooting instructions.</p>
 State™ Tabletop Griddle (17") Quick Start Guide weber SЛАТЕ™	<p><a href="#">Weber Slate 17" Tabletop Griddle Quick Start Guide: Preheat &amp; Cooking Settings</a></p> <p>Get started with your Weber Slate 17" tabletop griddle. This quick start guide provides essential preheat times, cooking temperatures, and tips for griddling.</p>

	<p><a href="#"><u>Dyna-Glo 2-Burner Portable Tabletop Gas Griddle User Manual &amp; Assembly Guide</u></a></p> <p>Comprehensive user manual and assembly guide for the Dyna-Glo 2-Burner Portable Tabletop Gas Griddle (Model DGL345SNPL/DGL345SNPL-D). Includes safety instructions, operating procedures, cleaning, and troubleshooting tips.</p>
	<p><a href="#"><u>King HW-FS, HWP-FS, HWPT-FS 120V Series Thermostat Installation, Wiring, and Programming Guide</u></a></p> <p>Comprehensive guide for King Electric's HW-FS, HWP-FS, and HWPT-FS 120V series thermostats. Covers general information, safety, specifications, wiring instructions, programming for HWP/HWPT models, installation, and maintenance. Includes details on temperature control for residential and commercial heating systems.</p>