

[Manuals.plus](#) /

› [Epson](#) /

› Epson DS-70 Document Scanner User Manual

Epson DS-70

Epson DS-70 Document Scanner User Manual

Model: DS-70 | Brand: Epson

PRODUCT OVERVIEW

The Epson DS-70 is a compact and lightweight mobile single-sheet-fed document scanner designed for professionals who need efficient scanning on the go. It offers fast scanning speeds, capable of processing a single page in as fast as 5.5 seconds. This versatile scanner supports various document types, including standard paper up to 8.5" x 72", as well as business cards, ID cards, and receipts. It comes equipped with OCR (Optical Character Recognition) and document management software, enabling users to easily create editable text and searchable PDF files. The DS-70 is conveniently powered via USB when connected to a computer, eliminating the need for external power adapters or batteries. It is compatible with both Windows and Mac operating systems, making it suitable for a wide range of work environments.

SETUP GUIDE


What's in the Box

Upon unboxing your Epson DS-70, verify that all components are present:

- DS-70 document scanner
- Start Here poster
- USB cable
- Maintenance sheets

In the Box


DS-70 Portable Document Scanner



USB Cable



Maintenance Sheets



Start Here Poster

Figure 1: Included items with the Epson DS-70 Document Scanner.

Connecting the Scanner

The Epson DS-70 is a **USB-powered** device, meaning it draws power directly from your computer via the USB cable. No external power adapter or batteries are required for operation.

1. Connect one end of the provided USB cable to the USB port on the Epson DS-70 scanner.
2. Connect the other end of the USB cable to an available USB port on your computer (Windows or Mac).



Figure 2: The Epson DS-70 scanner connected via USB, indicating no external power is needed.

Software Installation

The necessary drivers and software for the Epson DS-70 are available for download from the official Epson support website. A software installation disc is not included with the product. Ensure your scanner is connected to your computer before starting the software installation process.

- Visit the official Epson support website for the DS-70 model.
- Download and install the latest drivers and document management software.
- Follow the on-screen instructions to complete the installation.

OPERATING THE SCANNER

Scanning Documents

The Epson DS-70 is designed for quick and efficient single-sheet scanning. It can scan a single page in as fast as 5.5 seconds at 300 dpi (based on 8.5" x 11" 1-sheet scan speed).

1. Ensure the scanner is connected and the software is running on your computer.
2. Insert the document face-up into the scanner's input slot. The scanner will automatically detect the document.
3. Initiate the scan from the Epson scanning software on your computer.

4. The scanned image will appear in the software interface, allowing you to review, edit, and save.



Figure 3: Document being fed into the Epson DS-70 scanner.



Scan a Single
Page in as
**Fast as 5.5
Seconds¹**

1 At 300 dpi, based on 8.5" x 11", 1-sheet scan speed.

Figure 4: User scanning a document quickly with the DS-70.

Versatile Document Handling

The DS-70 can handle a variety of media types and sizes, making it suitable for diverse scanning needs:

- **Documents:** Scans documents up to 8.5" x 72" in length.
- **Cards:** Capable of scanning business cards and ID cards.
- **Receipts:** Ideal for digitizing receipts for expense tracking.



Scan Documents
up to 8.5" x 72" —
**Plus Business/
ID Cards and
Receipts**

Figure 5: The DS-70's ability to scan various document sizes and types.

OCR and Document Management

The included OCR and document management software allows you to transform your scanned images into editable text and searchable PDF files. This feature enhances productivity by making your digitized documents easily retrievable and modifiable. The scanner also supports an **Automatic Feeding Mode**, which allows you to combine multiple single-page scans into one continuous file, simplifying the handling of multi-page documents.

Official Product Video



Video 1: "Ultra Fast Portable Business Scanners from Epson" - This video provides a comprehensive overview of the Epson DS-70 and DS-80W scanners, highlighting their speed, portability, and key features for business use, including document handling and software capabilities.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Epson DS-70 scanner. Refer to the included "Maintenance sheets" for detailed instructions.

- **Cleaning:** Periodically clean the scanner's rollers and glass surfaces using a soft, lint-free cloth. For stubborn marks, use a mild, non-abrasive cleaner specifically designed for electronics.
- **Software Updates:** Keep your scanner's drivers and software updated by regularly checking the Epson support website for new versions.

TROUBLESHOOTING

If you encounter issues with your Epson DS-70 scanner, consider the following common troubleshooting steps:

- **Scanner Not Detected:**
 - Ensure the USB cable is securely connected to both the scanner and the computer.
 - Try connecting to a different USB port on your computer.
 - Restart your computer and the scanner.
 - Verify that the correct drivers are installed and up to date.
- **Poor Scan Quality:**
 - Clean the scanner's glass and rollers as described in the Maintenance section.
 - Adjust the scan settings (resolution, color mode) in the Epson scanning software.
 - Ensure the document is inserted correctly and flat.
- **Paper Jams:**
 - Carefully remove any jammed paper from the scanner.
 - Ensure documents are not wrinkled or torn before feeding.
 - Do not overload the input slot.

For more detailed troubleshooting, please refer to the comprehensive [User Guide \(PDF\)](#) available on the Epson support website.

SPECIFICATIONS

Feature	Detail
Product Dimensions	1.8 x 10.7 x 1.3 inches
Item Weight	9.4 ounces (0.59 Pounds)
Model Number	DS-70
Scanner Type	Document
Media Type	Receipt, ID Card, Business Card
Connectivity Technology	USB
Resolution	1200 dpi
Scanning Speed	As fast as 5.5 seconds per page (300 dpi, 8.5" x 11", 1-sheet)
Power Consumption (Operation)	2.5 watts
Sheet Size	Up to 8.50 x 14 inches (standard), up to 8.5" x 72" (long documents)
Color Depth	16-bit

WARRANTY AND SUPPORT

The Epson DS-70 Document Scanner is backed by a **3-year limited warranty** with Next-Business-Day Replacement. This commitment ensures world-class service and support for your product.

For detailed warranty terms and conditions, or to access support resources, please visit the official Epson website. Contact information for customer support can typically be found on the Epson support pages or in your product's documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07HP2F1PZ>

More documents and user manuals: <https://manuals.plus/>