

[Manuals.plus](#) /

> [auna](#) /

> auna MCD-82 Compact Stereo System User Manual

## auna MCD6-82 BT BK

# auna MCD-82 Compact Stereo System User Manual

Model: MCD6-82 BT BK

## 1. INTRODUCTION

---

Thank you for purchasing the auna MCD-82 Compact Stereo System. This system combines modern audio-visual playback technology with a slim design, offering versatile entertainment options. Please read this manual thoroughly before use to ensure proper operation and to maximize the lifespan of your device. Keep this manual for future reference.

## 2. SAFETY INSTRUCTIONS

---

- Read all instructions carefully before operating the device.
- Keep the unit away from heat sources, direct sunlight, humidity, water, and other liquids.
- Do not expose the unit to extremely high or low temperatures.
- Do not operate the unit if it has been exposed to water, moisture, or any other liquids to prevent electric shock, explosion, and/or injury to yourself and damage to the unit.
- Do not use the unit if it has been dropped or damaged in any way.
- Repairs to electrical equipment should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
- Do not insert objects into any openings.
- Use only accessories recommended by the manufacturer.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## 3. PACKAGE CONTENTS

---

Carefully unpack your auna MCD-82 system and ensure all items are present and in good condition. The package should include:

- Main Unit
- 2 x Speaker Boxes
- Remote Control
- User Manual (this document)

## 4. PRODUCT OVERVIEW

---

The auna MCD-82 is a versatile compact stereo system designed for various audio and video playback. It features a slim design suitable for wall mounting or stand placement.



### KOMPLETTSYSTEM

Integrierter DVD-Player sowie zwei  
Stereo-Lautsprecher

**Figure 4.1:** The auna MCD-82 as a complete system, featuring an integrated DVD player and two stereo speakers.



## FORMATVIELFALT

DVD-/CD-Player, USB- & SD-Ports, analoger UKW-Tuner sowie HDMI-Anschluss und AUX-Eingang

**Figure 4.2:** Rear view of the auna MCD-82 showing various connection ports including HDMI Output, Video, L/R Audio, USB, and SD/MMC/MS slots.

### 4.1 Front Panel Controls

The front panel includes an LCD display, a central control knob, and various buttons for playback, mode selection, and volume adjustment. The CD compartment is located centrally.

### 4.2 Rear Panel Connections

The rear panel provides the following connection options:

- **USB Port:** For connecting USB storage devices.
- **SD Card Slot:** For inserting SD/MMC/MS memory cards.
- **AUX Input (3.5mm jack):** For connecting external audio devices.
- **Headphone Output (3.5mm jack):** For private listening.
- **Speaker Outputs:** Terminal set for connecting the two external speakers.

- **HDMI Output:** For connecting to a TV or monitor for video playback.
- **A/V Output (RCA):** For connecting to older TVs or monitors.
- **FM Antenna Input:** For connecting the included wire antenna.

## 5. SETUP

### 5.1 Placement

The auna MCD-82 can be placed on a flat surface using its stand or mounted on a wall to save space.



**Figure 5.1:** The auna MCD-82 can be easily wall-mounted or placed on a surface using its stand, offering flexible, space-saving installation options.

### 5.2 Speaker Connection

Connect the two speaker boxes to the speaker terminal set on the rear of the main unit. Ensure correct polarity (positive to

positive, negative to negative) for optimal sound quality.

### 5.3 Power Connection

Connect the power adapter to the DC input on the main unit and then plug it into a suitable wall outlet.

### 5.4 Remote Control Battery Installation

Open the battery compartment on the back of the remote control. Insert 2 x 1.5V AAA batteries (not included), ensuring correct polarity. Close the compartment.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Power On/Off and Standby

Press the **STANDBY** button on the unit or remote control to switch the system on or off. When off, the system enters standby mode.

### 6.2 Mode Selection

Press the **MODE** button on the unit or remote control to cycle through available input sources: CD/DVD, USB, SD, Bluetooth, AUX, and Radio (OUC/FM).

### 6.3 CD/DVD Playback

The system supports CD, CD-R(W), MP3-CD, DVD, DIVX, and MPEG4 formats.



## KOMPATIBLES LAUFWERK

Unterstützt DVD, DIVX, MPEG4,  
CD-R/RW & MP3-Formate

**Figure 6.1:** The auna MCD-82 features a compatible drive that supports DVD, DIVX, MPEG4, CD-R/RW, and MP3 formats.

1. Gently open the CD compartment cover.
2. Place a disc onto the spindle, ensuring it clicks into place.
3. Close the CD compartment cover.
4. Select CD/DVD mode using the **MODE** button. Playback should start automatically.
5. Use **PLAY/PAUSE**, **STOP**, and **SKIP** buttons (◀◀ ▶▶) for control.
6. The system offers repeat and random playback functions.

### 6.4 USB/SD Playback

Insert a USB drive into the USB port or an SD card into the SD slot. Select USB or SD mode. The system will automatically detect and play compatible audio files (e.g., MP3). Use the navigation buttons to browse folders and tracks. ID3 tag information will be displayed if available.

### 6.5 Bluetooth Streaming

The auna MCD-82 allows wireless audio streaming from Bluetooth-enabled devices.



**Figure 6.2:** The auna MCD-82 offers wireless connectivity via Bluetooth for music streaming from smartphones, tablets, laptops, and other compatible devices.

1. Select **Bluetooth** mode using the **MODE** button. The display will show "BT" or a similar indicator, and the unit will enter pairing mode.
2. On your smartphone, tablet, or laptop, enable Bluetooth and search for available devices.
3. Select "auna MCD-82" (or similar name) from the list of devices to pair.
4. Once paired, you can stream audio from your device to the stereo system.

## 6.6 Radio (OUC/FM)

Extend the FM wire antenna for better reception.

1. Select **Radio** mode using the **MODE** button.
2. To perform an automatic station scan, press and hold the **PLAY/PAUSE** button. The system will scan and save available stations (up to 20 presets).
3. To manually tune, use the **SKIP** buttons (◀◀ ▶▶).

4. To recall saved presets, use the **CH-** / **CH+** buttons.

## 6.7 AUX Input

Connect an external audio device (e.g., MP3 player, CD player, computer) to the **AUX IN** jack using a 3.5mm audio cable. Select **AUX** mode to play audio from the connected device.

## 6.8 Headphone Output


Plug headphones into the **HEADPHONE** jack for private listening. The main speakers will be muted automatically.

## 6.9 Sound Adjustment

The system offers equalizer presets (Piano, Classic, Rock, Pop, Jazz) to adjust the sound profile. These can typically be accessed via the remote control. Some models may also allow manual adjustment of bass and treble.

## 6.10 Remote Control Operation

The included remote control provides convenient access to all functions from a distance.



# BEQUEM

Einfache Steuerung von der Couch  
via Fernbedienung

**Figure 6.3:** The auna MCD-82 can be conveniently controlled from a distance using the provided remote control.

## 7. MAINTENANCE

### 7.1 Cleaning

Wipe the unit with a soft, dry cloth. Do not use abrasive cleaners, waxes, or solvents as they may damage the finish. Ensure the unit is unplugged before cleaning.

### 7.2 Disc Care

Handle discs by their edges. Keep them clean and free of scratches. Store discs in their cases when not in use.

## 8. TROUBLESHOOTING

If you encounter issues with your auna MCD-82 system, please refer to the following table before contacting support.

| Problem                  | Possible Cause                                                               | Solution                                                                                         |
|--------------------------|------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|
| No power                 | Power cable not connected; power outlet faulty.                              | Check power cable connection; try a different outlet.                                            |
| No sound                 | Volume too low; speakers not connected; wrong input mode.                    | Increase volume; check speaker connections; select correct input mode.                           |
| CD/DVD not playing       | Disc dirty or scratched; disc inserted incorrectly; unsupported format.      | Clean or replace disc; ensure disc is correctly placed; check disc format compatibility.         |
| Bluetooth not connecting | Bluetooth not enabled on device; system not in pairing mode; device too far. | Enable Bluetooth on your device; ensure system is in Bluetooth pairing mode; move device closer. |
| Poor radio reception     | Antenna not extended; weak signal.                                           | Fully extend the FM wire antenna; try repositioning the antenna or the unit.                     |

## 9. SPECIFICATIONS

The following are the technical specifications for the auna MCD-82 Compact Stereo System:

- **Model Number:** MCD6-82 BT BK
- **Connectivity:** Bluetooth, USB, SD, AUX (3.5mm), Headphone (3.5mm), HDMI, A/V Output
- **Supported Media:** CD, CD-R(W), MP3-CD, DVD, DIVX, MPEG4
- **Tuner:** OUC/FM with 20 preset stations
- **Speaker Type:** 2-way Bass Reflex Stereo Speakers
- **Audio Output Mode:** Stereo
- **Equalizer Presets:** Piano, Classic, Rock, Pop, Jazz

- **Color:** Black
- **Main Unit Dimensions (W x H x D):** Approximately 20 x 28 x 26 cm
- **Speaker Dimensions (W x H x D):** Approximately 19 x 28 x 17 cm (each)
- **Remote Control Power:** 2 x 1.5V AAA batteries (not included)



**Figure 9.1:** Dimensions of the auna MCD-82 main unit, approximately 44 cm wide, 23.8 cm high, and 10.8 cm deep.

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the time of purchase or contact your retailer. Keep your proof of purchase for any warranty claims.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**<https://manuals.plus/asin/B07HP8RD36>**

More documents and user manuals: **<https://manuals.plus/>**