

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Gillette](#) /
- › [Gillette Custom Plus3 Disposable Razors \(36-Count\) User Manual](#)

Gillette 1243053

Gillette Custom Plus3 Disposable Razors (36-Count) User Manual

Essential instructions for safe and effective use.

1. SETUP

1.1 Unpacking

Carefully open the product packaging. Remove the razors from the blister pack. Inspect each razor for any visible damage before initial use.



Image: Gillette Custom Plus3 Disposable Razors 36-count box.

2. OPERATING INSTRUCTIONS

2.1 Preparing for Shave

1. **Wet Skin:** Thoroughly wet the area of skin you intend to shave with warm water.
2. **Apply Shaving Cream/Gel:** Apply a generous amount of shaving cream or gel to create a rich lather.

This helps to soften the hair and lubricate the skin, reducing friction and irritation.

2.2 Shaving Technique

1. **Hold Razor:** Hold the Gillette Custom Plus3 razor firmly but comfortably in your hand. The ergonomic handle is designed for a secure grip, even when wet.
2. **Shave with the Grain:** For best results and to minimize skin irritation, shave in the direction of hair growth using light, even strokes. The 40-degree pivot head adjusts to the contours of your face or body for a close shave.
3. **Rinse Frequently:** Rinse the razor head frequently under running water during your shave to prevent hair and shaving cream buildup between the blades. The Easy Rinse Blades are designed for efficient cleaning.
4. **Post-Shave Care:** After shaving, rinse your skin with cool water and pat dry. Apply an aftershave balm or moisturizer to soothe and hydrate the skin.





Image: A single Gillette Custom Plus3 Disposable Razor, highlighting its design.

3. MAINTENANCE

3.1 Cleaning the Razor

- After each stroke, rinse the razor head under running water to clear away hair and shaving cream.
- Do not tap the razor against the sink or any hard surface, as this can damage the precision blades.

3.2 Storage

- Store your razor in a dry environment to prolong blade life.
- Always place the protective cap back on the razor head when not in use to protect the blades from damage and maintain hygiene.

4. TROUBLESHOOTING

Issue	Solution
Skin irritation or nicks	Ensure skin is well-lubricated with shaving cream/gel. Shave in the direction of hair growth. Replace the razor if blades are dull.
Dull blades	Replace the razor with a new one. Disposable razors are designed for optimal performance for a limited number of shaves.

Issue	Solution
Blades clogging with hair/cream	Rinse the razor frequently under running water during shaving. Do not tap the razor against hard surfaces.

5. SPECIFICATIONS

Feature	Detail
Brand	Gillette
Model	Custom Plus3 (1243053)
Number of Blades	3
Special Features	Ergonomic handle, Moisturizing Strip (Comfortgel Technology), Pivoting Head (40-degree)
Unit Count	36.00 Count
GTIN/UPC	047400662797

6. WARRANTY AND SUPPORT

6.1 Warranty Information

Gillette Custom Plus3 Disposable Razors are designed for single-use or limited use, depending on individual shaving habits and hair type. For specific information regarding product quality or manufacturing defects, please refer to Gillette's official website or contact their customer support directly.

6.2 Customer Support

For further assistance, inquiries, or to provide feedback, please visit the official Gillette website. Contact details, including phone numbers and email addresses, can typically be found on the product packaging or the brand's official online presence.