

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [IKEA](#) /
- › [IKEA Skadis Connector Instruction Manual](#)

IKEA 103.207.89

IKEA Skadis Connector Instruction Manual

PRODUCT OVERVIEW





This image displays two white IKEA Skadis Connectors. Each connector consists of a long, flat metal piece with two holes at the top for attachment to a pegboard, and a C-shaped clamp mechanism at the bottom. A blue threaded screw with a white plastic knob is visible, used to tighten the clamp onto a surface. The connectors are designed to secure a Skadis pegboard to a desk or shelf edge without drilling.

The IKEA Skadis Connector is designed to securely attach your Skadis pegboard to various surfaces, such as desks, shelves, or tabletops. This product provides a stable mounting solution without the need for drilling, utilizing a robust clamping mechanism.

FEATURES

- Product Model: 103.207.89
- Durable metal construction
- Adjustable to accommodate different mount thicknesses
- No drilling required for installation

SETUP

Follow these steps to properly set up your IKEA Skadis Connector:

1. **Attach to Pegboard:** Align the two holes at the top of the Skadis Connector with the corresponding holes on your IKEA Skadis pegboard. Secure the connector to the pegboard using appropriate screws (typically provided with the Skadis pegboard or the connector itself, if specified). Ensure a firm attachment.

2. **Position the Pegboard:** Place the Skadis pegboard, with the connectors attached, against the edge of the surface where you intend to mount it (e.g., desk, shelf).
3. **Secure the Clamp:** Position the clamp mechanism of the connector around the edge of the surface. Turn the white plastic knob on the threaded screw clockwise to tighten the clamp. Continue tightening until the pegboard is securely fastened and does not wobble.
4. **Verify Stability:** Gently test the stability of the mounted pegboard to ensure it is firmly in place before placing items on it.

OPERATING

Once installed, the IKEA Skadis Connector operates by providing a stable and non-permanent mounting solution for your Skadis pegboard. It allows you to utilize vertical space efficiently by keeping your pegboard securely attached to a horizontal surface. The adjustable clamp ensures compatibility with various surface thicknesses, providing flexibility in placement.

MAINTENANCE

To ensure the longevity and proper function of your Skadis Connector, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the connectors with a soft, damp cloth. Use a mild detergent if necessary, then dry thoroughly. Avoid abrasive cleaners or harsh chemicals.
- **Check Tightness:** Periodically check the tightness of the clamping screw. If the pegboard feels loose, re-tighten the screw to ensure a secure fit.
- **Inspect for Damage:** Regularly inspect the metal components for any signs of wear, corrosion, or damage. If any damage is observed, discontinue use and consider replacement.

TROUBLESHOOTING

Pegboard is not stable or feels loose:

- Ensure the clamping screw is fully tightened against the surface.
- Verify that the connector is properly attached to the Skadis pegboard.
- Check if the surface thickness is within the adjustable range of the connector.

Screws for attachment are missing:

- The IKEA Skadis Connector is designed to clamp onto a surface without drilling into that surface. The product itself may or may not include screws for attaching the connector to the Skadis pegboard. Please refer to the product packaging or the Skadis pegboard instructions for details on necessary screws for pegboard attachment.
- If screws for attaching the connector to the pegboard are missing and were expected, contact the retailer or IKEA customer support.

SPECIFICATIONS

Attribute	Detail
Brand	IKEA

Attribute	Detail
Model Number	103.207.89
Color	White
Material	Metal
Finish Type	Powder
Mounting Type	Wall Mount (via pegboard) / Clamp-on (to surface)
Style	Adjustable
Item Weight	0.01 Ounces
Maximum Weight Capacity	1.3 Pounds (approx. 0.5 Kilograms)
Included Components	[Mounting Screws] (for attachment to pegboard)
Number of Hooks	2 (referring to the pair of connectors)
Surface Recommendation	Wood (for clamping surface)

WARRANTY AND SUPPORT

For information regarding product warranty, returns, or technical support, please refer to your purchase receipt or contact the retailer from whom you purchased the IKEA Skadis Connector. You may also visit the official IKEA website or contact IKEA customer service directly for assistance with product-related inquiries.

Please have your product model number (103.207.89) and purchase details ready when contacting support.