

Ingenuity 11624

Ingenuity SimpleComfort Baby Swing Instruction Manual

Brand: Ingenuity | Model: 11624

1. INTRODUCTION

Product Overview

The Ingenuity SimpleComfort Compact Soothing Swing is designed to provide ultimate comfort and soothing for your baby. It features multiple swing directions, adjustable recline, soothing vibrations, and a control panel for customized settings. This swing is suitable for babies from 0 to 9 months, weighing between 6 and 20 lbs.



Image: The Ingenuity SimpleComfort Baby Swing in Pink Cassidy, showcasing its overall design and color scheme.

Key Features

- **Multi-Directional Swing:** Rotates 180 degrees and swings in 3 directions (side-to-side & front-to-back).
- **Adjustable Comfort:** Features a comfy oversized seat with a removable headrest for newborns and a 2-position recline.
- **Soothing Options:** Includes 6 swing speeds, 8 melodies, 3 nature sounds, white noise, and soothing vibrations.
- **Portable Design:** Lightweight frame with a handle and wheels for easy room-to-room movement.
- **Convenient Controls:** GentleTouch control panel with timer settings (30, 45, or 60 minutes) and auto-shut off after 2 hours.
- **Engaging Mobile:** Overhead mobile with 2 plush toys (flower and birdie) to stimulate baby.
- **Easy Maintenance:** Machine washable seat pad and headrest for simple cleaning.
- **Safety:** Equipped with a 5-point harness for secure placement.
- **Power Options:** Swing motion and music powered by included USB cord; vibrations powered by 1 C battery (not included).

2. SETUP AND ASSEMBLY

Unpacking

Carefully remove all components from the packaging. Ensure all parts listed in the assembly guide are present before beginning assembly. Keep packaging materials away from children.

Assembly Instructions

Assembly is required for this product. Please refer to the detailed assembly instructions provided in the original packaging for step-by-step guidance. Ensure all connections are secure before use.





Image: An annotated diagram highlighting key components of the swing, including controls, headrest, mobile, recline, and harness.

Powering the Unit

- The swing motion and music functions are powered by the included USB cord. Connect the USB cord to a compatible power adapter (not included) and then to a wall outlet.

- The vibration unit requires 1 C battery (not included). The battery compartment is located at the base of the swing.



**Swing powered by the included USB cord
and vibrations powered by 1 C battery**

Image: A visual representation of the USB power cord and a note about the C battery for vibration.

3. OPERATING INSTRUCTIONS

Control Panel Overview

The GentleTouch control panel allows you to customize your baby's soothing experience.



TrueSpeed™ Technology maintains 6 speeds as baby grows. WhisperQuiet motor.

Image: A detailed view of the control panel, showing buttons for power, sounds, music, volume, speed, and timer settings.

- **Power Button:** Turns the swing on or off.
- **Nature Sounds/Music Buttons:** Select from 3 nature sounds or 8 melodies.
- **Volume Control:** Adjust the audio volume (high or low).
- **Swing Speed:** Choose from 6 different swing speeds using TrueSpeed Technology, which maintains consistent speed as your baby grows.
- **Timer Settings:** Set the swing to operate for 30, 45, or 60 minutes. The swing will auto-shut off after 2 hours if no timer is selected.

Swing Directions

The seat rotates 180 degrees, allowing the swing to move in 3 different directions: front-to-back or side-to-side. This versatility helps find the most soothing motion for your baby.



Seat Rotates 180 degrees and swings in 3 directions

Image: The swing demonstrating its ability to rotate 180 degrees and swing in three directions.

Recline Adjustment

The seat offers a 2-position recline to accommodate your baby's comfort needs, from a more upright position to a flatter recline.



Image: A baby comfortably seated in the swing, illustrating the recline feature.

Vibration Feature

Activate the soothing vibration feature by pressing the button located at the base of the seat. This requires one C battery (not included).



Soft music, sounds
and vibrations for
soothing.

Swing turns off
automatically with
the 30, 45 or 60
minute timer
settings.



Image: A close-up of the vibration button on the swing's seat.

Overhead Mobile and Safety Harness

The swing includes an overhead mobile with two plush toys that can be removed if desired. The 5-point harness ensures your baby is securely fastened in the swing.



Image: A baby secured in the swing, highlighting the 5-point harness and the overhead mobile with toys.

4. CARE AND MAINTENANCE

Cleaning Instructions

- **Frame:** Wipe the metal frame with a soft, clean cloth and mild soap.
- **Seat Pad and Headrest:** Remove from frame. Fasten buckles on seat restraint and seat pad. Fasten all hook-and-loop patches to the corresponding patch. Machine wash with cold water, gentle cycle. No bleach. Tumble dry, using low heat.
- **Toy Bar and Toys:** Wipe clean with a damp cloth and mild soap. Air dry. Do not immerse in water.



Image: The removable seat pad being placed into a washing machine, demonstrating its machine-washable feature.

Storage

When storing the swing, always keep it in a dry location, away from any heat sources, and out of direct sunlight.

5. TROUBLESHOOTING

For common issues and solutions, please refer to the comprehensive troubleshooting section in the full user manual provided with your product. If problems persist, contact customer support.

6. PRODUCT SPECIFICATIONS


Attribute	Detail
Brand	Ingenuity
Model Number	11624
Color	Cassidy
Product Dimensions (D x W x H)	34.25" x 29.53" x 36.22"
Item Weight	14.96 pounds
Material Composition	64% Metal, 29% Plastic, 7% Fabric
Recommended Age/Weight	0-9 Months / 6-20 lbs
Power Source	Corded Electric (USB) for swing/music, Battery Powered (1 C battery) for vibration
Assembly Required	Yes





7. WARRANTY AND SUPPORT

For detailed warranty information and customer support, please refer to the official user manual included with your product or visit the manufacturer's website. You can also download the User Manual (PDF) [here](#).

© 2025 Ingenuity. All rights reserved.

Related Documents - 11624

	<p>Ingenuity InLighten Soothing Swing - Van Elephant User Manual</p> <p>User manual for the Ingenuity InLighten Soothing Swing in the Van Elephant design. Provides instructions on assembly, use, safety warnings, and care.</p>
---	---

<div><p>SimpleComfort Compact Soothing Swing™ - Everston™</p><p>Swing - Model 11149 - MEES</p><p>ingenuitybaby.com</p></div>	<p>Ingenuity SimpleComfort Compact Soothing Swing - Everston User Manual</p> <p>User manual and instructions for the Ingenuity SimpleComfort Compact Soothing Swing - Everston model (11149-MEES). Includes safety warnings, assembly, battery information, care, and usage details for this baby swing by Ingenuity (Kids2).</p>
<div><p>SimpleComfort™ Compact Soothing Swing - Chambray</p><p>Swing - Model 11149 - MEES</p><p>ingenuitybaby.com</p></div>	<p>Ingenuity SimpleComfort Compact Soothing Swing - Chambray User Manual</p> <p>This manual provides instructions for the Ingenuity SimpleComfort Compact Soothing Swing in Chambray. It includes safety warnings, assembly instructions, care and cleaning guidelines, and usage information for the swing's features.</p>
<div><p>SimpleComfort™ Compact Soothing Swing - Parker™</p><p>Swing - Model 11149 - MEES</p><p>ingenuitybaby.com</p></div>	<p>Ingenuity SimpleComfort Compact Soothing Swing - Parker User Manual</p> <p>This user manual provides instructions for the Ingenuity SimpleComfort Compact Soothing Swing - Parker. It includes safety warnings, assembly instructions, care and cleaning guidelines, and information on the swing's features.</p>
<div><p>SimpleComfort Compact Soothing Swing & Rocker™ - Raylan™</p><p>Swing - Model 11149 - MEES</p><p>ingenuitybaby.com</p></div>	<p>Ingenuity SimpleComfort Compact Soothing Swing & Rocker - Raylan User Manual</p> <p>This user manual provides essential safety information, assembly instructions, battery guidelines, and care tips for the Ingenuity SimpleComfort Compact Soothing Swing & Rocker™ in the Raylan™ design.</p>

ingenuity



InLighten™ Soothing Swing - Kitt™

Swing - Montessori - Black/White

ingenuitybaby.com

11/20/2018

[Ingenuity InLighten Soothing Swing - Kitt™ User Manual and Safety Guide](#)

This comprehensive user manual provides detailed instructions for assembling, using, and caring for the Ingenuity InLighten Soothing Swing - Kitt™. It includes essential safety warnings, operational guidance for the control module, and maintenance tips, presented in English, Spanish, and French.