

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Costzon](#) /
- › [Costzon Ride on Excavator \(Model 609M\) Instruction Manual](#)

Costzon 609M

Costzon Ride on Excavator (Model 609M) Instruction Manual

Brand: Costzon | Model: 609M

1. INTRODUCTION

Thank you for choosing the Costzon Ride on Excavator. This versatile 3-in-1 construction vehicle toy is designed to provide an engaging play experience for children aged 36 months to 3 years. It functions as a ride-on excavator, a push car, and a sliding car, promoting motor skills and balance. The toy features an adjustable bucket, realistic sound effects, and convenient under-seat storage.

This manual provides essential information for the safe assembly, operation, and maintenance of your new ride-on toy. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Costzon Ride on Excavator showcasing its 3-in-1 versatile design as a scooter, digger, and with under-seat storage.

2. SAFETY INFORMATION

WARNING: To prevent serious injury:

- Adult assembly required.
- Adult supervision is required at all times.
- Recommended for children aged 36 months to 3 years.
- Maximum weight capacity: 55 lbs (25 kg).
- Do not use near stairs, swimming pools, steep inclines, or public roads.
- Ensure the child wears appropriate safety gear, such as the included helmet, during play.
- Inspect the toy regularly for loose parts or damage. Discontinue use if any damage is found.
- This toy is not a battery-powered ride-on car; it is manually operated.

3. PARTS LIST

Please ensure all parts are present before beginning assembly. If any parts are missing or damaged, contact Costzon customer service.

- Bulldozer Body (Main Vehicle)
- Bucket
- Bucket Fixture (x2)
- Front Fixed Handle
- Rear Fixed Handle
- Control Handle
- Helmet
- Toy Stones (x3)
- Screws: 5.5*11*3mm (x1), 4.5*9*3mm (x4)



Image: Thumbnail for the Kids Ride on Excavator Assembly Video, showing all included parts.

4. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Costzon Ride on Excavator. A screwdriver is required (not included).

Step 1: Assemble the Helmet

1. Take the helmet and the white plastic inner frame.
2. Insert the tabs of the inner frame into the corresponding slots inside the helmet.
3. Ensure all tabs are securely fastened to create a comfortable fit.




Image: Step-by-step visual guide for assembling the safety helmet.

Step 2: Install Batteries for Sound Effects

1. Lift the seat of the bulldozer body to reveal the battery compartment.
2. Open the battery compartment cover.
3. Insert 3 x AA batteries (not included) according to the polarity indicators.
4. Close the battery compartment cover and secure the seat.



Hidden Battery Box
 3 x AA Batteries Are Required
 But Not Included



Horn
Sound



Engine
Sound



Dump
Truck Sound



Volume
Increment



Volume
Decrement

Image: Close-up of the hidden battery box under the seat, showing where to insert 3 AA batteries for sound functions.

Step 3: Attach the Bucket

1. Align the bucket with the front arm of the bulldozer body.
2. Secure the bucket to the arm using the two bucket fixtures and 4.5*9*3mm screws (x4). Ensure a tight fit.



Image: Visual steps for attaching the front bucket to the main vehicle body.

Step 4: Install Handles

1. Attach the Front Fixed Handle and Rear Fixed Handle to the top of the excavator arm. Secure them with the appropriate screws (4.5*9*3mm x2).
2. Insert the Control Handle into the designated slot on the side of the excavator arm. Secure it with the 5.5*11*3mm screw (x1).




Image: Instructions for attaching the fixed and control handles to the excavator arm.

Assembly Video

Video: Official assembly guide for the Costzon Ride on Excavator. This video demonstrates the complete assembly process from unboxing to final setup.

5. OPERATING INSTRUCTIONS

Riding the Excavator

- To move the excavator, the child sits on the seat and uses their feet to push the toy forward or backward.
- The steering wheel allows for directional control.

Operating the Adjustable Bucket

- Use the red Control Handle on the side of the excavator arm to raise and lower the bucket.
- The bucket's angle can also be adjusted to scoop up or dump materials like the included toy stones, sand, or dirt.

Easy to Operate

Manual operation ensures unlimited fun



Flexible Control Levers



Adjustable Bucket



Image: A child demonstrating the use of the adjustable bucket with the control levers.

Sound Effects

- Press the buttons on the dashboard to activate various realistic sound effects, including horn, engine, and dump truck sounds.
- Volume can be adjusted using the dedicated volume increment and decrement buttons.



Image: The dashboard with buttons for various sound effects and volume control.

Under-Seat Storage

- Lift the seat to access the storage compartment, perfect for holding small toys, snacks, or the included toy stones.

Product Overview Video

Video: A brief overview of the Costzon Ride on Excavator, highlighting its features and play scenarios.

6. MAINTENANCE

- **Cleaning:** Wipe the toy with a damp cloth and mild soap. Do not use abrasive cleaners.
- **Storage:** Store the toy in a cool, dry place away from direct sunlight when not in use.
- **Battery Replacement:** Replace AA batteries when sound effects become faint or stop working.
- **Inspection:** Periodically check all screws and connections to ensure they are secure.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from buttons	Batteries are dead or incorrectly installed.	Replace with new AA batteries, ensuring correct polarity.
Bucket not moving smoothly	Debris in the mechanism or loose connections.	Check for obstructions and ensure handles/fixtures are securely attached.
Difficulty moving the toy	Uneven surface or excessive weight.	Use on flat, smooth surfaces. Ensure weight does not exceed 55 lbs.

8. SPECIFICATIONS

Feature	Detail
Model Number	609M
Product Dimensions	33.5 x 12.5 x 17.5 inches (L x W x H)
Item Weight	7 pounds
Recommended Age	36 months - 3 years
Weight Capacity	55 lbs (25 kg)
Batteries Required	3 x AA batteries (not included)
Material	High-quality plastic (PP, HDPE)
Certifications	ASTM, CPSIA

Product Dimension



1 Safety Helmet



3 Toy Stones



Recommended
Ages: 3+ Years Old



Weight Capacity:
55 lbs



Image: Visual representation of product dimensions, recommended age, weight capacity, and included accessories (helmet, toy stones).

9. WARRANTY AND SUPPORT

For any questions, concerns, or to report missing/damaged parts, please contact Costzon customer service. Refer to your purchase documentation for specific warranty details.

You can visit the official Costzon store for more information and support:

[Visit the Costzon Store on Amazon](#)



© 2026 Costzon. All rights reserved.