

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Ariete](#) /
- › [Ariete Vintage Electric Kettle 2868/03 User Manual](#)

Ariete 2868/03

Ariete Vintage Electric Kettle

MODEL: 2868/03

Introduction

This manual provides essential instructions for the safe and efficient use of your Ariete Vintage Electric Kettle, model 2868/03. Please read all instructions carefully before first use and retain this manual for future reference.

The Ariete Vintage Electric Kettle is designed for heating water quickly and safely. Its features include a 1-liter capacity, 360-degree cordless base, and an automatic shut-off function.



Image: Front view of the Ariete Vintage Electric Kettle in beige, showcasing its design and spout.

Important Safety Instructions

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions.
2. Do not touch hot surfaces. Use handles or knobs.
3. To protect against fire, electric shock, and injury to persons, do not immerse cord, plugs, or the appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Contact the manufacturer for examination, repair, or adjustment.

7. The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter, or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
12. Do not use appliance for other than intended use.
13. Scalding may occur if the lid is removed during the heating cycle.
14. Ensure the lid is securely closed before operating.

Product Overview

Familiarize yourself with the components of your Ariete Vintage Electric Kettle:

- **Kettle Body:** The main container for water.
- **Lid:** Covers the opening of the kettle.
- **Handle:** For safe pouring and carrying. Features a soft-touch finish.
- **Spout:** For pouring water.
- **On/Off Switch:** Located near the base of the handle.
- **Power Base:** The cordless 360-degree base that supplies power to the kettle.



Image: Detailed front view of the kettle, highlighting the handle, spout, and power switch.

Setup

1. **Unpacking:** Carefully remove the kettle and all accessories from the packaging. Retain packaging for future storage or transport.
2. **First Use Cleaning:** Before first use, fill the kettle with clean water to the maximum level. Boil the

water, then discard it. Repeat this process two to three times to remove any manufacturing residues.

3. **Placement:** Place the power base on a stable, flat, heat-resistant surface, away from the edge of the counter. Ensure the power cord is not dangling or in contact with hot surfaces.

Operating Instructions

1. **Fill the Kettle:** Remove the kettle from its power base. Open the lid and fill the kettle with the desired amount of water. Do not fill below the minimum mark or above the maximum mark (1 liter). Ensure the lid is securely closed after filling.
2. **Place on Power Base:** Place the kettle firmly onto its 360-degree cordless power base.
3. **Connect to Power:** Plug the power cord into a suitable wall outlet.
4. **Switch On:** Press the On/Off switch located at the base of the handle downwards. The indicator light will illuminate, signifying that the kettle is heating.
5. **Automatic Shut-off:** The kettle will automatically switch off once the water has boiled. The indicator light will turn off.
6. **Pouring:** Carefully lift the kettle from the base and pour the hot water. Exercise caution as the kettle body and steam can be hot.
7. **Re-boiling:** If you need to re-boil water, wait a few moments for the internal thermostat to reset before pressing the On/Off switch again.

MOD. 2869

BOUILLOIRE VINTAGE 1,7L

THÉ, TISANES ET INFUSIONS POUR VOS MOMENTS DE DÉTENTE



EAU CHAUDE
DANS QUELQUES
INSTANTS



SOCLE
SANS FIL



CAPACITÉ
1,7L



Image: The Ariete Vintage Electric Kettle positioned on a kitchen counter, ready for use with tea cups in the background.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your kettle.

- Cleaning the Exterior:** Unplug the kettle and allow it to cool completely. Wipe the exterior with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the finish. Never immerse the kettle body or power base in water.
- Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. This can affect performance and taste.
 - Fill the kettle with a mixture of one part white vinegar and two parts water.
 - Bring the mixture to a boil and then let it stand for at least 30 minutes, or longer for heavy scale.
 - Discard the mixture and rinse the kettle thoroughly with fresh water several times.
 - Alternatively, use a commercial descaling solution designed for kettles, following the product's instructions.
- Storage:** When not in use, ensure the kettle is clean and dry. Store it in a cool, dry place. The power cord can be wrapped around the base for tidy storage.

Troubleshooting

Problem	Possible Cause	Solution
Kettle does not heat.	Not plugged in; kettle not properly seated on base; power switch not engaged; no power at outlet.	Check power connection; ensure kettle is correctly placed on base; press power switch; check household circuit breaker.
Kettle switches off before boiling.	Limescale buildup; insufficient water.	Descal the kettle; ensure water level is above the minimum mark.
Water tastes metallic or unusual.	New kettle residue; limescale buildup.	Perform first-use cleaning again; descale the kettle.
Steam escaping from lid.	Lid not properly closed.	Ensure the lid is securely closed before boiling.

Specifications

Feature	Detail
Brand	Ariete
Model Number	2868CR
Capacity	1 Litre
Power / Wattage	1630W

Feature	Detail
Voltage	220 Volts
Material	Metal
Product Dimensions	20 x 21 x 15.5 cm
Item Weight	800 g
Special Features	Cordless, Auto Shut-off, Soft Touch Finishing



Image: The Ariete Vintage Electric Kettle with its key dimensions (height, width, depth) indicated.

Warranty and Support

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. Specific warranty terms may vary by region and retailer.

For technical assistance or inquiries, please contact Ariete customer service through their official website or the contact details provided in your product packaging.

© Ariete. All rights reserved.