

[Manuals.plus](#) /

> [GameSir](#) /

> GameSir VX Aimswitch Keyboard and Mouse Adapter User Manual

## GameSir VX1

# GameSir VX Aimswitch User Manual

Model: VX1 | Brand: GameSir

## INTRODUCTION

The GameSir VX Aimswitch is a versatile keyboard and mouse adapter designed to bring PC-like gaming precision to your console experience. It is compatible with mainstream console platforms including Xbox One, PS4, PS3, and Nintendo Switch, offering stable and instant wireless connection. This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your device to ensure optimal performance.

## SETUP GUIDE

### Package Contents

- GameSir VX Aimswitch Keypad
- GameSir GM190 Gaming Mouse
- Agility X 2.4GHz Wireless Dongle
- USB Cable



The GameSir VX Aimswitch package includes the one-handed mechanical keypad, a wired gaming mouse, and a 2.4GHz wireless dongle for seamless connectivity.

## Connecting to Consoles

The GameSir VX Aimswitch is compatible with Xbox One, PS4, PS3, and Nintendo Switch. Follow these steps for initial setup:

1. Ensure your console's original controller is powered on.
2. Turn on the GameSir VX Aimswitch keypad using the power switch.
3. Plug the GameSir GM190 gaming mouse into the USB port on the GameSir VX Aimswitch keypad.
4. Insert the Agility X 2.4GHz wireless dongle into an available USB port on your console. The LED indicator light on the keypad and dongle should turn solid green, indicating a stable connection.
5. Turn off your console's original controller.
6. Connect your console's original controller to the GameSir VX Aimswitch keypad using a USB cable.
7. On the keypad, press the 'Esc' key to finalize the connection.

Your browser does not support the video tag.

This video demonstrates the step-by-step process of connecting the GameSir VX Aimswitch to a PlayStation 4 console, including powering on the keypad, connecting the mouse, inserting the wireless dongle, and linking the original controller.



**すべてのゲーム機に対応**

XBOX	PS3	PS4	SWITCH	PC
Xbox One Xbox One S Xbox One X	PS3 PS3 (Slim)	PS4 PS4 (Pro) PS4 (Slim)		Windows 7 Windows 8 Windows 10

The GameSir VX Aimswitch is compatible with a wide range of gaming consoles, including Xbox One, PS3, PS4, Nintendo Switch, and PC (Windows 7, 8, 10).



Agility X™テクノロジー搭載、1msの超低遅延で即時ワイヤレス接続が可能

The Agility X 2.4GHz wireless dongle provides a stable and instant wireless connection with a maximum control range of 32.8 feet, requiring no additional drivers.



QRコードをスキャンしてG-Crux APPをダウンロードしてください

Scan the QR code or visit [gamesir.hk/pages/g-crux](https://gamesir.hk/pages/g-crux) to download the G-Crux mobile app for advanced configuration and customization.

## OPERATING INSTRUCTIONS

### Keypad Features

The GameSir VX Aimswitch keypad features authentic Blue mechanical switches, providing tactile feedback and a satisfying click for each keypress. Each key is configurable via the GameSir G-Crux mobile app when the keypad is connected to a mobile device.



**TTC社製メカニカル青軸採用**  
独特のクリックと指先のタクトイル感がほしいゲーマー向け

The keypad utilizes TTC mechanical blue switches, known for their distinct click and tactile feel, preferred by many gamers.

## Mouse Features

The included gaming mouse is designed for precision and comfort. It features adjustable DPI settings and configurable side buttons, pre-tuned for optimal compatibility with consoles. The mouse is lightweight and designed for extended gaming sessions.

PMW3360 GAMEING-GRADE  
光学式センサー搭載

16000 DPI    400 IPS    50 ACC    1000 REFRESH RATE



The gaming mouse features a PMW3360 gaming-grade optical sensor, offering up to 16000 DPI, 400 IPS, 50 ACC, and a 1000Hz refresh rate for precise tracking.

### Customization with G-Crux App

The GameSir G-Crux mobile app allows for extensive customization of your VX Aimsitch. You can configure individual keys on the keypad, adjust mouse sensitivity (DPI), and fine-tune various settings to suit your gaming style. It is recommended to update the firmware to the latest version via the app for the best experience.



The G-Crux app provides a user-friendly interface for customizing key bindings, mouse settings, and other parameters for an optimized gaming experience.

## CARE AND MAINTENANCE

- Keep the device clean by wiping it with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Do not expose the device to extreme temperatures, humidity, or direct sunlight.
- Store the device in a cool, dry place when not in use.
- Avoid dropping or subjecting the device to strong impacts.
- Ensure cables are not bent or kinked excessively to prevent damage.

## TROUBLESHOOTING

- **Mouse Delay in Game:** Try adjusting the dead zone value via the G-CRUX app.
- **Button Customization:** While the device can be used out of the box, it is highly recommended to apply the recommended configuration via the G-CRUX app for optimal performance.
- **Headset Support:** The GameSir VX Aimswitch does not support headset or voice chat functions directly. It is recommended to connect your headset directly to your console (PS3, PS4, Xbox One, Switch).
- **Keypad Used Separately:** The GameSir VX keypad cannot be used separately from the mouse and dongle. Replacing it with another brand's keyboard is not recommended.
- **Game Compatibility:** The GameSir VX supports popular FPS games on consoles. If a specific game configuration is not found on G-CRUX, you can customize it yourself or contact GameSir support for assistance.
- **Nintendo Switch Connection Issues:**

- a. Ensure "Pro Controller Wired Communication" is enabled on your Switch.
- b. Enter the "Change Grip/Order" interface and remain there.
- c. Power on the GameSir VX gaming keypad. The LED indicator light should flash green.
- d. Plug the GameSir GM190 gaming mouse into the USB port of the keypad.
- e. Plug the Agility X 2.4GHz wireless dongle into the USB port of the Nintendo Switch. The indicator lights on the keypad and dongle should turn solid green.
- f. Simultaneously press 'FN' and '5' button on the GameSir VX gaming keypad to connect to Nintendo Switch. The indicator light should turn solid red.
- g. In the "Change Grip/Order" interface, press 'Q' + 'E' on the keypad and wait for the connection.
- h. Ensure you have pressed 'Fn+5', not 'Fn+F5'.

## TECHNICAL SPECIFICATIONS

Feature	Detail
Brand	GameSir
Item Model Number	VX1
Hardware Platform	PlayStation 4, Xbox, Nintendo Switch, PS3
Item Weight	1.89 pounds
Product Dimensions	14.17 x 7.87 x 2.95 inches
Color	VX AimSwitch
Power Source	Battery Powered
Batteries	2 A batteries required (included)
Connectivity Technology	Wireless (2.4G), Wired
Special Features	Console Compatibility, Wireless Connectivity, Configurable Keys, Mechanical Switches, Adjustable DPI, Ergonomic Design

## WARRANTY AND SUPPORT

GameSir products typically come with a limited warranty covering manufacturing defects. For specific warranty details, please refer to the official GameSir website or the documentation included with your purchase. For further assistance, technical support, or to download the full user manual in PDF format, please visit the official GameSir support page or refer to the links below:

- [Download User Manual \(PDF\)](#)

- [Visit the GameSir Store on Amazon](#)