

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Joby](#) /
- › [Joby TelePod Pro Kit Instruction Manual](#)

Joby JB01548-BWW

Joby TelePod Pro Kit Instruction Manual

Model: JB01548-BWW

1. INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Joby TelePod Pro Kit. Please read this manual thoroughly before operating the product and retain it for future reference.

2. PRODUCT OVERVIEW

The Joby TelePod Pro Kit is a versatile camera support system designed for various content creation needs. It functions as a grip, monopod, elevated stand, and stable tripod. Key components include a removable BallHead 1K, a 1/4"-20 attachment point, and adjustable legs.



Image 1: The Joby TelePod Pro Kit demonstrating its multi-functional capabilities as a tripod, monopod, and grip, with different camera types attached.

2.1. Components

- **TelePod Pro Base:** The main body with integrated legs and extension pole.
- **Removable BallHead 1K:** Provides flexible camera positioning.
- **1/4"-20 Attachment:** Standard screw for mounting cameras and accessories.
- **Adjustable Legs:** Three-position click-set legs for stability.
- **Wrist Strap:** For secure handling.

3. SETUP

3.1. Attaching the BallHead 1K

1. Unscrew the top cap from the TelePod Pro base if present.
2. Align the BallHead 1K with the 1/4"-20 screw on the top of the extension pole.
3. Rotate the BallHead 1K clockwise until it is securely tightened. Ensure it is firm but do not overtighten.

3.2. Mounting Your Camera

1. Ensure the BallHead 1K is securely attached to the TelePod Pro base.
2. Locate the 1/4"-20 screw on the BallHead 1K.
3. Align your camera's tripod mount with the screw.
4. Rotate the camera clockwise until it is firmly attached to the BallHead 1K.
5. Adjust the angle of your camera using the BallHead 1K's locking knob. Tighten the knob to secure the desired position.



Image 2: A GoPro camera mounted on the BallHead 1K of the Joby TelePod Pro Kit, ready for use.

4. OPERATING MODES

The Joby TelePod Pro Kit offers three primary operating modes:

4.1. Grip / Monopod Mode

In this mode, the legs are closed, and the extension pole is extended to function as a handheld grip or a monopod for overhead shots.

1. Ensure the legs are fully closed and secured.
2. Twist the extension pole collar counter-clockwise to unlock.
3. Extend the pole to the desired length.
4. Twist the extension pole collar clockwise to lock the pole in place.
5. Use the wrist strap for added security during handheld operation.



Image 3: A hand holding the Joby TelePod Pro Kit in grip mode, with a GoPro camera attached, demonstrating its use as a handheld support.

4.2. Elevated Stand Mode

For elevated camera or 360-degree camera setups, extend the mount and deploy the legs.

1. Twist the extension pole collar counter-clockwise to unlock.
2. Extend the pole to the desired height.
3. Twist the extension pole collar clockwise to lock the pole in place.
4. Open the legs to one of the three click-set positions for stability. Ensure all three legs are evenly spread.



Image 4: The Joby TelePod Pro Kit configured as an elevated stand, supporting a 360-degree camera for a wider field of view.

4.3. Stable Tripod Mode

With legs folded out and the extension lowered, the TelePod Pro Kit provides a stable base for your camera.

1. Ensure the extension pole is fully retracted and locked.
2. Open the legs to the widest click-set position for maximum stability. This is especially recommended for heavier cameras or uneven surfaces.



Image 5: The Joby TelePod Pro Kit in its stable tripod configuration, supporting a camera at a low height.

5. MAINTENANCE

- **Cleaning:** Wipe the product with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the TelePod Pro Kit in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspection:** Periodically check all screws and joints for tightness. Re-tighten if necessary, but do not overtighten.
- **Lubrication:** Do not apply lubricants to the extension pole or leg mechanisms, as this can attract dirt and impair function.

6. TROUBLESHOOTING

Issue: BallHead 1K or camera wobbles/spins.

Solution: Ensure the BallHead 1K is securely tightened to the TelePod Pro base and the camera is firmly attached to the BallHead 1K. The BallHead 1K's locking knob must be fully tightened to secure the camera angle.

Issue: Extension pole does not stay at desired length or wobbles.

Solution: Ensure the extension pole collar is twisted clockwise until fully locked. If the issue persists, check for any debris obstructing the locking mechanism.

Issue: Tripod feels unstable.

Solution: Ensure the legs are fully splayed out to their widest click-set position, especially when supporting heavier cameras or on uneven surfaces. Verify that the extension pole is fully retracted and locked when using as a stable tripod.

7. SPECIFICATIONS

Feature	Detail
Model Number	JB01548-BWW
Product Dimensions	2.17 x 2.17 x 10.35 inches
Item Weight	12.3 ounces (0.35 Kilograms)
Weight Limit	6.6 Pounds (3 kg)
Maximum Height	70 Centimeters
Minimum Height	262.9 Millimeters
Material	Aluminum, ABS Plastic, Glass-Filled Nylon Plastic, TPE
Tripod Head Type	Ball Heads
Compatible Devices	Camera

8. WHAT'S IN THE BOX

- TelePod™ Pro Kit (includes integrated extension pole and legs)
- Removable BallHead 1K

9. WARRANTY INFORMATION







The Joby TelePod Pro Kit comes with a **JOBY 1 Year Warranty**. For detailed warranty terms and conditions, please refer to the official Joby website or contact customer support.

10. SUPPORT

For further assistance, product registration, or to view additional resources, please visit the official Joby website:

www.joby.com

Related Documents - JB01548-BWW

 <p>SeaPal Waterproof Case Instruction manual</p>	<p>JOBY SeaPal Waterproof Case Instruction Manual</p> <p>Comprehensive instruction manual for the JOBY SeaPal Waterproof Case, detailing setup, usage, maintenance, and safety information for protecting smartphones in aquatic environments.</p>
 <p>Impulse Bluetooth Remote User Manual and Safety Information</p>	<p>JOBY Impulse Bluetooth Remote User Manual and Safety Information</p> <p>This document provides instructions and safety warnings for the JOBY Impulse Bluetooth Remote, including details on battery safety and regulatory compliance.</p>
 <p>Impulse Bluetooth Remote User Manual</p>	<p>JOBY Impulse Bluetooth Remote User Manual</p> <p>User manual for the JOBY Impulse Bluetooth remote, detailing setup, connection, battery replacement, safety warnings, and compliance information.</p>
 <p>SeaPal 6\" Dome Instruction manual</p>	<p>JOBY SeaPal 6\" Dome Instruction Manual for Underwater Smartphone Photography</p> <p>Official instruction manual for the JOBY SeaPal 6\" Dome, detailing setup, usage, safety, maintenance, and warranty for underwater and over/under smartphone photography with JOBY SeaPal Waterproof Cases.</p>
 <p>Wavo POD USB Microphone</p>	<p>JOBY Wavo POD USB Microphone: Setup, Features, and Specifications</p> <p>Comprehensive guide to the JOBY Wavo POD USB microphone, covering unboxing, product features, setup instructions, LED indicator meanings, and compatibility information for content creators.</p>
 <p>Universal clamp with integrated cold shoe mount and two 1/4\"-20 standard mounts, allowing it to be used vertically or horizontally. Mount your phone to a camera or other accessories with the included double lock USB plug. Mount your phone to an existing phone mount or other accessories using the included double lock USB plug. Fits phones from 2.36\" to 4.09\". Patent pending. © 2015 Joby Inc. All rights reserved.</p>	<p>JOBY GripTight Smart Clamp: Universal Phone Mount for Cameras</p> <p>Detailed information on the JOBY GripTight Smart clamp, a versatile accessory for mounting smartphones to cameras and other equipment. Features include a 1/4\"-20 mount, cold shoe adapter, and adjustable grip for phones from 2.36\" to 4.09\".</p>