

[manuals.plus](#) /› [Artemide](#) /› [Artemide Tolomeo Mini 100W E26 Table Lamp User Manual](#)**Artemide TOL0045**

# Artemide Tolomeo Mini 100W E26 Table Lamp User Manual

Model: TOL0045

## 1. INTRODUCTION

This manual provides comprehensive instructions for the safe and efficient use of your Artemide Tolomeo Mini 100W E26 Table Lamp. Please read this manual thoroughly before installation and operation, and retain it for future reference. The Artemide Tolomeo Mini is designed for indoor use, offering adjustable illumination with its articulated aluminum arm and shade.

## 2. SAFETY INFORMATION

- Ensure the lamp is connected to a power source within the specified voltage range (120V).
- Do not exceed the maximum bulb wattage of 100W. Use an E26 (medium base) A19 compatible incandescent, compact fluorescent, or LED lamp.
- Always disconnect the power before cleaning, performing maintenance, or replacing the bulb.
- Avoid placing the lamp in areas with excessive moisture or extreme temperatures.
- Do not attempt to modify the lamp's electrical components. Refer servicing to qualified personnel.
- Keep the lamp away from flammable materials.

## 3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Artemide Tolomeo Mini Lamp Arm and Head Assembly
- Aluminum Base
- Shade
- Power Cord



Image 3.1: All components of the Artemide Tolomeo Mini Table Lamp, including the articulated arm, lamp head, base, and power cord.

## 4. SETUP INSTRUCTIONS

---

- 1. Unpack Components:** Carefully remove all parts from the packaging and place them on a clean, flat surface.
- 2. Attach the Base:** Securely attach the lamp's articulated arm assembly to the aluminum base. Ensure the connection is firm and stable.
- 3. Install the Bulb:** Insert an E26 (medium base) A19 compatible bulb (not included) into the lamp head socket. Do not exceed 100W.
- 4. Position the Lamp:** Place the lamp on a stable, flat surface.
- 5. Connect Power:** Plug the power cord into a standard 120V electrical outlet.



Image 4.1: The Artemide Tolomeo Mini Table Lamp fully assembled and ready for use.

## 5. OPERATING INSTRUCTIONS

---

- **Turning On/Off:** The lamp features an On/Off switch located on the lamp head. Press or touch the switch to turn the light on or off.
- **Adjusting Position:** The lamp's arm structure, made of extruded aluminum, and joints with tension control knobs allow for full adjustability. Gently manipulate the arm and head to direct light as desired. The shade offers 360-degree rotation.

## 6. MAINTENANCE

---

- **Cleaning:** Disconnect the lamp from power. Use a soft, dry cloth to wipe down the aluminum surfaces and shade. Avoid abrasive cleaners or solvents.
- **Bulb Replacement:** Ensure the lamp is unplugged and the bulb has cooled completely. Unscrew the old bulb and screw in a new E26 (medium base) A19 compatible bulb, not exceeding 100W.
- **Joint Tension:** The tension control knobs on the joints can be adjusted if the arm becomes too loose or too stiff. Turn clockwise to tighten, counter-clockwise to loosen.

## 7. TROUBLESHOOTING

---

### **Lamp does not turn on:**

Check if the power cord is securely plugged into the outlet and the lamp. Verify that the bulb is correctly installed and not burnt out. Test the outlet with another device.

### **Light flickers:**

Ensure the bulb is screwed in tightly. If using an LED bulb, confirm it is dimmable if connected to a dimmer switch (though this lamp has an On/Off switch on the head). Try a different bulb.

### **Arm does not hold position:**

Adjust the tension control knobs on the joints. Tighten them slightly until the arm holds its desired position.

## 8. SPECIFICATIONS



---

<b>Brand</b>	Artemide
<b>Model Number</b>	TOL0045
<b>Dimensions (D x W x H)</b>	8" x 26.75" x 21.25"
<b>Item Weight</b>	6 Pounds
<b>Material</b>	Aluminum (extruded arm, die-cast joints, base, shade)
<b>Finish Type</b>	Polished
<b>Bulb Base</b>	E26 (Medium Base)
<b>Max Wattage</b>	100W
<b>Compatible Bulb Type</b>	A19 Incandescent, CFL, or LED
<b>Voltage</b>	120V
<b>Control Method</b>	On/Off (on head)
<b>Indoor/Outdoor Usage</b>	Indoor

## 9. WARRANTY AND SUPPORT

---

For warranty information, product support, or to inquire about replacement parts, please contact Artemide directly through their official website or customer service channels. Specific warranty terms and conditions may vary and are provided by the manufacturer.

	<p><a href="#">Artemide Tolomeo Lighting Fixtures: Installation and Safety Guide</a></p> <p>Comprehensive guide for installing and safely using Artemide Tolomeo Pinza, Faretto, Clamp, Vive, and Wall lighting fixtures. Includes general warnings, compliance information, and detailed assembly/mounting instructions for each model.</p>
	<p><a href="#">Artemide Tolomeo Micro LED Lamp - Installation and Operation Guide</a></p> <p>Comprehensive guide for the Artemide Tolomeo Micro LED lamp, covering assembly for table, wall, clamp, and floor mounting, operation, dimming, LED replacement, and safety compliance.</p>
	<p><a href="#">Artemide Tolomeo Midi LED: Installation and Operation Guide</a></p> <p>Comprehensive guide for the Artemide Tolomeo Midi LED lamp, covering installation for various mounting types (table, wall, clamp, floor), operation, dimming, and LED replacement. Includes safety warnings and technical specifications.</p>
	<p><a href="#">Artemide Tolomeo LED MWL / Mini LED MWL User Manual and Installation Guide</a></p> <p>Comprehensive guide for the Artemide Tolomeo LED MWL and Mini LED MWL lamps, covering installation, operation, maintenance, and safety information. Features detailed instructions and technical specifications.</p>
	<p><a href="#">Artemide Tolomeo Decentrata Lamp Bending Angles and Adjustments</a></p> <p>Detailed guide illustrating the bending angles and rotational adjustments for the Artemide Tolomeo Decentrata lamp, showcasing its flexibility and range of motion.</p>
	<p><a href="#">Artemide Laguna Lamp: Installation and Usage Guide</a></p> <p>Detailed instructions for the Artemide Laguna lamp, including bulb compatibility (LED only), dimensions, and operation. Features information for models with E26 and E12 bases.</p>