

[Manuals.plus](#) /

› [FoodVille](#) /

› FoodVille MF02 Rechargeable Milk Frother Instruction Manual

FoodVille MF02

FoodVille MF02 Rechargeable Milk Frother Instruction Manual

Model: MF02

Brand: FoodVille

PRODUCT OVERVIEW

The FoodVille MF02 Rechargeable Milk Frother is a versatile handheld device designed for creating perfect milk foam for various beverages and for mixing other ingredients. It features multiple whisking speeds and a durable stainless steel whisk.



Image: The FoodVille MF02 Rechargeable Milk Frother, a sleek black handheld device with a stainless steel whisk, ready for use.

PACKAGE CONTENTS

- FoodVille MF02 Frother Handle
- Milk Frother Whisk (double layer)
- Balloon Whisk (for eggs/protein powder)
- Metal Stand
- USB Charging Cable



Image: All components of the FoodVille MF02 package laid out: the frother handle, two interchangeable whisks (milk frother and balloon whisk), a metal stand, and a USB charging cable.

SETUP

1. **Initial Charge:** Before first use, fully charge the frother using the provided USB cable. The charging port is located at the bottom of the handle. A full charge typically takes approximately 6 hours and can last for up to 60 days with average daily use (5 minutes/day).
2. **Attach Whisk:** Select the desired whisk (milk frother or balloon whisk) and firmly insert it into the motor shaft at the top of the frother handle. Ensure it clicks securely into place.
3. **Placement:** Place the frother in its metal stand when not in use to keep it organized and allow any residual liquid to drip.



Image: Close-up of the FoodVille MF02 frother handle showing the three speed buttons (Low, Mid, High) and the power indicator light.

OPERATING INSTRUCTIONS

- Power On:** Press the power button (top button) once to turn on the frother at the lowest speed.
- Adjust Speed:** Press the middle button to cycle through the three speed settings: Low (19000rpm for silky latte froth), Mid (21000rpm for creamy cappuccino), and High (23000rpm for Dalgona fluff or thicker foam). The indicator lights will show the selected speed.
- Frothing/Mixing:** Submerge the whisk head into the liquid you wish to froth or mix. Move the frother gently up and down or in circular motions until the desired consistency is achieved.
- Power Off:** Press the power button again to turn off the frother.

Your browser does not support the video tag.

Video: A demonstration of the FoodVille MF02 milk frother in action, showing how it quickly creates foam in a cup of milk.

Your browser does not support the video tag.

Video: A user demonstrating the FoodVille MF02 frother mixing protein powder in a shaker bottle, highlighting its effectiveness for smooth

blending.

MAINTENANCE AND CLEANING

- **Whisk Cleaning:** After each use, detach the whisk from the handle. Rinse the whisk under running water immediately. For thorough cleaning, you can activate the frother with the whisk submerged in a glass of soapy water, then rinse.
- **Handle Cleaning:** Wipe the frother handle with a damp cloth. **Do not submerge the handle in water** as this can damage the internal electronics.
- **Storage:** Store the frother and its accessories in the provided metal stand in a dry place.

Dual Heads From Coffee to Cooking



Image: The FoodVille MF02 frother showcasing its two interchangeable whisk heads: one for milk frothing and matcha, and another balloon whisk for egg whites and protein powder.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Frother does not turn on.	Low battery or not charged.	Charge the frother fully using the USB cable.
Whisk is wobbly or detaches easily.	Whisk not properly attached.	Ensure the whisk is firmly inserted into the motor shaft until it clicks.
Weak frothing/mixing power.	Low battery or incorrect speed setting.	Recharge the frother. Select a higher speed setting if needed.
Excessive splashing during operation.	Speed setting too high for liquid volume or container size.	Reduce the speed setting or use a taller container.

SPECIFICATIONS

- **Model Name:** MF02
- **Brand:** FoodVille
- **Material:** Plastic (handle), Stainless Steel (whisk heads)
- **Special Feature:** Adjustable Speed Control (3 speeds: 19000rpm, 21000rpm, 23000rpm)
- **Power Source:** Electric, Rechargeable Battery (1800 mAh)
- **Product Dimensions:** Approximately 3"W x 9"H
- **Item Weight:** 0.5 Pounds (8 ounces)
- **Included Components:** Frother handle, 2 whisks, metal stand, USB charging cable
- **Product Care:** Hand Wash Only (whisks), Wipe Clean (handle)

WARRANTY AND SUPPORT

The FoodVille MF02 Rechargeable Milk Frother comes with a **2-year replacement warranty**. For warranty claims, product support, or any inquiries, please contact FoodVille customer service. You may need your Amazon order number for warranty activation or claims.

For further assistance, please visit the official FoodVille website or contact their support team directly. Keep your purchase receipt or order confirmation as proof of purchase.

SAFETY INFORMATION

- Keep out of reach of children.
- Do not immerse the main frother handle in water.
- Use only the provided USB cable for charging.
- Avoid operating the frother without liquid to prevent damage to the motor.
- Do not use abrasive cleaners or scouring pads on any part of the frother.

VERSATILE USE CASES

Beyond frothing milk for cappuccinos and lattes, the FoodVille MF02 is also ideal for:

- Mixing protein powders and nutritional shakes.
- Blending matcha tea.
- Whisking eggs for omelets or baking.
- Creating bulletproof coffee.
- Preparing salad dressings and sauces.

Barista-Quality Froth in Seconds



Fast
Recharge



Turbo
Power



Long
Lasting



Image: The FoodVille MF02 frother creating rich, barista-quality foam in a glass of coffee, demonstrating its efficiency and power.

BATTERY LIFE AND CHARGING

The built-in 1800 mAh rechargeable battery provides long-lasting performance. With an average daily usage of 5 minutes, a single charge can power the frother for up to 60 days. The frother is charged via a standard USB cable, offering convenient charging from various power sources.

One Charge Lasts 60 Days (5 mins/day)

Days

60

The average daily usage
duration is 5 minutes

mah

1800

Rechargeable battery



Image: The FoodVille MF02 frother connected to a wall adapter via its USB charging cable, illustrating its rechargeable feature and long battery life.

ERGONOMIC DESIGN

The FoodVille MF02 features an ergonomic design for comfortable handling. Its compact size and lightweight construction make it easy to store and use. The included metal stand ensures the frother is always ready and keeps your countertop tidy.



Image: A woman and a child happily using the FoodVille MF02 frother to prepare a drink, demonstrating its user-friendly design.

LONG SHAFT DESIGN

The frother's 4.5-inch long shaft is designed to reach the bottom of most 16 oz tumblers and taller containers, ensuring thorough mixing and frothing without hassle.


4.5" Long Shaft Fits 16 oz Tumblers.



Image: The FoodVille MF02 frother demonstrating its long shaft, easily reaching into a tall 16 oz tumbler for effective mixing.

QUALITY MATERIALS

The frother features 18/8 grade stainless steel whisks, ensuring durability, hygiene, and resistance to corrosion. The robust construction is designed for long-lasting performance.



Pure Sips: 18/8 Grade Stainlesssteel Frother.

Image: The stainless steel whisk of the FoodVille MF02 frother being rinsed under running water, highlighting its easy-to-clean and durable material.

POWERFUL MOTOR

Equipped with a powerful turbo motor, the FoodVille MF02 can create thick, creamy foam in as little as 15 seconds, making it an efficient tool for your kitchen.

Skip the Line & the Bill: 30s to a \$1 Latte.



*Based on 12oz latte: \$0.40 milk + \$0.50 coffee + \$0.10 energy vs \$5 cafe price + \$1 tip.
Save \$1,200/year if you replace 3 cafe drinks weekly!

Image: An internal diagram of the FoodVille MF02 frother's powerful turbo motor, illustrating its robust design for quick frothing.

CUSTOMER SUPPORT

FoodVille is committed to providing excellent customer service. Should you encounter any issues or have questions about your MF02 frother, their support team is available to assist you promptly.



Image: The FoodVille MF02 frother displayed with its black product packaging, emphasizing the brand's presentation and quality.

ADDITIONAL RESOURCES

- [Product Page](#)
- [FoodVille Brand Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question