Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Soundcore AK-A3902021

Soundcore Liberty Air True Wireless Earphones User Manual

Model: AK-A3902021 | Brand: Soundcore

Product Overview

The Soundcore Liberty Air True Wireless Earphones are designed to deliver an incredible sound experience with advanced features for everyday use. These earphones feature Graphene-enhanced drivers for exceptional audio clarity and powerful bass. Dual microphones with cVc 8.0 noise reduction technology ensure crystal-clear calls by effectively highlighting your voice and minimizing background sounds. With integrated touch controls, managing your music and calls is intuitive and convenient. The earphones offer a secure and comfortable fit, making them suitable for various activities.



Image: Soundcore Liberty Air True Wireless Earphones with their charging case.

What's in the Box

Your Soundcore Liberty Air package includes the following items:

- Liberty Air X true wireless earphones
- Charging case
- XS/S/M/L/XL EarTips (multiple sizes for optimal fit)
- 60 cm Micro USB cable
- User manual



Image: A visual representation of the items included in the product packaging.

Setup and Getting Started

Charging Your Earphones

Before first use, fully charge the earphones and the charging case. The earphones provide up to 7 hours of listening on a single charge, extended to a total of 28 hours with the charging case. The charging time for the earphones is approximately 1 hour.

1. Place the earphones into the charging case. Ensure they are properly seated to begin charging.
2. Connect the Micro USB cable to the charging port on the case and to a power source.
3. The LED indicators on the case will show the charging status.



Image: The Soundcore Liberty Air earphones placed inside their charging case, illustrating the charging process.

Pairing with Your Device

The Soundcore Liberty Air earphones utilize Bluetooth 5.0 for a stable and seamless connection. Pairing is designed to be straightforward:

1. Open the charging case. The earphones will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "Soundcore Liberty Air" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear an audio confirmation.



Image: A user holding the Soundcore Liberty Air charging case with an earbud, demonstrating the connection process.

Achieving a Secure Fit

For optimal sound quality and comfort, it's important to choose the correct EarTip size and ensure a secure fit. The earphones come with multiple EarTip sizes (XS/S/M/L/XL) to suit different ear canals.

1. Try different EarTip sizes to find the one that provides the best seal and comfort for your ears.
2. Gently insert the earphone into your ear canal and twist it slightly to secure it in place.
3. A good fit will block out external noise and enhance bass performance.




Image: A graphic illustrating the secure fit of the Soundcore Liberty Air earbud in the ear canal.

Operating Instructions

Touch Controls

The Soundcore Liberty Air earphones feature intuitive touch controls on each earbud for easy management of music and calls.

- **Play/Pause:** Double-tap the right earbud.
- **Next Track:** Press and hold the right earbud.
- **Previous Track:** Press and hold the left earbud.
- **Activate Voice Assistant:** Double-tap the left earbud.



Image: A user interacting with the touch-sensitive surface of the Soundcore Liberty Air earbud to control playback.

Call Management

Manage your calls with ease using the touch controls:

- **Answer/End Call:** Double-tap the right earbud.
- **Reject Call:** Press and hold the right earbud.

The dual microphones with cVc 8.0 noise reduction technology ensure your voice is clear during calls, even in noisy environments.




Image: A woman wearing Soundcore Liberty Air earphones, highlighting the ultra-clear call feature with noise reduction.

Sound Quality

Experience expertly tuned sound with the Soundcore Liberty Air earphones. They feature Graphene drivers that oscillate with extreme precision, delivering audio with pinpoint accuracy and clarity across a wider soundstage. aptX technology ensures

consistently high-quality audio transmission via Bluetooth.



Image: A close-up illustration of the Graphene-enhanced driver technology within the earbud, emphasizing deep bass and exceptional detail.

Care and Maintenance

The Soundcore Liberty Air earphones have an IPX5 rating, providing water and sweat resistance. This makes them suitable for sports and exercise, protecting them from splashes and sweat. To ensure longevity and optimal performance:

- Clean the earphones regularly with a soft, dry cloth.
- Avoid exposing them to extreme temperatures or direct sunlight for prolonged periods.
- Store them in the charging case when not in use to protect them and keep them charged.

Troubleshooting

If you encounter any issues with your Soundcore Liberty Air earphones, try the following common troubleshooting steps:

- **No Sound/Connection Issues:** Ensure both earphones are charged and properly seated in the case. Disconnect and re-pair the earphones with your device.
- **One Earbud Not Working:** Place both earbuds back into the charging case, close the lid, wait a few seconds, and then take them out again to re-establish the connection.
- **Volume Control:** Note that these earphones do not have on-device volume controls. Adjust the volume directly from your connected Bluetooth device.
- **Intermittent Connection:** Ensure your device is within the Bluetooth range (up to 10 meters). Avoid physical obstructions between your device and the earphones.

Specifications

Feature	Detail
Brand	Soundcore
Model Number	AK-A3902021
Connectivity Technology	Bluetooth
Bluetooth Version	5.0
Bluetooth Range	10 Meters
Control Type	Touch Control
Battery Life (Earbuds)	7 Hours (single charge)
Total Playtime (with case)	28 Hours
Charging Time	1 Hour
Water Resistance Level	IPX5 (Water Resistant)
Audio Driver Type	Dynamic Driver (Graphene-Enhanced)
Frequency Range	20Hz-20kHz
Item Weight	1.92 ounces
Product Dimensions	2.36 x 0.98 x 1.77 inches

Warranty and Support

For detailed warranty information and customer support, please refer to the official Soundcore website or the contact information provided in your product packaging. A comprehensive User Manual (PDF) is also available for download via the following link: User Manual (PDF).

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07HSYJWMR

More documents and user manuals: **https://manuals.plus/**