

## Meike MK-XT2G

# Meike MK-XT2G Metal Hand Grip Instruction Manual

For Fujifilm X-T2 Camera

[Overview](#)

[Setup](#)

[Usage](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Support](#)

## 1. PRODUCT OVERVIEW

---

The Meike MK-XT2G is a metal hand grip designed specifically for the Fujifilm X-T2 camera. This accessory enhances the camera's handling and stability, particularly when using heavier lenses, by providing a more secure grip and reducing camera shake. It also serves as a replacement for the Fujifilm MHG-XT2 hand grip.

Constructed from durable metal, the grip offers robust protection for the camera's bottom. Its design allows for convenient access to the battery compartment and SD card slot without needing to remove the grip. Additionally, the integrated Arca-Swiss compatible plate facilitates quick attachment and detachment from compatible tripods.



Figure 1: Meike MK-XT2G hand grip mounted on a Fujifilm X-T2 camera, showing improved ergonomics.

## 2. SETUP AND INSTALLATION

---

Follow these steps to securely attach the Meike MK-XT2G hand grip to your Fujifilm X-T2 camera:

1. **Prepare Your Camera:** Ensure your Fujifilm X-T2 camera is powered off before installation.
2. **Align the Grip:** Position the Meike MK-XT2G hand grip underneath your camera, aligning the mounting screw on the grip with the tripod socket on the camera body.
3. **Secure the Grip:** Use the integrated screw on the grip's base to tighten it firmly to the camera. The grip features a lever/handle for easy tightening without additional tools. Ensure it is snug to prevent any movement.



Figure 2: Underside of the Meike MK-XT2G hand grip, highlighting the camera mounting screw and Arca-Swiss compatible base.

Once installed, the grip should remain securely in place, whether the camera is held upright or flat.

### 3. OPERATING AND FEATURES

---

The Meike MK-XT2G hand grip is designed to enhance your photography experience with several key features:

- **Improved Ergonomics:** The extended grip, featuring an imitation leather design, provides a more comfortable and secure hold on your camera, reducing fatigue during prolonged use.
- **Enhanced Stability:** The solid metal base and extended grip contribute to greater stability, which is particularly beneficial when using large or heavy lenses, helping to minimize camera shake.
- **Battery and SD Card Access:** The design allows full access to the camera's battery compartment and SD card slot without requiring the removal of the hand grip. This ensures uninterrupted shooting.
- **Arca-Swiss Compatibility:** The base of the grip is Arca-Swiss compatible, enabling quick and easy attachment and detachment from tripods and other support systems that use the Arca-Swiss standard.

The grip equipped with a slide rail helps facilitate its detachment from tripod.



Figure 3: The hand grip mounted on a tripod, demonstrating the integrated slide rail for convenient detachment.

## 4. MAINTENANCE

---

To ensure the longevity and optimal performance of your Meike MK-XT2G hand grip, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the grip regularly with a soft, dry cloth to remove dust and fingerprints. For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, store the grip in a clean, dry environment, away from extreme temperatures and humidity.
- **Inspection:** Periodically check the mounting screw for tightness. If the grip feels loose, re-tighten the screw using the integrated lever.

## 5. TROUBLESHOOTING

---

If you encounter any issues with your Meike MK-XT2G hand grip, consider the following common solutions:

- **Grip feels loose on camera:**

- Ensure the mounting screw is fully tightened. Use the integrated lever to secure it firmly.
  - Verify that the grip is correctly aligned with the camera's tripod socket.
- **Difficulty accessing battery/SD card:**
    - Confirm the grip is correctly installed. The design allows for clear access to these compartments. If access is obstructed, the grip might be misaligned or not fully seated.
  - **Grip not fitting tripod:**
    - The grip features an Arca-Swiss compatible plate. Ensure your tripod head or quick-release clamp is also Arca-Swiss compatible.
    - Check for any debris in the tripod clamp or on the grip's base that might prevent a secure fit.

## 6. SPECIFICATIONS

---

Detailed specifications for the Meike MK-XT2G Metal Hand Grip:

<b>Model</b>	MK-XT2G
<b>Compatibility</b>	Fujifilm X-T2 Camera
<b>Material</b>	Metal base, imitation leather grip
<b>Mounting</b>	1/4 inch screw to camera tripod socket
<b>Tripod Compatibility</b>	Arca-Swiss standard
<b>Dimensions (Approximate)</b>	Length: 12.5 cm Large Width: 5.5 cm Mini Width: 3.5 cm Height of Base: 1 cm Height of Grip: 5 cm
<b>Weight (Approximate)</b>	100 g
<b>Manufacturer Model Number</b>	MKFFA-P
<b>ASIN</b>	B07HT49KT4



Figure 4: Various views of the Meike MK-XT2G hand grip, showcasing its design and features.

## 7. WARRANTY AND SUPPORT

---

For warranty information, technical support, or any inquiries regarding your Meike MK-XT2G hand grip, please refer to the official Meike website or contact your retailer. Keep your purchase receipt as proof of purchase for warranty claims.

**Manufacturer:** Meike

**Date First Available:** October 2, 2018

