

BANZAI Pipeline

BANZAI Pipeline Water Park Toy Instruction Manual

Model: Pipeline

1. IMPORTANT SAFETY INFORMATION

Read and understand all instructions before setting up and using the BANZAI Pipeline Water Park Toy. Failure to follow these instructions may result in serious injury or property damage. This product is intended for outdoor domestic use only. Adult supervision is required at all times.

- Always ensure the water park is set up on a level, soft surface, such as grass, free from sharp objects or debris.
- Maintain a safe distance from fences, buildings, trees, and other obstacles.
- Do not use the product in windy conditions.
- Ensure the blower motor is placed on a stable surface and protected from water.
- Securely anchor the water park to the ground using all provided stakes and anchor bags to prevent movement during use.
- Only allow the recommended number of users on the water park at one time. Refer to specifications for user capacity.
- Do not allow users to wear shoes, glasses, or sharp objects while on the water park.
- Keep pets away from the inflatable to prevent damage.
- Empty the water park completely after each use and ensure it is dry before storage to prevent mold and mildew.

2. PACKAGE CONTENTS

Verify that all components listed below are present in your package before beginning assembly.

- 1 Inflatable Water Slide
- 1 Blower Motor
- 1 Water Spraying Hose Assembly
- 3 Blower Ground Stakes
- 8 Water Slide Ground Stakes + 1 Extra
- 1 Carrying Bag
- 4 Repair Patches



1 Inflatable Water Slide




1 Blower Motor



1 Water Spraying Hose Assembly



3 Blower Ground Stakes



8 Water Slide Ground Stakes + 1 Extra



1 Carrying Bag



4 Repair Patches

Figure 2.1: All included components for the BANZAI Pipeline Water Park.


3. SETUP INSTRUCTIONS

Follow these steps to correctly set up your BANZAI Pipeline Water Park. Setup typically takes less than 2 minutes after unrolling.

1. **Unroll the Product:** Lay the inflatable water park flat on a clean, level surface in your desired location. Ensure the air intake tube is accessible and free from obstructions.
2. **Attach Blower Motor:** Connect the air intake tube of the inflatable to the blower motor. Ensure a secure fit.
3. **Inflate:** Plug in the blower motor and turn it on. The water park will begin to inflate.
4. **Secure Air Release Chute:** Locate the short air release chute and tie it shut as indicated in the instructions.
5. **Secure Ground Stakes:** Once the water park is fully inflated, use the provided ground stakes to secure the inflatable to the ground. Place stakes through the designated loops at the base of the water park. Use the blower ground stakes to secure the blower motor.
6. **Attach Sprayer Hose:** Connect the water spraying hose assembly to the designated attachment points on the water park.
7. **Connect to Garden Hose:** Attach the other end of the water spraying hose assembly to a standard garden hose. Turn on the water supply.
8. **Add Water:** Allow water to fill the splash pool area to the recommended level.



CONSTANT AIR INFLATABLES **SET UP STEPS**



Detailed set up instructions included with your constant air inflatable.

Figure 3.1: Visual guide for the setup steps of the inflatable water park.

4. OPERATING INSTRUCTIONS

Once fully set up and filled with water, the BANZAI Pipeline Water Park is ready for use. Ensure continuous adult supervision during operation.

- **Climbing:** Users can climb the inflatable wall to reach the top of the slide.
- **Sliding:** Slide down the cushiony slick slide, which features a water wall for added fun.
- **Splash Landing:** The slide leads into a splash pool area.
- **Water Features:** The integrated water spraying hose assembly provides continuous water flow over the slide and into the splash area.



Figure 4.1: The BANZAI Pipeline Water Park in use, illustrating the slide, climbing wall, and splash pool.

5. MAINTENANCE AND STORAGE

Proper maintenance and storage will extend the life of your BANZAI Pipeline Water Park.

5.1 Cleaning

- After each use, drain all water from the splash pool.
- Clean the entire surface of the inflatable with mild soap and water. Rinse thoroughly.
- Ensure all dirt, leaves, and debris are removed from the water park.

5.2 Drying

- It is crucial to completely dry the water park before deflating and storing it to prevent mold and mildew.
- Leave the blower motor running for several hours after draining the water to allow air to circulate and dry the interior of the inflatable.
- If possible, allow the inflatable to air dry in the sun for an additional period after the blower is turned off.

5.3 Storage

- Once completely dry, turn off the blower motor and allow the water park to deflate.
- Fold or roll the deflated water park neatly.
- Place the folded water park into the provided carrying bag.
- Store the water park in a cool, dry place, away from direct sunlight and extreme temperatures.

5.4 Repairs

- Use the included repair patches for small punctures or tears.
- Clean and dry the damaged area thoroughly before applying a patch.
- For larger damages or if unsure, contact customer support.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Water park does not inflate fully.	Blower not connected properly; air release chute open; power issue; puncture.	Ensure blower is securely attached and powered on. Check if the air release chute is tied shut. Inspect for punctures and use repair patches if necessary.
Water is not spraying or flow is weak.	Hose not connected; water supply off; kink in hose; clogged nozzle.	Verify garden hose is connected and water supply is on. Check for kinks in the hose assembly. Inspect sprayer nozzles for clogs.
Water park deflates slowly during use.	Small air leak; blower motor not strong enough (unlikely with included blower).	This is normal for constant airflow inflatables; a slight air escape is part of the design. For significant leaks, inspect for punctures and use repair patches.
Mold or mildew develops.	Improper drying before storage.	Clean the affected area with a mold-specific cleaner. Ensure thorough drying before future storage.

7. SPECIFICATIONS

Key technical details for the BANZAI Pipeline Water Park Toy.

- **Brand:** BANZAI
- **Model:** Pipeline
- **Dimensions (L x W x H):** 175 inches x 114 inches x 95 inches (14 ft 7 in x 9 ft 6 in x 7 ft 11 in)
- **Item Weight:** 22.54 Kilograms
- **Material Type:** Nylon
- **Recommended Age Range:** 5 to 12 years (Manufacturer Minimum Age: 60 months, Maximum Age: 144 months)
- **Number of Players:** 3-5
- **Color:** Blue, Orange, Yellow, Green



8. WARRANTY AND CUSTOMER SUPPORT

For warranty information, product support, or to purchase replacement parts, please contact BANZAI customer service directly. Refer to the product packaging or the official BANZAI website for the most current contact details.

Online Support: Visit the official BANZAI website for FAQs and support resources.

Contact Manufacturer: For specific inquiries, reach out to Banzai customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question