



[Manuals.plus](#) /

› [Lancaster Gaming Company](#) /

› Lancaster 2 Player Electronic Arcade 3 in 1 Basketball, Football, Baseball Game Instruction Manual

## Lancaster Gaming Company BBG019\_018P

# Lancaster 2 Player Electronic Arcade 3-in-1 Game Instruction Manual

Model: BBG019\_018P

## 1. INTRODUCTION

Thank you for choosing the Lancaster 2 Player Electronic Arcade 3-in-1 Game. This product is designed to provide an engaging multi-sport experience, combining basketball, football, and baseball into a single unit. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new arcade game. Please read it thoroughly before assembly and use, and retain it for future reference.



Figure 1: The Lancaster 2 Player Electronic Arcade 3-in-1 Game in both basketball and football/baseball configurations.

## 2. SAFETY INFORMATION

To ensure safe operation and prevent injury or damage, please adhere to the following guidelines:

- **Adult Assembly Required:** This product contains small parts and requires adult assembly. Keep children away during assembly.
- **Supervision:** Children should be supervised by an adult when using this game.
- **Stable Surface:** Always place the game on a flat, level, and stable surface to prevent tipping.
- **Clearance:** Ensure adequate clear space around the game during use to prevent collisions.
- **Electrical Components:** The electronic scorekeeper contains electrical components. Do not expose it to water or excessive moisture. Use only the specified battery type and ensure correct polarity.
- **Inspection:** Regularly inspect all parts for wear, damage, or loose connections. Do not use the game if any part is damaged.
- **Intended Use:** This product is designed for recreational use only. Do not modify the game or use it for purposes other than its intended design.

## 3. PACKAGE CONTENTS

Verify that all components listed below are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Main Frame Components (metal tubing)
- Backboard with Electronic Scorekeeper
- Basketball Hoops and Nets
- Ball Return Ramp and Netting
- Football/Baseball Target Panel
- Basketballs (quantity: 4)
- Footballs (quantity: 2)
- Baseballs (quantity: 2)
- Air Pump
- Assembly Hardware (screws, bolts, connectors)
- Instruction Manual



Figure 2: Included accessories and general dimensions of the game.

## 4. SETUP AND ASSEMBLY

Assembly typically requires two adults and approximately 60-90 minutes. Follow the step-by-step instructions provided in the separate assembly guide included with your product. The general steps are outlined below:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches.
2. **Assemble Base Frame:** Connect the main metal tubing sections to form the base structure using the provided hardware. Ensure all connections are secure.
3. **Attach Ball Return Ramp:** Secure the fabric ball return ramp to the frame.
4. **Install Backboard and Scorekeeper:** Mount the backboard, which includes the electronic scorekeeper, to the upper frame.
5. **Attach Hoops and Nets:** Secure the basketball hoops and nets to the backboard.
6. **Install Protective Netting:** Attach the side and top protective netting to contain stray balls.
7. **Insert Batteries:** Open the battery compartment on the electronic scorekeeper (usually located on the back) and insert the required batteries (not included), ensuring correct polarity.
8. **Inflate Balls:** Use the provided air pump to inflate the basketballs, footballs, and baseballs to their recommended pressure.



## 5. OPERATING INSTRUCTIONS

The Lancaster 3-in-1 game offers multiple play modes for basketball, football, and baseball.

### 5.1 Electronic Scorekeeper

The integrated LED scorekeeper tracks scores and time. It typically requires 3x AA batteries (not included).



Figure 4: Detail of the electronic scorekeeper.

- **Power On/Off:** Press the power button (usually located near the display) to turn the scorekeeper on or off.
- **Game Mode Selection:** Use the mode button to cycle through available game modes (e.g., Single Player, Two Player, various time limits). Refer to the labels on the backboard for specific mode descriptions.
- **Score Tracking:** Sensors detect successful shots/throws and automatically update the score.
- **Sound Effects:** The scorekeeper includes sound effects for scoring and game events.

## 5.2 Basketball Game

To play basketball, ensure the ball return ramp is in the basketball configuration, directing balls back to the player. The game features two hoops for competitive play.

- Select a basketball game mode on the scorekeeper.
- Players take turns shooting basketballs into the hoops.
- The electronic scorekeeper will automatically track points.




Figure 5: A user engaging with the basketball game mode.

## 5.3 Football and Baseball Game

To switch to football or baseball, the ball return ramp needs to be adjusted, and the target panel for football/baseball should be positioned in front of the hoops. This panel typically attaches to the frame.

- Adjust the game setup to the football/baseball configuration.
- Use the provided footballs or baseballs.
- Players aim to throw the balls through the designated holes on the target panel.
- Scores are typically tracked manually or by specific sensors if available for this mode.



Figure 6: A user playing the football/baseball game mode.

## 6. MAINTENANCE

Regular maintenance will extend the life of your game.

- **Cleaning:** Wipe down metal and plastic surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Netting:** Check the netting for tears or damage. Replace if necessary.
- **Ball Inflation:** Periodically check the inflation of the balls and re-inflate as needed using the provided pump.
- **Battery Replacement:** Replace batteries in the scorekeeper when the display dims or functions improperly. Always use new batteries of the specified type.
- **Storage:** When not in use, store the game in a dry, cool place away from direct sunlight and extreme temperatures. Some models may be foldable for compact storage.

## 7. TROUBLESHOOTING

Refer to the following table for common issues and their solutions.

<b>Problem</b>	<b>Possible Cause</b>	<b>Solution</b>
Scorekeeper not turning on	Dead or incorrectly installed batteries	Replace batteries with new ones, ensuring correct polarity.
Score not registering	Sensor obstruction or malfunction	Check for debris blocking the sensor. Ensure the ball passes directly through the hoop. If issue persists, contact support.
Balls losing air quickly	Under-inflation or small puncture	Re-inflate balls. Inspect for punctures; replace if necessary.
Game feels unstable	Loose connections or uneven surface	Tighten all assembly hardware. Move the game to a flat, level surface.

## 8. SPECIFICATIONS

- **Model:** BBG019\_018P
- **Brand:** Lancaster Gaming Company
- **Material:** Plastic, Metal
- **Age Range:** 12 years and above
- **Sports:** Basketball, Football, Baseball
- **Power Source (Scorekeeper):** Batteries (not included)
- **Approximate Dimensions (L x W x H):** 56 x 30 x 66 inches
- **Item Diameter (Balls):** 3 Inches (for some included balls)

(L X W X H): 56 X 30 X 66 INCHES




Figure 7: Detailed dimensions and included accessories.

## 9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Lancaster Gaming Company customer support directly. If you require assistance with assembly, parts, or troubleshooting beyond what is covered in this manual, please visit the official Lancaster Gaming Company website or contact their customer service department.

**Website:** [www.lancastergaming.com](http://www.lancastergaming.com) (Example link, please verify actual website)