

[Manuals.plus](#) /

› [VIGO](#) /

› VIGO Amada Waterfall Vessel Bathroom Sink Faucet Instruction Manual

VIGO VG03026BN

VIGO Amada Waterfall Vessel Bathroom Sink Faucet Instruction Manual

Model: VG03026BN | Brand: VIGO

INTRODUCTION

This manual provides essential information for the installation, operation, maintenance, and troubleshooting of your VIGO Amada Waterfall Single-Handle Single-Hole Mount Vessel Bathroom Sink Faucet. Designed for modern bathrooms, this faucet features a unique waterfall spout, single-handle control, and a durable brushed nickel finish. Please read these instructions thoroughly before beginning installation or use to ensure proper function and longevity of your product.



Image: The VIGO Amada Waterfall Vessel Faucet in Brushed Nickel, showcasing its sleek design.

SETUP AND INSTALLATION

Proper installation is crucial for the performance of your VIGO Amada faucet. This faucet is designed for single-hole, deck-mount vessel sink installations. For detailed, step-by-step instructions, please refer to the comprehensive installation manual provided with your product (often available as a PDF download from the manufacturer's website).

Key Installation Considerations:

- **Mounting Type:** Deck Mount, suitable for vessel sinks.
- **Hole Requirements:** Requires a standard 1-3/8 inch (35mm) hole opening.
- **Plumbing Connections:** Utilizes standard US 3/8-inch plumbing connections and freeze-resistant metal-braided PEX lines for durability and thermostability.
- **Included Components:** All necessary mounting hardware, handles, and supply lines are included for a complete setup.




Image: Technical diagram showing the front and side dimensions of the VIGO Amada Faucet, including spout height, reach, and mounting hole diameter.

Installation Video Overview:



Video: An official VIGO product video (VG03026 Product Video) demonstrating the features and potentially aspects of installation for the Amada faucet series.

OPERATING INSTRUCTIONS

The VIGO Amada faucet is designed for intuitive and effortless operation.

Water Flow and Temperature Control:

- The faucet features a single lever handle for precise control over both water flow and temperature.
- Lift the handle to increase water flow.
- Move the handle left for hot water and right for cold water.

- The unique waterfall spout delivers a gentle, splash-free stream of water.



Image: The VIGO Amada Faucet in operation, showing the waterfall effect of the water stream into a vessel sink.

WaterSense Compliance:

This faucet is WaterSense certified, delivering an efficient 1.2 GPM (gallons per minute) flow rate. This design conserves water without compromising water pressure, contributing to reduced utility costs and environmental impact.

MAINTENANCE

To maintain the appearance and functionality of your VIGO Amada faucet, follow these simple maintenance guidelines:

- **Cleaning:** Clean the faucet regularly with a soft cloth and mild soap. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish.
- **Finish Care:** The brushed nickel finish is designed to resist fingerprints and water spots, making it low-maintenance. Wipe dry after each use to prevent water spot buildup, especially in hard water areas.
- **Ceramic Disc Valve:** The Sedal ceramic disc valve is tested for 500,000 uses, ensuring long-term drip-free

performance. No routine maintenance is typically required for the valve itself.

Effortless Control

Single handle design allows for precise control of water temperature and flow.



Eternal Seal™

VIGO's patented ceramic disc cartridge **prevents water leaks and dripping** for long-lasting operation.




Image: An illustration highlighting the premium quality and engineering of VIGO faucets, including reinforced PEX piping and durable finishes.

TROUBLESHOOTING

If you encounter issues with your VIGO Amada faucet, refer to the following common troubleshooting tips. For more complex problems, consult a qualified plumber or contact VIGO customer support.

Common Issues and Solutions:

- **Low Water Flow:**
 - Check if the water supply valves under the sink are fully open.
 - Inspect the aerator (if applicable to your model, though waterfall spouts typically don't have traditional aerators) for debris or mineral buildup.
- **Leaking/Dripping:**
 - Ensure all connections are tight. Do not overtighten.
 - The ceramic disc valve is designed to prevent leaks. If persistent leaking occurs, the valve cartridge may need inspection or replacement.
- **Difficulty Adjusting Temperature:**
 - Verify that both hot and cold water supply lines are connected correctly and fully open.
 - If the issue persists, the valve cartridge might require professional assessment.



Video: A 360-degree spin video of the VIGO Amada Faucet, useful for visual inspection of the product from all angles.

SPECIFICATIONS

Brand	VIGO
Model Name	Amada

Model Number	VG03026BN
Mounting Type	Deck Mount
Finish Type	Brushed Nickel
Material	Solid Brass
Number of Handles	1
Hole Count	1
Spout Height	8 inches
Spout Reach	5 inches
Mounting Hole Diameter	1.38 inches
Flow Rate	1.2 GPM
Handle Type	Lever
Valve Type	Ceramic Disc Valve
UPC	849922027500

WARRANTY AND SUPPORT

VIGO stands behind the quality of its products. The VIGO Amada Waterfall Vessel Bathroom Sink Faucet comes with a **limited lifetime warranty**. This warranty covers manufacturing defects and ensures lasting performance.

Certifications:

This faucet is certified to meet various quality and safety requirements, including:

- CUPS (Certified to Uniform Plumbing Code)
- NSF-61 (National Sanitation Foundation)
- AB1953 (Lead-Free Compliance)

Customer Support:

For any inquiries, technical assistance, or warranty claims, VIGO provides support through email and phone assistance. Please refer to the official VIGO website or your product packaging for current contact information.



Video: An official VIGO video showcasing various VIGO Bathroom Faucets, highlighting design and quality.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question