

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Amazon Basics](#) /

› [Amazon Basics Rectangular Coffee Table with Lift Top and Storage, M61756T14B User Manual](#)

Amazon Basics M61756T14B

Amazon Basics Rectangular Coffee Table with Lift Top and Storage (Model: M61756T14B)

Instruction Manual

INTRODUCTION

This manual provides instructions for the assembly, operation, and maintenance of your Amazon Basics Rectangular Coffee Table with Lift Top and Storage. This black coffee table features a modern lift-top design and integrated storage, suitable for various living spaces. Its sturdy wooden construction and sleek black finish offer both functionality and aesthetic appeal.

SAFETY INFORMATION

- Always assemble the product on a soft, clean surface to prevent scratches.
- Ensure all screws and fasteners are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the maximum weight recommendation of 40 pounds on the tabletop.
- Keep small parts away from children during assembly.
- Use caution when operating the lift-top mechanism to avoid pinching fingers or hands.
- Do not stand or sit on the table.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Tabletop with pre-assembled lift mechanism
- Side panels
- Bottom shelf panels

- Support beams
- Hardware pack (screws, cam locks, Allen wrench)

Note: Additional tools such as a screwdriver may be required for assembly and are not included.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this coffee table. Follow the steps below carefully. It is recommended to have two people for certain assembly steps.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent damage.
2. **Identify Parts:** Refer to the included parts list (not provided in this manual, typically found in the product box) to identify each component.
3. **Assemble Base Frame:** Connect the side panels and bottom shelf panels using the provided hardware (e.g., cam locks, screws). Ensure all connections are snug.
4. **Attach Lift-Top Mechanism:** The lift-top mechanism is typically pre-assembled to the tabletop. Carefully align the pre-assembled tabletop with the base frame and secure it using the designated screws. This step may require an Allen wrench and patience, especially for corner screws.
5. **Final Tightening:** Once all components are in place, gently re-tighten all screws and fasteners to ensure stability. Do not overtighten.



Figure 1: Assembled coffee table with the lift-top in the raised position, revealing hidden storage and lower shelves.

OPERATING INSTRUCTIONS

This coffee table features a versatile lift-top and ample storage options.

Lift-Top Operation:

1. **To Raise:** Gently lift the tabletop from one side. The spring-loaded mechanism will assist in raising it to a comfortable height for working or dining. It will lock into place when fully extended.
2. **To Lower:** Locate the release mechanism (often a lever or pull-tab) beneath the tabletop. Engage the mechanism and gently push the tabletop down until it rests flush with the base. Ensure no objects are obstructing the closing path.



Figure 2: Coffee table with the lift-top in the closed position, ready for general use.

Storage Features:

- **Hidden Storage:** The compartment beneath the lift-top provides concealed storage for items such as remote controls, magazines, or small blankets.
- **Open Shelves:** The lower section of the table includes open shelves, ideal for displaying books, decorative items, or storing baskets.



Figure 3: Detail of the open storage shelves, providing additional space for organization.

MAINTENANCE

- **Cleaning:** Wipe the table surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Spills:** Promptly clean up any spills to prevent staining, especially on the black finish.
- **Protection:** Use coasters and placemats to protect the tabletop from heat, moisture, and scratches.
- **Mechanism Care:** If the lift mechanism becomes stiff, a small amount of silicone lubricant can be applied to the moving parts. Avoid oil-based lubricants that may attract dust.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Tabletop is wobbly.	Loose fasteners.	Check and tighten all assembly screws and cam locks.
Lift-top mechanism is stiff or difficult to operate.	Lack of lubrication or initial stiffness.	Apply a small amount of silicone lubricant to the moving parts of the mechanism. Operate the lift-top several times to distribute the lubricant.
Surface scratches or minor blemishes.	Normal wear and tear; potential during shipping/assembly.	Use furniture markers or touch-up paint designed for black wood finishes. Use coasters and placemats to prevent future damage.

SPECIFICATIONS

Feature	Detail
Brand	Amazon Basics
Model Number	M61756T14B
Dimensions (D x W x H)	18" x 40" x 19"
Item Weight	39 Pounds
Maximum Weight Recommendation	40 Pounds
Frame Material	Wood
Color	Black
Assembly Required	Yes
Indoor/Outdoor Usage	Indoor

WARRANTY AND SUPPORT

This Amazon Basics Rectangular Coffee Table is backed by a **1-year limited warranty**. For detailed warranty information, claims, or technical support, please refer to the warranty card included with your product or visit the official Amazon Basics support website.

For further assistance, you may contact Amazon Basics customer service through their official channels.

