

[Manuals.plus](#) /

› [Legamaster](#) /

› Legamaster Board-Up Whiteboard User Manual

Legamaster 7-106375

Legamaster Board-Up Whiteboard User Manual

Model: 7-106375

INTRODUCTION

The Legamaster Board-Up Whiteboard is a frameless, magnetic board made of lacquered steel, designed for versatile use in office or home environments. Its robust and dry-wipeable surface ensures excellent writing and easy cleaning, making it ideal for brainstorming, sketching ideas, project planning, and visual communication. This manual provides essential information for the proper installation, operation, and maintenance of your whiteboard.

UNIQUE



Image: Legamaster Board-Up Whiteboard, showcasing its sleek, frameless design.

SAFETY INFORMATION

- Always ensure the wall surface is suitable for mounting and can support the weight of the whiteboard.
- Use appropriate tools and safety gear during installation.
- Keep small parts and mounting hardware out of reach of children.
- Do not hang heavy objects from the whiteboard.
- Avoid using abrasive cleaners or sharp objects on the whiteboard surface to prevent damage.

PACKAGE CONTENTS

Please verify that all items listed below are included in your package:

- 1 x Legamaster Board-Up Whiteboard (75 x 75 cm / 30"W x 29.5"H)

- 1 x Marker Tray
- 1 x Mounting Set (screws, wall plugs, mounting brackets)
- 1 x Installation Instructions

SETUP AND INSTALLATION

The Legamaster Board-Up Whiteboard is designed for easy wall mounting, either horizontally or vertically. Follow these steps carefully for secure installation.

1. **Prepare the Wall:** Choose a suitable location on a sturdy wall. Ensure there are no electrical wires or pipes behind the drilling points.
2. **Mark Drilling Points:** Hold the whiteboard against the wall at the desired height and position. Use a pencil to mark the locations for the mounting brackets. Ensure the marks are level using a spirit level.
3. **Drill Holes:** Using an appropriate drill bit for your wall type, drill holes at the marked points. Insert the wall plugs into the drilled holes.



Image: Illustrates the process of drilling and securing the mounting hardware to the wall.

4. **Attach Mounting Brackets:** Screw the mounting brackets securely into the wall plugs. Ensure they are firmly attached and level.
5. **Mount the Whiteboard:** Carefully align the whiteboard with the attached brackets and place the board onto the wall, ensuring it sits securely on the brackets. The design allows for easy placement without needing to hold the board during the final screwing.
6. **Install Marker Tray:** Attach the marker tray to the bottom edge of the whiteboard as desired.



Image: Example of multiple whiteboards installed in an office setting, demonstrating versatile arrangements.

OPERATING INSTRUCTIONS

Writing and Erasing

Use only dry-erase markers specifically designed for whiteboards. Write clearly on the lacquered steel surface. To erase, use a dry-erase board eraser or a soft, clean cloth. The surface is designed for easy dry-wiping.



Image: A user actively writing on the whiteboard, demonstrating its use in a collaborative setting.

Magnetic Functionality

The whiteboard features a magnetic surface, allowing you to attach notes, documents, photos, or other magnetic accessories using magnets. This makes it suitable for use as a memo board, weekly planner, or vision board.




Image: Examples of creative content and magnetic attachments on the whiteboard.

MAINTENANCE

- **Regular Cleaning:** For daily cleaning, use a dry-erase board eraser or a soft, dry cloth.
- **Deep Cleaning:** If ghosting or stubborn marks appear, use a specialized whiteboard cleaner spray or a damp cloth with mild soap and water. Wipe dry immediately with a clean, soft cloth. The surface is resistant to aggressive washing/cleaning agents.
- **Permanent Marker Removal:** In case of accidental use of permanent markers, Legamaster's MagicWipe (sold separately) can be used to remove the ink without damaging the surface.
- **Avoid Abrasives:** Do not use abrasive cleaners, scouring pads, or sharp objects, as these can scratch or damage the lacquered steel surface.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Marks are difficult to erase or ghosting occurs.	Using non-dry-erase markers, old/poor quality markers, or infrequent cleaning.	Ensure only dry-erase markers are used. Clean the board regularly with a whiteboard cleaner or damp cloth. For permanent marker, use Legamaster MagicWipe.

Problem	Possible Cause	Solution
Whiteboard is not securely mounted.	Improper installation, loose screws, or unsuitable wall material.	Re-check installation steps. Ensure screws are tightened and wall plugs are secure. If the wall material is weak, consider using stronger anchors or a different mounting location.
Magnetic items do not stick well.	Weak magnets or excessive weight.	Use stronger magnets. Ensure the items being attached are not too heavy.

SPECIFICATIONS

- Model Number:** 7-106375
- Dimensions:** 75 x 75 cm (29.53 x 0.39 x 29.53 inches)
- Weight:** 7.83 pounds
- Material:** Lacquered Steel
- Color:** White
- Mounting Type:** Wall Mount
- Features:** Magnetic, Dry-wipeable, Scratch-resistant, Fireproof, Bacteria and Chemical resistant

WARRANTY AND SUPPORT

Legamaster products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your product or visit the official Legamaster website. For technical support, replacement parts, or any other inquiries, please contact Legamaster customer service through their official channels.

Website: www.legamaster.com

© 2023 Legamaster. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question