

[Manuals.plus](#) /

› [Naturehike](#) /

› Naturehike Cloud Up 3 Person Tent Instruction Manual

Naturehike CNK2350WS020

Naturehike Cloud Up 3 Person Tent Instruction Manual

Model: CNK2350WS020

INTRODUCTION

The Naturehike Cloud Up 3 Person Tent is a lightweight, four-season backpacking tent designed for camping and hiking. It features a double-layer construction for weather protection and ventilation, making it suitable for various outdoor conditions. This manual provides detailed instructions for the proper setup, operation, maintenance, and care of your tent.

COMPONENTS LIST

Before setting up your tent, ensure all components are present:

- Rain Fly (Outer Tent)
- Inner Tent
- Carry Bag
- Tent Poles
- Wind Ropes
- Strapping Tape
- Stakes (Ground Pegs)
- Footprint (Ground Mat)



Image: All components of the Naturehike Cloud Up 3 Person Tent, including the rain fly, inner tent, poles, stakes, ropes, and carry bag.

SETUP INSTRUCTIONS

The Naturehike Cloud Up 3 Person Tent features a free-standing design for quick and easy setup, typically taking less than 5 minutes.

1. **Prepare the Site:** Choose a flat, clear area for your tent. Lay out the included footprint on the ground.
2. **Assemble Poles:** Connect the sections of the tent poles until they form a single, continuous frame.
3. **Set Up Inner Tent:** Lay the inner tent over the footprint. Insert the ends of the assembled poles into the grommets or sleeves located at the corners of the inner tent.
4. **Secure Inner Tent:** Clip the inner tent to the pole structure. If conditions are windy, use the provided stakes to secure the corners of the footprint and inner tent to the ground.
5. **Attach Rain Fly:** Drape the rain fly over the inner tent, ensuring the vestibule aligns with the inner tent's door. Attach the buckles on the rain fly to the corresponding buckles on the inner tent's pole structure.
6. **Stake Out Rain Fly:** Secure the rain fly to the ground using the remaining stakes. Utilize the wind ropes and strapping tape for additional stability, especially in windy conditions. Adjust the tension of the rain fly to ensure it is taut and provides adequate clearance from the inner tent for ventilation.



Image: A visual guide demonstrating the quick and easy setup process for the Naturehike Cloud Up 3 Person Tent.



Image: Detailed view of the outer tent being set up and the inner tent with its mesh structure.

OPERATING INSTRUCTIONS

Ventilation

The Cloud Up 3 features additional ventilation windows designed to minimize condensation buildup inside the tent. Ensure these windows are open when conditions allow to promote airflow.

Seasonal Use

This tent is designed for 4-season use:

- **Rainy/Snowy/Winter Weather:** Use both the inner and outer tent superposed together for waterproof and windproof protection.
- **Spring/Summer/Autumn:** For warmer, drier conditions, the inner layer can be used alone as a ventilated tent.

Zipper Operation

The tent is equipped with smooth zippers. Operate them carefully and avoid excessive force to prevent snagging on fabric. Always hold the fabric near the zipper when opening or closing.




Image: A close-up view of the tent's smooth zipper mechanism.

MAINTENANCE

Proper maintenance extends the life of your tent.

- **Cleaning:** Wipe clean with a damp cloth. Do not machine wash or use harsh detergents, as this can damage the waterproof coating.
- **Drying:** Always ensure the tent is completely dry before packing it away. Packing a wet or damp tent can lead to mildew growth and fabric degradation.
- **Storage:** Store your tent in a cool, dry place away from direct sunlight when not in use.
- **Pole Care:** Inspect tent poles for any damage or bends before and after each trip. Clean any dirt from pole sections.
- **Stakes and Ropes:** Clean stakes and wind ropes after use. Store them neatly to prevent tangling.

TROUBLESHOOTING

- **Condensation:** If condensation occurs, ensure all ventilation windows are open and that the rain fly is properly tensioned to allow airflow between the inner and outer tent.
- **Water Leakage:** Verify that the tent is set up correctly and that the rain fly is taut and fully covering the inner tent. Inspect seams for any visible damage. The tent features a waterproof coating and double-layer construction designed to prevent leakage.
- **Zipper Snagging:** When operating zippers, use a slow, steady motion and hold the fabric taut to prevent it from catching in the zipper teeth.
- **Tent Instability:** Ensure all stakes are firmly in the ground and all wind ropes are properly deployed and tensioned, especially in windy conditions.

SPECIFICATIONS


Model Name	CNK2350WS020
Occupancy	3 Person

Seasons	4 Season
Inner Layer Size (L x W x H)	85 x 71 x 43 inches (215 x 180 x 110 cm)
Outer Layer Size (L x W x H)	118 x 76 x 43 inches (300 x 193 x 110 cm)
Package Size (L x W x H)	17.7 x 5.9 x 5.9 inches (45 x 15 x 15 cm)
Weight	4.9 lbs (2.22 kg)
Material Type	20D Nylon
Rainfly Material	20D Nylon, PU 3000mm
Tent Floor Material	Nylon
Water Resistance Technology	Waterproof coating and double-layer construction
Poles	Yuksom Ø8.5 Aluminum Alloy
Installation Type	Free Standing



SPECIFICATIONS



- Outer tent size: 116.1*82.7*45.3inches
- Inner tent size: 86.6*70.9*43.3inches
- Storage size : 6.7*16.9 inches
- Weight:5.1lbs



inch



Tent storage bag x 1



Outer tent x 1



Tent poles x 1



Inner tent x 1



Ground pegs x 15



Footprint is included x 1



Tie down straps x 1



Wind ropes x 6

Image: Detailed specifications and dimensions of the Naturehike Cloud Up 3 Person Tent.

WARRANTY INFORMATION

The Naturehike Cloud Up 3 Person Tent comes with a **2 Year Manufacturer Warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for any warranty claims.

SUPPORT

For further assistance, technical support, or warranty inquiries, please contact Naturehike customer service. Refer to the official Naturehike website or your purchase documentation for current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07J6RVXZT>

More documents and user manuals: <https://manuals.plus/>