

[Manuals.plus](#) /

› [Ascend](#) /

› Ascend 22mm Replacement Watch Band for Skagen Watches (Screw Type) - Instruction Manual

Ascend SKML22SCR

Ascend 22mm Replacement Watch Band for Skagen Watches (Screw Type)

Instruction Manual

1. PRODUCT OVERVIEW

This manual provides instructions for the installation and care of your Ascend 22mm replacement watch band. This band is specifically designed for Skagen watches that utilize a screw-type attachment mechanism, not spring bars. The band is crafted from genuine calfskin leather and comes in a brown finish.



Image 1.1: The Ascend 22mm brown leather watch band, featuring a silver buckle and screw-type attachment points.

2. COMPATIBILITY

This replacement watch band is compatible with Skagen watches that meet the following two conditions:

1. The watch uses a **screw structure** for band attachment, not a spring rod structure.
2. The lug width of the watch is **22 mm**.

The strap is designed to be fixed directly with screws, ensuring a strong and secure connection.

Compatible Skagen Models:

- **233X Screw Leather Strap Series:** 233XXLGL, 233XXLSLB, 233XXLSLD, 233XXLSLO, 233XXLSLW, 233XXLRLB, 233XXLRLD, 233XXLSLCB, 233XXLBLBC.
- **SKW6000 Series:** SKW6024, SKW6025, SKW6051, SKW6052, SKW6053, SKW6082, SKW6097, SKW6098, SKW6099, SKW6100, SKW6101, SKW6103, SKW6104, SKW6105, SKW6106, SKW6107, SKW6108, SKW6112, SKW6113, SKW6114, SKW6115, SKW6142, SKW6143, SKW6145, SKW6147, SKW6148, SKW6162, SKW6163, SKW6164, SKW6165, SKW6183, SKW6184, SKW6190, SKW6191, SKW6192, SKW6193, SKW6194, SKW6195, SKW6196, SKW6197, SKW6198, SKW6199, SKW6202, SKW6203, SKW6232, SKW6234, SKW6236, SKW6243, SKW6251, SKW6253, SKW6254.
- **Other Models:** SKW2190, 355XLSS, A355XLSLB, 355XLSSB, 355XLSSNA, 355XLGLD, 733XLTTM, 733XLSS, 733XLSLB.
- Generally fits all 22mm screw construction watches.

Important Note: The 233X steel belt series with spring rods is NOT suitable for this replacement band.

3. PACKAGE CONTENTS

Your Ascend replacement watch band package includes:

- 1 x Ascend 22mm Leather Watch Band (brown)
- 4 x Replacement Screws
- 1 x Screwdriver Tool



Image 3.1: Included screwdriver and replacement screws for installation.

4. SETUP (INSTALLATION)

Follow these steps to replace your watch band:

1. **Prepare Your Workspace:** Work on a clean, well-lit surface. It is advisable to place a soft cloth or mat underneath to prevent scratches to your watch and to catch any small parts.
2. **Remove the Old Band:** Identify the screws on the side of your watch lugs that secure the current band. Use the provided screwdriver to carefully unscrew and remove the existing screws. Keep your original screws in a safe place as spares.
3. **Position the New Band:** Take one half of the new Ascend watch band. Align the end of the band with the lug opening on your watch. Ensure the band is oriented correctly (e.g., buckle side on top, if applicable, or according to your preference).
4. **Insert Screws:** Place one of the new screws onto the tip of the screwdriver. A magnetized screwdriver can be helpful for this step. Carefully guide the screw into the hole on the watch lug and through the band's attachment point.
5. **Secure the Band:** Gently turn the screw clockwise to tighten it. Do not overtighten, as this can strip the screw head or damage the watch. Ensure the band is securely fastened but still allows for slight movement.

6. **Verify Alignment:** Before fully tightening, check the alignment of the band from the front of the watch to ensure it sits correctly within the recess/channel. The pre-drilled holes in the band may not perfectly align with the watch's internal structure, so rely on visual alignment.
7. **Repeat for Other Side:** Repeat steps 3-6 for the other half of the watch band.
8. **Adjust for Fit (if necessary):** In some cases, you may need to gently crimp one or both ends of the band with needle-nose pliers to ensure it fits snugly into the watch's recess/channel.



Image 4.1: The watch band separated, ready for installation onto the watch lugs.

5. OPERATING (WEARING THE WATCH)

Once the watch band is securely installed, you can wear your watch as usual. Adjust the buckle to find a comfortable fit on your wrist. The multiple holes on the band allow for various wrist sizes.



Image 5.1: The underside of the watch band, indicating genuine leather material.

6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your leather watch band, follow these care instructions:

- **Avoid Water:** Leather can be damaged by prolonged exposure to water. Remove your watch before swimming, showering, or engaging in activities where it might get wet.
- **Avoid Heat and Direct Sunlight:** Excessive heat and direct sunlight can cause the leather to dry out, crack, or fade. Store your watch in a cool, dry place away from direct light when not in use.
- **Use a Skin Remedy:** Periodically apply a leather conditioner or skin remedy designed for leather products. This helps to keep the leather supple and prevents drying.
- **Clean Gently:** If cleaning is necessary, wipe the band with a soft, slightly damp cloth. Avoid harsh chemicals or abrasive cleaners.

7. TROUBLESHOOTING

This section addresses common issues you might encounter. If you experience problems not listed here, please refer to the Support section.

Band Does Not Fit:

- **Check Compatibility:** Ensure your watch meets both the 22mm lug width and screw-type attachment requirements as detailed in Section 2.
- **Verify Screw Type:** Confirm your watch uses screws, not spring bars. This band is not compatible with spring bar mechanisms.
- **Alignment:** During installation, ensure the band is correctly aligned with the watch lugs. Gentle crimping with needle-nose pliers may be needed to fit the band into the watch's recess.

Screws Are Loose:

- Gently re-tighten the screws using the provided screwdriver. Do not overtighten.
- If screws repeatedly loosen, ensure they are fully engaged in the watch's threads.

8. SPECIFICATIONS

Brand	Ascend
Model Number	SKML22SCR
ASIN	B07J9RSSHV
Band Width	22 mm
Material	Natural Calfskin Leather
Color	Brown
Attachment Type	Screw Construction

9. WARRANTY INFORMATION

Specific warranty details for this product are not provided in the available information. Please refer to the retailer or manufacturer's website for any applicable warranty policies.

10. SUPPORT

For further assistance or inquiries regarding your Ascend replacement watch band, please contact the seller through the platform where the purchase was made. Manufacturer contact information is not explicitly provided in the available data.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question