

[Manuals.plus](#) /

› [Sun Joe](#) /

› Sun Joe SPX3001-76 Pressure Washer U Shape Pin User Manual

Sun Joe SPX3001-76

Sun Joe SPX3001-76 Pressure Washer U Shape Pin User Manual

Model: SPX3001-76 | Brand: Sun Joe

PRODUCT OVERVIEW

The Sun Joe SPX3001-76 is a genuine replacement U-shape pin designed specifically for the Sun Joe SPX3001 and SPX4001 Electric Pressure Washers. This small but essential component plays a crucial role in securing certain parts of your pressure washer, ensuring stable and safe operation.



Image: The Sun Joe SPX3001-76 U-Shape Pin, a metal component with a distinctive U-shape and bent ends.

This part is manufactured to the exact specifications of your original equipment, guaranteeing a perfect fit and reliable

performance. It is a direct replacement for part #SPX3001-76.

INSTALLATION INSTRUCTIONS

This U-shape pin is typically used to secure components such as the handle or other accessories on your Sun Joe SPX3001 or SPX4001 Electric Pressure Washer. Always ensure the pressure washer is unplugged and depressurized before attempting any installation or replacement.

1. **Identify the Location:** Locate the area on your SPX3001 or SPX4001 pressure washer where the U-shape pin is missing or needs replacement. This is commonly found securing the upper handle to the main unit.
2. **Remove Old Pin (if applicable):** If replacing an existing pin, carefully remove the old or damaged pin. This may require gently wiggling or pulling it out.
3. **Align Components:** Align the components that the U-shape pin is intended to secure. For example, ensure the holes on the upper handle align with the corresponding holes on the pressure washer body.
4. **Insert New Pin:** Insert the new SPX3001-76 U-shape pin through the aligned holes. Apply gentle pressure until the pin is fully seated and securely holds the components together. The bent ends of the pin are designed to provide a secure fit.
5. **Verify Security:** Gently tug on the secured components to ensure the U-shape pin is firmly in place and the connection is stable.



Image: A Sun Joe SPX3001 Electric Pressure Washer, illustrating the type of equipment this U-pin is designed for.

MAINTENANCE

As a small metal component, the U-shape pin requires minimal maintenance. However, regular inspection can prolong its lifespan and ensure continued safety.

- **Regular Inspection:** Periodically check the U-shape pin for any signs of wear, bending, or corrosion. If the pin appears damaged or loose, replace it immediately to prevent accidental detachment of components.
- **Cleaning:** If the pin becomes dirty, wipe it clean with a damp cloth. Avoid using harsh chemicals that could corrode the metal.
- **Storage:** When not in use, store the pressure washer and its components in a clean, dry place to prevent rust and damage.

TROUBLESHOOTING

Most issues related to the U-shape pin are straightforward. Here are common scenarios and solutions:

Problem	Possible Cause	Solution
Pin does not fit into the holes.	Incorrect pin model or misalignment of components.	Ensure you have the correct pin (SPX3001-76) for your SPX3001 or SPX4001 pressure washer. Verify that the components you are trying to secure are perfectly aligned.
Pin feels loose after installation.	Pin not fully seated or components not properly aligned.	Push the pin firmly until it is fully seated. Re-check alignment of components and re-insert the pin.
Pin is bent or broken.	Excessive force, impact, or material fatigue.	Replace the pin with a new SPX3001-76 U-shape pin.

SPECIFICATIONS

Attribute	Detail
Model Number	SPX3001-76
Part Type	U-Shape Pin
Compatibility	Sun Joe SPX3001 Electric Pressure Washer, Sun Joe SPX4001 Electric Pressure Washer
Product Dimensions	Approximately 10 x 3 x 4 inches (packaging dimensions)
Item Weight	Approximately 1 pound (packaging weight)
Manufacturer	Snow Joe

WARRANTY AND SUPPORT

As a replacement part, the Sun Joe SPX3001-76 U-shape pin is typically covered under the warranty of the original Sun Joe pressure washer it is intended for, or under a limited warranty for replacement parts. For specific warranty details and support, please refer to the documentation provided with your Sun Joe pressure washer or contact Sun Joe customer service directly.

You can find more information and contact details on the official Sun Joe website or through their Amazon store page:

[Visit the Sun Joe Store on Amazon](#)

OFFICIAL PRODUCT VIDEOS

No official product-specific videos for the Sun Joe SPX3001-76 U-shape pin are available in the provided media. For general product demonstrations or assembly guides related to Sun Joe pressure washers, please visit the official Sun Joe website or their YouTube channel.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B07JBBX88J>

More documents and user manuals: **<https://manuals.plus/>**