

[Manuals.plus](#) /

› [Frigidaire](#) /

› Frigidaire Portable Compact Ice Maker Instruction Manual

Frigidaire EFIC120

Frigidaire Portable Compact Ice Maker

Model: EFIC120

INTRODUCTION

Thank you for choosing the Frigidaire Portable Compact Ice Maker. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.

WHAT'S IN THE BOX

- Ice Maker Unit
- Ice Basket
- Ice Scoop

KEY FEATURES

- **Large Capacity:** Produces up to 26 lbs of clear ice cubes per day with a reservoir located beneath the ice basket.
- **Efficient & Easy to Use:** Makes perfectly squared ice cubes in less than 6 minutes and stores up to 2.2 lbs at a time. Features user-friendly electronic controls.
- **Versatile:** Offers a choice to make ice cubes in two different sizes (Small and Large).
- **Modern Design:** Stainless Steel finish with a large transparent window to monitor ice production.
- **Functionality:** Digital control panel indicates when the bin is full and when water is empty. Ice automatically drops into the provided ice bucket when ready.

SETUP

Unpacking and Placement

Carefully remove all packaging materials. Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit, leaving at least 5 inches of space from walls or other appliances to allow for proper airflow from the side vents.



Figure 1: Product dimensions for proper placement.

Initial Cleaning

Before first use, clean the interior of the ice maker. Remove the ice basket and wash it with warm water and a mild detergent. Wipe the interior with a soft cloth. Rinse thoroughly and dry all components before reassembly.

Filling the Water Reservoir

Open the top lid and locate the water reservoir beneath the ice basket. Fill the reservoir with potable water up to the MAX fill line. Do not overfill.

Large Water Capacity

With a 2.3 qt. Water tank capacity,
You can enjoy uninterrupted ice making
Without having to constantly refill.



Figure 2: View of the large water reservoir capacity.

OPERATING INSTRUCTIONS

Powering On/Off

Plug the ice maker into a grounded electrical outlet. Press the **ON/OFF** button on the control panel to turn the unit on. The **POWER** indicator light will illuminate. To turn off, press the **ON/OFF** button again.

Intuitive Digital Led Control Panel

Take charge effortlessly with the digital LED control panel that allows easy adjustment of settings for personalized ice making at your fingertips.



Figure 3: Intuitive Digital LED Control Panel.

Selecting Ice Size

Press the **SELECT** button to choose between small (S) or large (L) ice cubes. The corresponding indicator light will illuminate.

Ice Production Cycle

Once powered on and ice size is selected, the ice maker will begin its cycle. Ice cubes will be produced and dropped into the ice basket. The first batch may take slightly longer.



FRIGIDAIRE is a pending or registered trademark of Electrolux Home Products Inc. and use under a license from Electrolux Home Products Inc. FRIGIDAIRE est une marque déposée ou en instance d'Electrolux Home Products Inc. et utilisée sous une licence d'Electrolux Home Products Inc.

Figure 4: Ice production in progress.

Indicators

- **ADD WATER:** This light illuminates when the water reservoir is low. Refill the reservoir to continue ice production.
- **ICE FULL:** This light illuminates when the ice basket is full. Remove ice from the basket to resume production.

MAINTENANCE AND CLEANING

Regular Cleaning

For optimal performance and hygiene, clean your ice maker regularly. It is recommended to clean the machine every 4-6 weeks, and the ice basket frequently.

- Unplug the unit before cleaning.

- Remove the ice basket and wash it with warm, soapy water.
- Drain any remaining water from the reservoir using the drain plug located at the bottom of the unit.
- Clean the interior of the reservoir and ice-making components with a soft cloth and a mild, non-abrasive cleaner or a solution of white vinegar and water (1:1 ratio). For hard-to-reach spots, a toothbrush can be used.
- Rinse thoroughly with clean water to remove any cleaning solution residue. Ensure no chemicals are left behind to avoid affecting ice taste.
- Wipe the exterior with a soft, damp cloth.

Draining Water

To drain the water, unplug the unit and place it over a sink or basin. Remove the drain plug from the bottom of the unit and allow all water to empty. Replace the plug securely after draining.

Storage

If storing the ice maker for an extended period, ensure it is thoroughly cleaned and dried. Store it in a cool, dry place away from direct sunlight and extreme temperatures.

TROUBLESHOOTING

Problem	Possible Cause	Solution