

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Victiv](#) /

› [Victiv T72 72-inch Camera Tripod Monopod Instruction Manual](#)

Victiv T72

Victiv T72 72-inch Camera Tripod Monopod Instruction Manual

Model: T72 | Brand: Victiv

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Victiv T72 72-inch Camera Tripod Monopod. This versatile and robust photography accessory is designed to provide stable support for a wide range of devices, including cameras, smartphones, spotting scopes, telescopes, and binoculars. Its innovative 2-in-1 design allows for quick conversion between a tripod and a monopod, making it an ideal companion for both amateur and professional photographers and videographers. This manual will guide you through the setup, operation, and maintenance of your new tripod to ensure optimal performance and longevity.

2. KEY FEATURES

- **Lightweight and Portable:** Weighing only 3.3 lbs (1.5 kg), this tripod is designed for easy transport with a strapped carrying bag.
- **Upgraded Solid Construction:** Made of durable aluminum alloy with thicker leg tubes for enhanced stability, suitable for long exposure photography.
- **Tripod and Monopod Combined Unit:** Quickly converts from a full tripod to a 55-inch monopod in approximately 5 seconds, offering dual functionality.
- **Versatile Height Adjustment:** Adjustable height from 21 inches to 72 inches, accommodating various shooting requirements.
- **Smooth 3-Way Swivel Head:** Features 360-degree panning and tilting capabilities, allowing for horizontal and vertical adjustments and easy direction changes.
- **Universal Compatibility:** Compatible with a wide array of devices including phones, DSLRs, spotting scopes, telescopes, and binoculars.
- **Wireless Remote Shutter:** Includes a remote for convenient hands-free photography from up to 33 feet away.

3. SETUP GUIDE

3.1 Unfolding the Tripod

To unfold the tripod, release the leg locks on each leg and extend them outwards. Adjust the leg angles for desired stability. Ensure all leg locks are securely fastened before mounting any equipment.

EXTREME HIGH LOAD CAPACITY

90% Aluminum Alloy Enough for Stable Long Exposure and Stronger Bearing Capacity




Carry handle design



Large Base Area



Thickened Leg Tube



Thickened non-slip foot mats




Image: The Victiv T72 Tripod fully extended, showcasing its maximum height and stable stance.

3.2 Attaching Your Device

The tripod comes with a universal mounting plate. Attach this plate to the bottom of your camera or the included phone holder. Then, slide the plate into the tripod head and secure it with the locking mechanism. For smartphones, use the universal phone holder provided.



Image: Close-up of the quick release plate, which attaches to your camera or phone holder for secure mounting on the tripod head.

3.3 Converting to Monopod

To convert the tripod into a monopod, loosen the center lock knob and remove the center column. The center column can then be used as a standalone monopod. Adjust its height by rotating the column and locking it into place.



Image: Visual guide illustrating the steps to convert the Victiv T72 from a tripod to a monopod by detaching the center column.

3.4 Using the Wireless Remote

The wireless remote shutter connects via Bluetooth to your smartphone. Pair the remote with your device to capture photos or start/stop video recording from a distance, allowing for hands-free operation.

Versatile Video Camera Tripod

Perfect for live streaming, recording, wedding, photography video recording, filming, meeting, live streaming, vlogging and travel



Wireless Remote Control

Experience with both IOS and Android phones. You can take photos or video from 30ft/10m away

Image: A user demonstrating the wireless remote shutter with a smartphone mounted on the tripod, enabling remote photo capture.

4. OPERATING INSTRUCTIONS

4.1 Adjusting Height and Stability

Extend the 4-section column legs by flipping open the leg locks. Adjust each leg to the desired height and angle, then securely close the locks. For added stability, especially in windy conditions, you can hang a weight from the center column hook.



Image: Close-up of the tripod legs showing the flip leg locks and the central hook for adding weight to enhance stability.

4.2 Using the 3-Way Swivel Head

The 3-way swivel head allows for precise adjustments. Loosen the main knob to pan the camera 360 degrees horizontally. Use the tilt handle to adjust vertical angles (up to 90 degrees) and horizontal angles (up to 270 degrees). Tighten the knobs once the desired position is achieved.

VICTIV Tripod KITS

1. Complete tripod kits
2. Extra quick release plate
3. Carrying case with shoulder straps
4. Universal Holder
5. Wireless remote



Image: The 3-way swivel head with a camera mounted, demonstrating its range of motion for panning and tilting.

4.3 Level Indicator

A built-in bubble level helps ensure your setup is perfectly horizontal, preventing skewed horizons in your photos and videos.

Video: A user demonstrates the built-in bubble level on the tripod head, ensuring a perfectly horizontal setup for photography and videography.

5. MAINTENANCE

To ensure the longevity and optimal performance of your Victiv T72 tripod, follow these maintenance guidelines:

- **Cleaning:** Wipe down the tripod with a soft, dry cloth after each use to remove dust, dirt, and moisture. For stubborn grime, use a slightly damp cloth and mild soap, then dry thoroughly.
- **Lubrication:** Periodically check the moving parts, such as leg locks and head mechanisms. If they feel stiff,

apply a small amount of silicone-based lubricant. Avoid oil-based lubricants as they can attract dust.

- **Storage:** Store the tripod in its carrying bag in a cool, dry place away from direct sunlight and extreme temperatures. Ensure it is fully collapsed and clean before storage.
- **Inspection:** Regularly inspect all screws, bolts, and connections to ensure they are tight. Do not overtighten. Check for any signs of wear or damage on the legs, head, and rubber feet.

6. TROUBLESHOOTING

If you encounter any issues with your Victiv T72 tripod, refer to the following common troubleshooting tips:

- **Tripod Instability:** Ensure all leg locks are fully engaged and the legs are spread evenly. Check if the ground surface is level. If using the center column hook, ensure any attached weight is balanced.
- **Stiff Leg Locks/Head Movement:** Apply a small amount of silicone lubricant to the moving parts as described in the maintenance section.
- **Device Not Secure:** Double-check that the quick release plate is correctly attached to your device and fully locked into the tripod head. Ensure the device's weight does not exceed the tripod's maximum load capacity.
- **Wireless Remote Not Connecting:** Ensure the remote's battery is charged and it is in pairing mode. Check your smartphone's Bluetooth settings to ensure it is discoverable and correctly paired with the remote.

7. SPECIFICATIONS

Feature	Specification
Product Dimensions	4.72 x 4.92 x 17.3 inches
Item Weight	3.52 pounds (1.6 Kilograms)
Material	Aluminum
Weight Limit	3.3 Pounds
Model Name	T72
Maximum Height	182 Centimeters (72 inches)
Compatible Devices	Camera, Smartphone
Special Feature	Lightweight, Compact, Monopod Functionality
Tripod Head Type	Ball Heads, Pan Heads (3-Way Swivel Head)

8. WARRANTY AND SUPPORT

Victiv offers various protection plans to safeguard your investment. For detailed information on warranty coverage, product support, or to purchase an extended protection plan, please visit the official Victiv store on Amazon or contact customer service.

- **2-Year Protection Plan:** Available for purchase.
- **3-Year Protection Plan:** Available for purchase.

- **Complete Protect:** A monthly plan covering eligible past and future purchases.

For further assistance, please refer to the contact information provided with your product packaging or visit the [Victiv Store on Amazon](#).