

Manuals.plus /

- › VIVO /
- › VIVO Swivel Bolt-Down TV Stand (STAND-TV00M2) Instruction Manual

VIVO STAND-TV00M2

VIVO Swivel Bolt-Down TV Stand (STAND-TV00M2) Instruction Manual

Model: STAND-TV00M2 | Brand: VIVO

1. INTRODUCTION

The VIVO Swivel Bolt-Down TV Stand (STAND-TV00M2) provides a secure and adjustable solution for mounting televisions ranging from 23 to 43 inches. This stand is designed for desktop, tabletop, or dresser placement, featuring a robust bolt-down base to prevent tipping and ensure stability. Its sleek, matte black finish complements various environments, while integrated cable management helps maintain an organized appearance. The stand offers swivel adjustment for optimal viewing angles and is compatible with common VESA mounting patterns.






Figure 1: VIVO Swivel Bolt-Down TV Stand with a television mounted.

2. SAFETY INFORMATION

Please read and understand all instructions before installation and use. Failure to do so may result in personal injury or property damage. Ensure all components are present and undamaged before assembly. Do not use this product for any purpose not explicitly specified by the manufacturer.

Weight and Size Limitations:

- **Screen Size:** 23 to 43 inches
- **Weight Capacity:** Up to 110 lbs (50 kg)

VESA Compatibility:

This stand supports VESA mounting patterns including 100x100mm, 200x100mm, and 200x200mm. Verify your TV's VESA pattern before proceeding with installation.



Figure 2: VESA compatibility, weight capacity, and key dimensions of the stand.

3. PACKAGE CONTENTS

Please check that all parts are included in your package:

- Main Support Pole
- Base Plate (Solid Steel)
- VESA Mounting Plate
- Hardware Kit (various screws, washers, spacers for TV and assembly)
- Instruction Manual

4. SETUP AND ASSEMBLY

Follow these steps to assemble your VIVO Swivel Bolt-Down TV Stand:

1. **Attach the Support Pole to the Base:** Secure the main support pole to the solid steel base plate using the provided screws. Ensure the screws are tightened firmly for stability.
2. **Attach VESA Plate to your TV:** Select the appropriate screws, washers, and spacers from the hardware kit that match your TV's VESA mounting holes. Attach the VESA mounting plate to the back of your television. Ensure the plate is securely fastened and flush against the TV's surface.

3. **Mount TV onto the Support Pole:** The support pole features a keyhole pattern with multiple slots for height adjustment. Carefully lift your TV (with the attached VESA plate) and hook the VESA plate onto the desired slots on the support pole.
4. **Secure the TV:** Once the TV is hooked onto the pole, use the provided safety screws to lock the VESA plate to the support pole. This prevents accidental lifting and ensures the TV remains securely in place.
5. **Bolt-Down the Stand (Optional but Recommended for Stability):** Position the assembled stand on your desired surface. Mark the locations for the bolt-down screws through the holes in the base plate. Drill pilot holes if necessary, then secure the stand to the surface using the provided bolt-down hardware. This feature enhances stability and prevents tipping.



Figure 3: The bolt-down base provides enhanced stability when secured to a surface.




Figure 4: The VESA plate attaches to the TV and hooks onto the main support pole.

Assembly Video:

For a visual guide on assembly and features, please watch the official product video:

Video 1: Feature Video - VIVO TV Table Mount (STAND-TV00M2). This video demonstrates the assembly process and key features of the TV stand.

5. OPERATING INSTRUCTIONS

Adjusting Swivel:

The stand allows for a swivel adjustment range of -30° to $+30^{\circ}$. Gently grasp the sides of your television and rotate it to the desired viewing angle. A locking mechanism is integrated to prevent unintended movement.



Figure 5: The swivel feature allows for optimal viewing angles.

Height Adjustment:

The VESA mounting plate can be positioned at different heights along the support pole during assembly. To change the height, you will need to unmount the TV, reposition the VESA plate to a different set of keyhole slots, and then re-secure the TV.

6. CABLE MANAGEMENT

The support pole features integrated cable management openings. Route your TV's power and input cables through these openings to keep them tidy and out of sight, contributing to a clean and organized setup.



Figure 6: Cables can be routed through the support pole for a clean setup.

7. MAINTENANCE

Regularly inspect all screws and connections to ensure they remain tight and secure. Clean the stand with a soft, dry cloth. Avoid using abrasive cleaners or solvents that may damage the finish.

8. TROUBLESHOOTING

- **TV feels unstable:** Ensure all assembly screws are tightened. If using the bolt-down feature, confirm the stand is securely fastened to the surface. Verify the TV's weight does not exceed the 110 lbs capacity.
- **Difficulty swiveling:** Check for any obstructions around the base or the TV. Ensure the locking mechanism is not engaged too tightly.
- **TV is not level:** During assembly, ensure the VESA plate is correctly aligned and secured evenly on the support pole.

9. SPECIFICATIONS

- **Model:** STAND-TV00M2
- **Brand:** VIVO

- **Material:** Alloy Steel
- **Color:** Black
- **Item Weight:** 5.68 pounds
- **Package Dimensions:** 16.65 x 9.37 x 5.39 inches
- **Compatible Screen Sizes:** 23 to 43 inches
- **Weight Capacity:** 110 lbs (50 kg)
- **VESA Compatibility:** 100x100mm, 200x100mm, 200x200mm
- **Movement Type:** Swivel (-30° to +30°)
- **Mounting Type:** Tabletop Mount (Bolt-Down)
- **UPC:** 818538023671

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact VIVO customer service directly. Keep your purchase receipt for warranty claims.