

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Pure Daily Care](#) /
- › [Pure Daily Care Ultimate Aromatherapy Diffuser and Essential Oil Set Instruction Manual](#)

Pure Daily Care PDC-AD10-BNDL-JP

Pure Daily Care Ultimate Aromatherapy Diffuser and Essential Oil Set Instruction Manual

Model: PDC-AD10-BNDL-JP

[Introduction](#) [What's Included](#) [Safety Information](#) [Setup](#) [Operating](#)
[Instructions](#) [Maintenance](#) [Troubleshooting](#) [Specifications](#)

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Pure Daily Care Ultimate Aromatherapy Diffuser and Essential Oil Set. Please read this manual thoroughly before operation and retain it for future reference.

2. WHAT'S INCLUDED

Your Pure Daily Care Ultimate Aromatherapy Diffuser and Essential Oil Set includes the following components:

- 1 x Aromatherapy Diffuser (Wood Grain Finish)
- 10 x 10ml Essential Oil Bottles:
 - Lavender
 - Eucalyptus
 - Tea Tree
 - Orange
 - Peppermint
 - Lemongrass
 - Jasmine
 - Nutmeg
 - Clove
 - Spearmint
- 1 x Power Cable

- 1 x Instruction Manual



Image: The complete Pure Daily Care Ultimate Aromatherapy Diffuser set, featuring the wood grain diffuser and ten bottles of essential oils.

3. IMPORTANT SAFETY INFORMATION

- **Caution:** Avoid direct skin contact with undiluted essential oils.
- Keep the diffuser and essential oils out of reach of children and pets.
- Ensure proper ventilation in the area where the diffuser is used.
- Do not exceed the maximum water fill line to prevent malfunction.
- Place the diffuser on a stable, flat surface away from direct sunlight, heat sources, and air conditioning vents.
- Unplug the device before cleaning or refilling.
- Do not immerse the diffuser base in water or other liquids.

4. SETUP GUIDE

1. **Unpack:** Carefully remove all components from the packaging.
2. **Placement:** Place the diffuser on a flat, stable surface.
3. **Connect Power:** Connect the power cable to the diffuser's power input located at the bottom. Ensure the cable is routed through the designated channel for stability.



Image: Underside of the diffuser showing the power port and internal components, including the water tank.

4. **Remove Cover:** Gently lift the top cover of the diffuser.
5. **Fill Water Tank:** Using a measuring cup, fill the water tank with clean tap water. Do not exceed the maximum water level indicator inside the tank (400ml capacity).



Image: Cross-section view of the diffuser's water tank, highlighting the maximum fill line for proper operation.

6. **Add Essential Oils:** Add 5-10 drops of your preferred essential oil directly into the water tank. Adjust the number of drops based on desired scent intensity.



Image: A collection of the ten included essential oil bottles, ready for use with the diffuser.

7. **Replace Cover:** Securely place the top cover back onto the diffuser.
8. **Plug In:** Plug the power adapter into a wall outlet.

5. OPERATING INSTRUCTIONS

The diffuser features two control buttons: **LIGHT** and **MIST**.

5.1 Mist Control

Press the **MIST** button to cycle through the operating modes:

- **1H:** Diffuser operates for 1 hour, then automatically shuts off.
- **3H:** Diffuser operates for 3 hours, then automatically shuts off.
- **6H:** Diffuser operates for 6 hours, then automatically shuts off.
- **ON:** Diffuser operates continuously until the water level is low, then automatically shuts off.
- Press again to turn off the mist function.



Image: The diffuser actively producing mist, with the timer settings (1H, 3H, 6H, ON) illuminated on its base.

5.2 Light Control

Press the **LIGHT** button to control the LED ambient lighting:

- First press: Activates automatic color cycling through 7 ambient light modes.
- Subsequent presses: Locks the light on a specific color.
- Hold the **LIGHT** button for 2 seconds to turn off the light function.
- The light function operates independently of the mist function.

Problem	Possible Cause	Solution
No mist or weak mist	Insufficient water in tank. Water level too high. Ultrasonic plate dirty. Diffuser not placed on a flat surface.	Add water to the appropriate level. Empty some water, ensuring it's below the MAX line. Clean the ultrasonic plate as per maintenance instructions. Ensure the diffuser is on a stable, flat surface.
No power	Power cable not properly connected. No power from outlet.	Check power cable connection to diffuser and outlet. Test the outlet with another device.
Light not working	Light function is off.	Press the LIGHT button to activate or cycle through modes.

8. SPECIFICATIONS

- **Brand:** Pure Daily Care
- **Model Number:** PDC-AD10-BNDL-JP
- **Material:** BPA-free Plastic (Wood Grain Finish)
- **Power Source:** Corded Electric
- **Water Tank Capacity:** 400 ml
- **Coverage Area:** Up to 800 sq ft
- **Wattage:** 10 watts
- **Timer Settings:** 1 hour, 3 hours, 6 hours, Continuous (ON)
- **Light Modes:** 7 ambient colors with 2 intensity settings (14 combinations), independent operation.
- **Auto Shutoff:** Yes (when water level is low)
- **Product Dimensions:** Approximately 3.94"L x 3.94"W x 3.94"H
- **Item Weight:** 2.03 pounds

9. WARRANTY AND SUPPORT

For warranty information or technical support, please contact Pure Daily Care customer service. Refer to the product packaging or the official Pure Daily Care website for contact details.

Online Support: [Visit the Pure Daily Care Store on Amazon](#)