YING RAY CRMC-A790JBEZ, CRMC-A791JBEZ

YING RAY Replacement Remote Control User Manual

For Sharp Air Conditioner Models: CRMC-A790JBEZ, CRMC-A791JBEZ

Brand: YING RAY

1. Introduction

This manual provides instructions for the YING RAY replacement remote control designed for specific Sharp Air Conditioner models CRMC-A790JBEZ and CRMC-A791JBEZ. This remote control offers direct functionality without the need for programming.



Image 1: Front and back view of the YING RAY replacement remote control. The front features a digital display, mode buttons, temperature controls, fan speed, timer, and swing functions. The back shows a label indicating 'PORTABLE AIR CONDITIONER' and various mode icons like COOL, AUTO, DEHUM, HEAT, MEGA COOL, ON TIMER, AUTO FAN, and OFF TIMER.

2. Setup: Battery Installation

The remote control requires two AAA 1.5V ordinary batteries (not included). Follow these steps for proper installation:

1. Open the battery compartment cover on the back of the remote control.
2. Insert two AAA batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. Close the battery compartment cover securely.

Important Note on Battery Types:

Some AAA battery types, particularly 'Type B' in certain markets, may have a slightly shorter positive pole. If the remote does not function after battery installation, gently pull out the positive pole spring within the battery compartment slightly to ensure proper contact.



Image 2: This image provides important tips for battery usage, specifically addressing two types of AAA batteries ('A' and 'B') found in the USA & Canada market. It illustrates that 'Type B' batteries, which have a slightly shorter positive pole, may require the positive pole spring in the remote's battery compartment to be gently pulled out a little to ensure proper contact and functionality.

3. Operating Instructions

This replacement remote control is designed to work immediately with compatible Sharp Air Conditioner models without any programming required. Simply insert the batteries, and it is ready for use.

Key Functions:

- **MODE:** Cycles through various operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP. ▲/▼:** Adjusts the temperature setting. Note: Temperature display is in Celsius only.
- **FAN:** Controls the fan speed.
- **TIMER:** Sets the on/off timer for the air conditioner.

- **SWING:** Activates or deactivates the air swing function.
- **DISPLAY:** Toggles the display on the remote or AC unit.
- **CANCEL:** Cancels current timer settings or other functions.

4. Important Compatibility Information

This remote control is specifically designed as a replacement for Sharp Air Conditioner models CRMC-A790JBEZ and CRMC-A791JBEZ. It is **not a universal remote control** and may not be compatible with other Sharp AC models or other brands.




Image 3: This image compares the YING RAY replacement remote control (left) with another Sharp air conditioner remote (right). The visual comparison helps users identify if their original remote matches the design, confirming compatibility with the replacement unit. Both remotes feature similar button layouts for air conditioner functions.

5. Troubleshooting

- **Remote not responding:**
  - Ensure batteries are inserted correctly with the correct polarity (+/-).
  - Replace old batteries with new AAA 1.5V batteries.
  - Check for proper battery contact, especially if using 'Type B' batteries (refer to Section 2).
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
- **Limited functionality:**
  - Confirm your air conditioner model is one of the compatible models (CRMC-A790JBEZ, CRMC-A791JBEZ). This remote is not universal.

6. Specifications

- **Product Type:** Replacement Air Conditioner Remote Control
- **Brand:** YING RAY
- **Compatible Models:** Sharp CRMC-A790JBEZ, CRMC-A791JBEZ
- **Battery Type:** 2 x AAA 1.5V (not included)
- **Controller Type:** Button Control
- **Special Feature:** Ergonomic design
- **Display:** Celsius Only
- **Model Number (Internal):** 2018101234

7. Warranty and Support

Specific warranty details for this product are not provided in the available information. For any issues or support inquiries, please contact the seller directly through your purchase platform. Ensure to provide your order details and a clear description of the problem for efficient assistance.

© 2023 YING RAY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question