

manuals.plus /

› [Logitech](#) /

› [Logitech Crayon Digital Pencil User Manual](#)

Logitech 914-000033

Logitech Crayon Digital Pencil User Manual

Model: 914-000033

Brand: Logitech

PRODUCT OVERVIEW

The Logitech Crayon is a pixel-precise digital pencil designed for all iPads (2018 releases and later). It leverages Apple Pencil technology to provide a natural and intuitive writing and drawing experience. Its robust design, anti-roll shape, and dynamic smart tip make it a versatile tool for creativity and productivity.



Figure 1: Logitech Crayon Digital Pencil in Orange.

WHAT'S IN THE BOX

- Logitech Crayon Digital Pencil
- 1-Year Limited Hardware Warranty

Note: Charging cable (Lightning) is not included and must be supplied by the user.

CRAYON

Digital pencil
Digitaler Stift
Crayon numérique

iPad (6th generation)



logitech®



Figure 2: Logitech Crayon packaging, showing the digital pencil.

KEY FEATURES

- **Compatibility:** Designed for any iPad (2018 releases or later) with iOS updated to 12.2 and above.
- **Apple Pencil Technology:** Utilizes Apple Pencil technology for natural writing and drawing, including Scribble for handwriting-to-text conversion.
- **Dynamic Smart Tip:** Allows for automatic line weight adjustment by simply tilting the Crayon.
- **Instant Connection:** Connects to iPad instantly upon power-on, requiring no complex device pairing.
- **Wide App Support:** Delivers precise and fast input with hundreds of Apple Pencil supported applications.
- **Durable Design:** Built tough with 4 ft drop protection and a unique roll-proof shape.
- **Long Battery Life:** Provides up to 7.5 hours of active writing time on a single charge.
- **Palm Rejection Technology:** Enables users to rest their hand on the screen comfortably while writing or drawing without interference.

SETUP

1. Charging the Logitech Crayon

The Logitech Crayon uses a standard Lightning connector for charging. To charge, remove the orange cap at the top of the Crayon to reveal the Lightning port. Insert a Lightning cable (not included) into the port and connect it to a power source. A full charge provides up to 7.5 hours of active writing time.




7.5 HOURS BATTERY LIFE

With quick charge feature

Figure 3: Charging port located at the top of the Logitech Crayon.

2. Powering On and Pairing

The Logitech Crayon connects to your compatible iPad instantly. Simply press the power button located near the charging port (Figure 4). No complex Bluetooth pairing is required. Ensure your iPad's iOS is updated to 12.2 or above for optimal performance.



NO PAIRING. PRESS ON.
Draw from iPad to iPad

Figure 4: Power button on the Logitech Crayon for instant connection.

OPERATING INSTRUCTIONS

Writing and Drawing

The Logitech Crayon offers pixel-precise input, making it ideal for notes, sketches, and annotations. Its fast responsiveness ensures a fluid experience, similar to using a traditional pen and paper.




PRECISE AND RESPONSIVE

Figure 5: Logitech Crayon in use for precise and responsive drawing on an iPad.

Apple Pencil Technology Integration

The Crayon utilizes Apple Pencil technology, allowing for seamless integration with compatible iPad apps. This includes features like Scribble, which converts your handwriting to text.




USES APPLE PENCIL® TECHNOLOGY

Figure 6: Demonstrating the use of Apple Pencil technology with Logitech Crayon.

Tilt Functionality

To achieve thicker or thinner lines, simply tilt the Logitech Crayon. The smart tip automatically adjusts the line weight based on the angle of the Crayon, providing dynamic control over your strokes.



TILT FOR THICKER OR THINNER LINES

Figure 7: Illustrating the tilt feature for varying line thickness.

Palm Rejection

The integrated palm rejection technology allows you to rest your hand naturally on the iPad screen while using the Crayon, preventing unintended marks or interactions from your palm.



PALM REJECTION TECHNOLOGY

For comfortable drawing

Figure 8: Palm rejection in action, allowing comfortable drawing.

Official Product Video

Your browser does not support the video tag.

Video 1: Official Logitech Crayon Product Video, demonstrating key features and usage scenarios.

MAINTENANCE

To ensure the longevity and optimal performance of your Logitech Crayon, keep the tip clean and free from debris. Replacement tips are available from Logitech if the original tip becomes worn or damaged. Store the Crayon in a safe place to prevent physical damage.

TROUBLESHOOTING

Crayon Not Responding:

- Ensure the Crayon is charged. Connect it to a Lightning cable and power source.
- Verify the Crayon is powered on by pressing the power button. The indicator light should be green.
- Check your iPad's compatibility. The Crayon works with iPads (2018 releases and later) running iOS 12.2 or above.
- Ensure Bluetooth is enabled on your iPad, even though direct pairing is not required, some background services may rely on it.
- Restart your iPad.

Inaccurate or Lagging Input:

- Clean the Crayon tip and your iPad screen.
- Ensure no other styluses are connected or interfering with the iPad.
- Update your iPad's iOS to the latest version.

SPECIFICATIONS

Attribute	Detail
Brand	Logitech
Model Number	914-000033
Color	Orange
Item Weight	1.6 ounces
Product Dimensions	0.3 x 0.4 x 6.4 inches
Material	Polycarbonate/Acrylonitrile Butadiene Styrene (PC/ABS), Aluminum
Battery Type	1 Lithium Polymer battery (included)
Battery Life (Active)	Up to 7.5 Hours
Compatible Devices	iPad (2018 releases and later), iOS 12.2+

WARRANTY AND SUPPORT






The Logitech Crayon comes with a 1-Year Limited Hardware Warranty. For detailed warranty information or

additional support, please refer to the official Logitech website or the user guide available for download.

Official User Guide (PDF): [Download Here](#)

© 2024 Logitech. All rights reserved.

Related Documents - 914-000033

	<p>Logitech Crayon: Precision Digital Pencil for iPad</p> <p>Explore the Logitech Crayon, a pixel-precise digital pencil designed for iPads, featuring Apple Pencil technology, Scribble support, and palm rejection for enhanced creativity and productivity. Includes setup, technical specifications, and system requirements.</p>
	<p>Logitech Crayon FAQs and Troubleshooting Guide</p> <p>Frequently asked questions and troubleshooting tips for the Logitech Crayon digital pencil, covering setup, battery, charging, compatibility, and usage with iPads.</p>
	<p>Logitech Crayon Setup Guide</p> <p>A comprehensive setup guide for the Logitech Crayon digital pencil, detailing product setup, software updates, usage instructions, charging procedures, LED indicator meanings, product components, replaceable parts, and essential care and storage tips.</p>
	<p>Logitech Crayon Setup Guide for Schools</p> <p>A comprehensive setup and usage guide for the Logitech Crayon digital pen, designed for educational institutions, covering product setup, software updates, charging, maintenance, and troubleshooting.</p>
	<p>Logitech Combo Touch & Crayon User Manuals</p> <p>Detailed user guides for the Logitech Combo Touch keyboard case and Logitech Crayon digital pencil, covering setup, features, compatibility, and care for various iPad models.</p>

LOGITECH CRAYON
Setup Guide



logitech

[Logitech Crayon Setup Guide: Connect and Use Your Digital Pen](#)

Learn how to set up, use, and charge your Logitech Crayon digital pen for compatible iPads. Includes troubleshooting tips and care instructions.