

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [CLP](#) /

› [CLP Sanka I Fabric Rocking Chair Instruction Manual](#)

CLP Sanka I

CLP Sanka I Fabric Rocking Chair Instruction Manual

Model: Sanka I

INTRODUCTION

Thank you for choosing the CLP Sanka I Fabric Rocking Chair. This manual provides essential information for the safe assembly, operation, and maintenance of your new rocking chair. Please read these instructions carefully before assembly and retain them for future reference.

SAFETY INFORMATION

- Ensure all components are securely fastened before use.
- Do not exceed the maximum weight capacity of 136 kg (approximately 300 lbs).
- Keep small parts away from children during assembly to prevent choking hazards.
- Use the chair on a flat, stable surface to prevent tipping.
- Avoid standing on the chair or using it as a step stool.

PACKAGE CONTENTS

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Chair Seat and Backrest Assembly (1)
- Metal Frame (1)
- Wooden Rocking Runners (2)
- Hardware Pack (screws, washers, Allen key)

SETUP AND ASSEMBLY

The CLP Sanka I Rocking Chair requires partial assembly. Follow these steps carefully:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.

2. Attach the metal frame to the underside of the chair seat and backrest assembly using the provided screws. Ensure the frame is oriented correctly.
3. Securely fasten the wooden rocking runners to the bottom of the metal frame using the remaining hardware. Ensure the runners are aligned properly for smooth rocking motion.
4. Tighten all screws with the included Allen key. Do not overtighten.
5. Once assembled, gently test the chair for stability and rocking motion before full use.



Image: Assembly components and tools, including an Allen key and an instruction manual icon, indicating the partial assembly required for the rocking chair.




Image: A detailed view of the rocking chair's base, showing the sturdy metal frame connected to the beech wood runners, designed for smooth and stable rocking.

OPERATING INSTRUCTIONS

The CLP Sanka I Rocking Chair is designed for comfortable relaxation. To use your chair:

- Sit centrally on the seat, ensuring your weight is evenly distributed.
- Gently push off with your feet to initiate the rocking motion.
- The ergonomic design and padded seat provide a comfortable and relaxing experience.



Image: An illustration demonstrating the gentle rocking motion of the CLP Sanka I chair, highlighting its ergonomic design for relaxation.

MAINTENANCE AND CARE

Proper care will extend the life of your rocking chair:

- **Fabric Upholstery:** Regularly vacuum the fabric surface using an appropriate upholstery attachment to remove dust and debris. For spills, gently blot with a clean, damp cotton cloth. Do not use harsh household detergents or abrasive cleaners.
- **Metal Frame and Wooden Runners:** Wipe clean with a soft, damp cloth. Avoid using chemical cleaners that may damage the finish.
- **General:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.



Image: An icon depicting a hand wiping a surface with a cloth, symbolizing the recommended cleaning method for the chair's fabric upholstery.

TROUBLESHOOTING

- **Chair feels unstable:** Ensure all screws are fully tightened. Check that the chair is on a level surface.
- **Difficulty during assembly:** Review the assembly steps carefully. Ensure all parts are oriented correctly before tightening screws. If parts do not align, re-check the instructions for proper placement.
- **Squeaking during rocking:** Check all connections for tightness. A small amount of lubricant on metal-to-metal contact points (if accessible and safe) may help, but consult customer support if the issue persists.

SPECIFICATIONS

Feature	Specification
Brand	CLP

Feature	Specification
Model Number	Sanka I (152484501)
Overall Height	98 cm (38.6 inches)
Overall Width	71 cm (28 inches)
Overall Depth	88 cm (34.6 inches)
Seat Height	48 cm (18.9 inches)
Armrest Height (from floor)	58 cm (22.8 inches)
Maximum Load Capacity	136 kg (300 lbs)
Weight	16 kg (35.3 lbs)
Material (Frame)	Metal
Material (Runners)	Beech Wood
Material (Upholstery)	Fabric (100% Polyester)
Color	Black



Image: A visual representation of the CLP Sanka I Rocking Chair with key dimensions labeled, including height, width, depth, and seat height.

WARRANTY AND SUPPORT

Information regarding product warranty and customer support is not available in the provided data. Please refer to your purchase documentation or contact the retailer for details on warranty coverage and support options.