
[Manuals.plus](#) /

› [Dell](#) /

› Dell UltraSharp U2719D 27-inch QHD Monitor User Manual

Dell U2719D

Dell UltraSharp U2719D 27-inch QHD Monitor User Manual

This manual provides detailed instructions for setting up, operating, maintaining, and troubleshooting your Dell UltraSharp U2719D monitor.

1. PRODUCT OVERVIEW

The Dell UltraSharp U2719D is a 27-inch Quad HD (2560 x 1440) monitor designed for clear visual performance. It features a slim design, multiple connectivity options, and ergonomic adjustments for enhanced user comfort.



Figure 1: Front view of the Dell UltraSharp U2719D monitor, showcasing its slim bezels and adjustable stand.

2. SETUP INSTRUCTIONS

2.1 Unpacking the Monitor

Carefully remove all components from the packaging. Ensure all items listed in the packing slip are present. Retain the packaging for future transport or service needs.

2.2 Assembling the Stand

1. Place the monitor panel face down on a soft, clean cloth to prevent scratches.
2. Attach the stand riser to the monitor panel until it clicks into place.
3. Attach the stand base to the stand riser and tighten the captive screw.

2.3 Connecting the Cables

Connect the necessary cables to the monitor and your computer. The Dell U2719D supports various connectivity options.



Figure 2: Rear view of the Dell U2719D monitor, showing the power input, HDMI, DisplayPort, and USB ports for connectivity.

- **Power Cable:** Connect the power cable to the monitor's power port and then to a power outlet.
- **Video Cable:** Connect either an HDMI or DisplayPort cable from your computer's video output to the corresponding input on the monitor. The monitor supports DisplayPort and HDMI connectivity.
- **USB Upstream Cable:** Connect the USB upstream cable from your computer to the monitor's USB upstream port to enable the monitor's USB 3.0 downstream ports.

3. OPERATING THE MONITOR

3.1 Power On/Off

Press the power button located on the bottom right bezel of the monitor to turn it on or off. The power LED indicates the monitor's status.

3.2 On-Screen Display (OSD) Menu

The OSD menu allows you to adjust various monitor settings. Use the control buttons located on the bottom right of the monitor to navigate the menu.

- Press any control button to activate the OSD menu.
- Use the navigation buttons to scroll through options.
- Press the select button to enter a sub-menu or confirm a selection.
- Press the exit button to go back or exit the OSD menu.

3.3 Input Source Selection

If multiple video sources are connected, you can switch between them using the OSD menu or a dedicated input select button (if available).

3.4 Adjusting Display Settings

Within the OSD menu, you can adjust settings such as:

- **Brightness/Contrast:** Adjust the overall luminance and difference between light and dark areas.
- **Color Settings:** Select preset modes (e.g., Standard, Movie, Game, Custom Color) or fine-tune RGB values.
- **Aspect Ratio:** Choose between Wide 16:9 or other aspect ratio modes.

3.5 Using USB Ports

The monitor features multiple USB 3.0 downstream ports for connecting peripherals like keyboards, mice, and USB drives. Ensure the USB upstream cable is connected from your computer to the monitor.



Figure 3: Dell U2719D monitor connected to a keyboard and mouse, demonstrating its integrated USB hub functionality.

3.6 Ergonomic Adjustments

The monitor stand allows for various adjustments to optimize your viewing experience:

- **Height Adjustment:** Raise or lower the monitor to eye level.
- **Tilt:** Adjust the screen angle forward or backward.
- **Swivel:** Rotate the monitor left or right on its base.
- **Pivot:** Rotate the screen 90 degrees to switch between landscape and portrait orientation.



Figure 4: The Dell U2719D monitor shown in landscape, tilted, and portrait (pivoted) orientations, highlighting its ergonomic flexibility.

4. MAINTENANCE

4.1 Cleaning the Monitor

- Always unplug the monitor before cleaning.
- Use a soft, lint-free cloth lightly dampened with water or a non-abrasive screen cleaner.
- Avoid using harsh chemicals, abrasive cleaners, or spraying liquid directly onto the screen.
- Wipe the screen gently to remove dust and smudges.

4.2 General Care

- Avoid placing heavy objects on the monitor or its cables.
- Do not expose the monitor to extreme temperatures or humidity.
- Ensure adequate ventilation around the monitor.

5. TROUBLESHOOTING

If you encounter issues with your monitor, refer to the following common solutions:

Problem	Possible Solution
No image on screen	Ensure power cable is securely connected. Check video cable connection to both monitor and computer. Verify correct input source is selected via OSD.
Image is blurry or distorted	Check display resolution settings on your computer. Ensure it is set to the native resolution of 2560 x 1440. Reconnect video cable.
Flickering screen	Check video cable connection. Ensure graphics card drivers are up to date. Adjust refresh rate in display settings.
USB ports not working	Ensure the USB upstream cable is connected from the monitor to your computer. Check computer's USB drivers.

For further assistance, please refer to the Dell support website or contact customer service.

6. SPECIFICATIONS

Key technical specifications for the Dell UltraSharp U2719D monitor:

Feature	Detail
Brand	Dell
Model Name	U2719D
Screen Size	27 Inches
Resolution	QHD Wide 1440p (2560 x 1440)
Aspect Ratio	16:9
Display Type	LCD with LED backlight (IPS Technology)
Refresh Rate	60 Hz <i>(Note: Some product listings may incorrectly state 240Hz. The U2719D typically operates at 60Hz for its native resolution.)</i>
Response Time	5 Milliseconds (GtG)
Brightness	350 cd/m2
Contrast Ratio	1000:1
Viewing Angle	178 Degrees (Horizontal/Vertical)
Connectivity	HDMI, DisplayPort, USB 3.0 (1 Upstream, 4 Downstream)
Item Weight	5.51 Kilograms (monitor only)

Feature	Detail
Color	Black



Figure 5: Diagram illustrating the approximate dimensions of the Dell U2719D monitor, including screen size and depth.

7. WARRANTY AND SUPPORT

The Dell UltraSharp U2719D monitor comes with a manufacturer's warranty. Please refer to your purchase documentation for specific warranty terms and duration.

- **Warranty:** This product typically includes a 2-year manufacturer warranty.
- **Support:** 24/7 support is available. For technical assistance, driver downloads, or service requests, visit the official Dell Support website: www.dell.com/support

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question