Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-OE1

Joyroom JR-OE1 Bluetooth Headphones User Manual

Model: JR-OE1 | Reference: 70467

Introduction

Thank you for choosing the Joyroom JR-OE1 Bluetooth Headphones. This manual provides detailed instructions on how to set up, operate, and maintain your new headphones to ensure optimal performance and longevity. Please read this manual carefully before using the product and retain it for future reference.

Package Contents

Upon unboxing, please verify that all the following items are included:

- Joyroom JR-OE1 Bluetooth Headphones (Left and Right)
- Charging Case
- USB Charging Cable
- User Manual




Image: Contents of the Joyroom JR-OE1 package, showing the headphones, their charging case, a USB charging cable, and the instruction manual.

Product Overview

Familiarize yourself with the components of your Joyroom JR-OE1 Bluetooth Headphones.



Image: The Joyroom JR-OE1 Bluetooth Headphones, featuring an open-ear design, resting within their sleek charging case.

Headphone Components:

- **Ear Hook:** Designed for secure and comfortable fit over the ear.
- **Speaker Unit:** Delivers audio output.
- **Microphone:** For voice calls and commands.
- **Touch Control Area:** For managing playback, calls, and voice assistant.
- **Charging Contacts:** For charging the headphones within the case.

Charging Case Components:

- **Charging Port:** USB-C port for connecting the charging cable.
- **LED Indicator:** Shows charging status and battery level.
- **Headphone Slots:** Securely holds and charges the headphones.

Setup

1. Charging the Headphones and Case

1. Place the headphones into the charging case, ensuring they are properly seated.
2. Connect the USB charging cable to the charging port on the case and to a suitable USB power adapter (not included).
3. The LED indicator on the charging case will illuminate to show charging status. A full charge typically takes approximately 1.5 to 2 hours for the case and headphones.
4. Once fully charged, the LED indicator will change or turn off, depending on the model. Disconnect the charging cable.

2. Bluetooth Pairing

1. Ensure the headphones are charged. Open the charging case. The headphones will automatically enter pairing mode, and their indicator lights will flash (e.g., blue and red alternately).
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices. Select "JR-OE1" from the list.
4. Once connected, the headphone indicator lights will stop flashing and may turn off or show a steady blue light. A voice prompt may confirm "Connected".
5. If pairing fails, turn off Bluetooth on your device, place the headphones back in the case, close the case, then reopen and repeat the steps.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, or take the headphones out of the case. They will power on automatically.
- **Power Off:** Place the headphones back into the charging case and close the lid. They will power off automatically.

Music Playback

- **Play/Pause:** Tap the touch control area on either headphone once.
- **Next Track:** Double-tap the touch control area on the right headphone.
- **Previous Track:** Double-tap the touch control area on the left headphone.
- **Volume Up:** Triple-tap the touch control area on the right headphone.
- **Volume Down:** Triple-tap the touch control area on the left headphone.

Call Management

- **Answer/End Call:** Tap the touch control area on either headphone once.
- **Reject Call:** Press and hold the touch control area on either headphone for 2 seconds.

Voice Assistant

- **Activate Voice Assistant:** Press and hold the touch control area on either headphone for 3 seconds.

Maintenance

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the headphones and charging case. Do not use abrasive cleaners, alcohol, or chemical solvents.
- **Storage:** When not in use, store the headphones in their charging case to protect them from dust and damage. Store in a cool, dry place.

- **Battery Care:** To prolong battery life, avoid fully discharging the headphones and charging case frequently. Charge them regularly, even if not in use for extended periods.
- **Water Resistance:** The Joyroom JR-OE1 headphones are designed for daily use and may have some sweat or splash resistance. However, they are not waterproof. Avoid submerging them in water or exposing them to heavy rain.

Troubleshooting

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones and charging case fully.
Cannot pair with device.	Bluetooth is off on device; headphones not in pairing mode; interference.	Ensure Bluetooth is enabled. Place headphones in case, close, then reopen to re-enter pairing mode. Move closer to the device. Forget "JR-OE1" from your device's Bluetooth list and try pairing again.
No sound or intermittent sound.	Volume too low; out of Bluetooth range; connection issue.	Increase volume on both headphones and device. Ensure headphones are within 10 meters of the device. Reconnect the headphones.
Microphone not working.	Microphone blocked; device settings.	Ensure microphone is not covered. Check your device's audio input settings to confirm "JR-OE1" is selected.

Specifications

- **Model:** JR-OE1
- **Brand:** JOYROOM
- **Connectivity:** Bluetooth
- **Color:** Multicolore (Rose)
- **Manufacturer:** Joyroom
- **Country of Origin:** China
- **Reference Number:** 70467
- **Age Range (Description):** Adult
- **Number of Items:** 1

Warranty and Support

Joyroom products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your purchase or visit the official Joyroom website. Please retain your proof of purchase for any warranty claims.
Official Website: www.joyroom.com

© 2023 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JH7XQX4

More documents and user manuals: **https://manuals.plus/**