

CLP Sanka

CLP Sanka Rocking Chair Instruction Manual

INTRODUCTION

This manual provides comprehensive instructions for the assembly, safe operation, and maintenance of your CLP Sanka Rocking Chair. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product.

SAFETY INFORMATION

WARNING:

- Do not exceed the maximum load capacity of 136 kg (299 lbs).
- Ensure the chair is correctly assembled and maintained to prevent accidents.
- Use only the provided assembly accessories and follow the assembly instructions precisely.
- Keep children and pets away from the assembly area.
- Periodically check all screws and connections to ensure they remain tight.

PACKAGE CONTENTS

Your CLP Sanka Rocking Chair package includes the following components:

- Chair seat and backrest assembly (partially pre-assembled)
- Rocking base frame (metal and wood runners)
- Assembly tools (e.g., Allen key)
- Fasteners (screws, bolts, washers)
- Instruction sheet

Before beginning assembly, verify that all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.



Image: Illustration showing the chair base, assembly tools (Allen key), and an instruction manual icon, indicating included components for assembly.

ASSEMBLY INSTRUCTIONS

The CLP Sanka Rocking Chair arrives partially assembled. Follow these steps carefully for complete assembly:

1. **Unpack Components:** Carefully remove all components from the packaging. Place them on a soft, clean surface to prevent scratches.
2. **Identify Parts:** Refer to the included instruction sheet to identify each component and fastener.
3. **Attach Rocking Base:** Align the metal frame of the rocking base with the pre-drilled holes on the underside of the chair seat. Insert the provided screws and tighten them securely using the supplied tool. Ensure all connections are firm but do not overtighten.
4. **Check Stability:** Once assembled, gently rock the chair to ensure all connections are stable and the chair functions correctly.

Note:

- Assembly may be easier with two people.
- Do not force any parts together. If components do not fit, re-check the alignment and instructions.



Image: A detailed view of the rocking chair's base, highlighting the connection between the wooden runners and the black metal frame, indicating the assembly point.

OPERATING INSTRUCTIONS

The CLP Sanka Rocking Chair is designed for comfortable relaxation and gentle rocking motion.

- **Seating:** Sit centrally on the chair, ensuring your weight is evenly distributed.
- **Rocking Motion:** Gently push off with your feet to initiate a smooth rocking motion. Avoid excessive force or sudden movements.
- **Placement:** Place the chair on a flat, stable surface. Ensure there is sufficient space around the chair for safe rocking without hitting walls or other furniture.



Image: The CLP Sanka Rocking Chair shown in motion, with a blue arrow indicating the backward rocking movement, illustrating its primary function.

MAINTENANCE

Proper care will extend the life and appearance of your rocking chair.

- **Fabric Cleaning:** For general cleaning, use a soft cotton cloth dampened with lukewarm water. For light dirt, a damp cotton cloth is sufficient.
- **Vacuuming:** When using a vacuum cleaner, use only appropriate nozzles designed for upholstery to avoid damaging the fabric.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, solvents, or harsh chemicals, as these can damage the fabric and frame.
- **Frame Care:** Wipe the wooden and metal parts with a dry or slightly damp cloth.
- **Regular Inspection:** Periodically check all screws and connections for tightness and re-tighten if necessary.




Image: A graphic showing a hand wiping a surface, symbolizing the cleaning instructions for the chair's fabric upholstery.

SPECIFICATIONS

Feature	Detail
Brand	CLP
Model Name	Sanka
Overall Height	98 cm (38.6 inches)
Overall Width	71 cm (28 inches)
Overall Depth	88 cm (34.6 inches)
Seat Height	48 cm (18.9 inches)
Seat Dimensions (WxD)	62 x 55 cm (24.4 x 21.7 inches)
Backrest Height	64 cm (25.2 inches)

Armrest Height (from floor)	58 cm (22.8 inches)
Maximum Load Capacity	136 kg (299 lbs)
Product Weight	16 kg (35.3 lbs)
Upholstery Material	100% Polyester Fabric
Frame Material	Wood, Metal
Assembly Required	Yes
Recommended Use	Indoor, Reading, Relaxation



Image: Technical drawing illustrating the key dimensions of the CLP Sanka Rocking Chair, including total height, width, depth, seat height, and backrest height.

TROUBLESHOOTING

If you encounter issues during assembly or use, refer to the following common solutions:

- **Misaligned Holes:** If screw holes do not align, slightly loosen other already tightened screws to allow for minor adjustments. Ensure the components are oriented correctly according to the instructions. Sometimes, applying gentle pressure or wiggling the parts can help align them.
- **Missing or Damaged Parts:** If any parts are missing or damaged upon arrival, do not attempt to force assembly. Contact CLP customer support immediately for replacement parts.
- **Chair Instability:** Ensure all screws are fully tightened. Check that the chair is placed on a level surface. If the issue persists, disassemble and reassemble, paying close attention to each connection.

WARRANTY AND SUPPORT

For warranty information, replacement parts, or further assistance, please contact CLP customer support.
Keep your purchase receipt as proof of purchase.

Contact information can typically be found on the product packaging or the retailer's website where the product was purchased.