

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [SoBuy](#) /

› [SoBuy FWT31-W Corner Desk with Drawer Instruction Manual](#)

SoBuy FWT31-W

SoBuy FWT31-W Corner Desk with Drawer Instruction Manual

Brand: SoBuy | Model: FWT31-W

INTRODUCTION

Thank you for choosing the SoBuy FWT31-W Corner Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.

SAFETY INFORMATION

- Always assemble the desk on a soft, clean surface to prevent scratches.
- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Use only the provided hardware. Substituting parts may compromise the desk's stability and safety.
- Do not overtighten screws, as this can damage the material.
- Keep small parts away from children during assembly to avoid choking hazards.
- Place the desk on a level surface to prevent tipping.
- Do not exceed the maximum load capacity of 75 kg (165 lbs).

PACKAGE CONTENTS

Before assembly, verify that all components listed in the packing list are present. All parts are numbered for easy identification.




Image: Detailed diagram illustrating the dimensions and various components of the SoBuy FWT31-W corner desk.

If any parts are missing or damaged, please contact customer support for assistance.

SETUP AND ASSEMBLY

The SoBuy FWT31-W corner desk is designed for easy self-assembly. Follow the illustrated instructions provided in the package. It is recommended to have two people for assembly to ensure stability and ease of handling.

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface. Check against the parts list.
2. **Assemble Frame:** Begin by attaching the main support legs to the desk frame using the designated screws and connectors. Ensure all connections are secure but do not fully tighten yet.
3. **Install Shelves:** Attach the two lower shelves to the frame. These shelves provide additional storage space.
4. **Attach Drawer Slides:** Secure the drawer slides to the desk frame according to the instructions.
5. **Assemble Drawer:** Construct the drawer box and attach the drawer front with the handle.
6. **Insert Drawer:** Carefully slide the assembled drawer into the installed drawer slides.
7. **Final Tightening:** Once all components are in place, gently tighten all screws and fasteners. Do not overtighten.
8. **Position Desk:** Move the assembled desk to its desired corner location.



Image: The SoBuy FWT31-W corner desk fully assembled and placed in a room, showcasing its compact design.

OPERATING AND USAGE

The SoBuy FWT31-W corner desk is designed for versatile use in various settings such as offices, kitchens, bedrooms, living rooms, or studios. Its corner design optimizes space utilization.

- **Work Surface:** Use the spacious tabletop for your computer, books, or other work essentials.
- **Drawer Storage:** The integrated drawer provides convenient storage for stationery, documents, or personal items, keeping your workspace tidy.



Image: A close-up view of the desk's drawer pulled open, showing various office supplies and personal items neatly stored inside.

- **Lower Shelves:** Utilize the two shelves below the tabletop for additional storage of books, decorative items, or storage boxes.



Image: A detailed shot of the lower shelf of the desk, featuring a white storage box placed on it.

- **Weight Distribution:** Distribute weight evenly across the desk surface and shelves to maintain stability.

MAINTENANCE

Proper care will extend the life and appearance of your SoBuy FWT31-W desk.

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the lacquered finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the wood material.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary, but do not overtighten.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration of the finish.
- **Heat Protection:** Use coasters or protective pads under hot items to prevent heat damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Screws are loose; desk is on an uneven surface.	Check and tighten all screws. Move the desk to a level surface or use shims under the legs.
Drawer does not slide smoothly.	Drawer slides are misaligned or obstructed.	Ensure drawer slides are correctly installed and free of debris. Apply a silicone-based lubricant if needed.
Scratches or marks on the surface.	Sharp objects or abrasive cleaning.	Use furniture polish or touch-up pens for minor scratches. Avoid placing sharp objects directly on the surface.

SPECIFICATIONS

Model: FWT31-W

Brand: SoBuy

Color: White

Material: Engineered Wood (MDF with white lacquered finish)

Dimensions (L x W x H): 76 cm x 76 cm x 76 cm (29.9 x 29.9 x 29.9 inches)

Product Weight: 19 kg (41.9 lbs)

Maximum Load Capacity: 75 kg (165 lbs)

Features: 1 Drawer, 2 Shelves, Space-saving Corner Design

WARRANTY AND SUPPORT

SoBuy products are designed for quality and durability. If you encounter any issues with your FWT31-W desk, or if you are not satisfied with the product, please contact SoBuy customer support.

For returns or product problems, you may be eligible for a free return voucher. Please refer to your purchase documentation or contact the seller directly for specific warranty terms and support procedures.

Contact Information: Please refer to the contact details provided with your purchase or visit the official SoBuy website for support.