Noritz LP0157

NORITZ Cook Box Wide Grill Plate Set LP0157 Instruction Manual

Model: LP0157

1. Introduction

Thank you for purchasing the NORITZ Cook Box Wide Grill Plate Set, model LP0157. This set is designed to enhance your grilling experience by providing a dedicated grill plate and an oil splatter guard, specifically for use with NORITZ Piatt series gas ranges. The oil splatter guard is engineered to reduce oil splatter inside your grill by up to 99.9%, making cleanup significantly easier. Please read this manual thoroughly before use to ensure safe and optimal performance.

2. Safety Information

Always follow basic safety precautions when using kitchen appliances to reduce the risk of fire, electric shock, personal injury, or property damage.

- **Compatibility:** This Cook Box is designed for specific NORITZ Piatt series gas ranges.**Verify compatibility with your gas range on the manufacturer's website before use.** Using it with an incompatible model may cause damage or unsafe conditions.
- **Hot Surfaces:** The grill plate and oil splatter guard will become extremely hot during and after use. Always use oven mitts or heat-resistant gloves when handling.
- **Placement:** Ensure the Cook Box is correctly seated in the grill compartment before starting the cooking process.
- **Cleaning:** Allow components to cool completely before cleaning. Refer to the "Maintenance and Cleaning" section for proper cleaning procedures.
- **Supervision:** Do not leave the grill unattended while cooking.
- **Ventilation:** Ensure adequate ventilation when using your gas grill.

3. Package Contents

The NORITZ Cook Box Wide Grill Plate Set LP0157 includes the following components:

- **Wide Grill Plate (LP0151):** Designed for even cooking and easy food release.
- **Oil Splatter Guard (LP0152):** Helps contain oil splatter within the grill compartment.



Image of the Noritz Cook Box Wide Grill Plate Set, showing the grill plate and the oil splatter guard components.

4. Setup

Before first use, wash all components with warm, soapy water and dry thoroughly.

1. **Check Compatibility:** Confirm that your NORITZ gas range is a Piatt series model compatible with the LP0157 Cook Box. Refer to your gas range manual or the NORITZ website for details.
2. **Assemble the Cook Box:** Place the oil splatter guard (LP0152) into the grill compartment of your gas range. Then, place the wide grill plate (LP0151) inside the oil splatter guard. Ensure both components are securely seated.
3. **Pre-heating:** For best results, pre-heat the Cook Box inside the grill compartment according to your recipe or gas range instructions.

5. Operating Instructions

Using the NORITZ Cook Box is straightforward. Always refer to your gas range's instruction manual for specific grilling functions and temperature settings.

1. **Prepare Food:** Place your food directly onto the wide grill plate. Avoid overcrowding to ensure even cooking.
2. **Insert into Grill:** Carefully slide the assembled Cook Box (with food) into the grill compartment of your compatible NORITZ gas range.
3. **Grill:** Close the grill door and set your gas range to the desired grilling temperature and time. The oil splatter guard will help keep the grill interior cleaner during cooking.
4. **Remove Food:** Once cooking is complete, use oven mitts or heat-resistant gloves to carefully remove the Cook Box from the grill. Transfer food to a serving dish.

5. **Cool Down:** Allow the Cook Box components to cool completely before attempting to clean them.

6. Maintenance and Cleaning

Regular cleaning will prolong the life of your Cook Box and maintain its performance.

- **Cool Down:** Always ensure the grill plate and oil splatter guard have cooled down completely before handling or cleaning.
- **Washing:** Wash both the grill plate and oil splatter guard with warm water and a mild dish soap. Use a soft sponge or cloth to avoid scratching the surface. For stubborn food residues, soak the components in warm, soapy water for a period before cleaning.
- **Rinsing:** Rinse thoroughly with clean water to remove all soap residue.
- **Drying:** Dry immediately with a soft cloth to prevent water spots and ensure longevity.
- **Do Not Use:** Avoid using abrasive cleaners, steel wool, or harsh chemicals, as these can damage the surface finish.

7. Troubleshooting

If you encounter issues with your NORITZ Cook Box, consider the following common solutions:

- **Food Sticking:** Ensure the grill plate is clean and properly pre-heated. A small amount of cooking oil can be applied to the grill plate before placing food, if appropriate for your recipe.
- **Uneven Cooking:** Verify that the Cook Box is correctly positioned within the grill compartment. Ensure the grill is pre-heated evenly. Avoid overloading the grill plate.
- **Excessive Smoke:** This can occur if there is accumulated grease or food residue in the grill compartment or on the Cook Box components. Ensure all parts are clean before use.
- **Difficulty Cleaning:** For baked-on residue, soak the components in hot, soapy water for an extended period (e.g., 30 minutes to an hour) before scrubbing gently.

If problems persist, consult your NORITZ gas range manual or contact NORITZ customer support.

8. Specifications

Feature	Specification
Model Number	LP0157
Components	Wide Grill Plate (LP0151), Oil Splatter Guard (LP0152)
Dimensions (L x W x H)	27.1 cm x 20.9 cm x 4.5 cm
Material	Aluminum

Feature	Specification
Color	Silver
Compatibility	NORITZ Piatt Series Gas Ranges (verify specific model)

9. Warranty and Support

For warranty information, product registration, or technical support, please refer to the official NORITZ website or contact NORITZ customer service directly. Keep your purchase receipt as proof of purchase.

NORITZ Official Website: www.noritz.co.jp

Please note that warranty terms and conditions may vary by region and product.

© 2024 NORITZ Corporation. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question