



Manuals.plus /

› DollaTek /

› DollaTek L2 R2 Trigger and Spring Replacement Kit for PS4 Controller Instruction Manual

DollaTek PS4 L2 R2 Trigger Replacement Kit

DollaTek L2 R2 Trigger and Spring Replacement Kit for PS4 Controller

Instruction Manual

INTRODUCTION

This manual provides instructions for installing the DollaTek L2 R2 Trigger and Spring Replacement Kit for your PS4 controller. This kit is designed to replace worn or damaged L2 and R2 trigger buttons and their corresponding springs, restoring the original functionality of your controller. Please read all instructions carefully before beginning the installation process.

WHAT'S INCLUDED

The DollaTek L2 R2 Trigger and Spring Replacement Kit includes the following components:

- 5 Pairs of L2 R2 Trigger Gamepad Buttons for PS4 controller
- 5 Pairs of L2 R2 Trigger Springs for PS4 controller



Image: Contents of the DollaTek L2 R2 Trigger and Spring Replacement Kit, showing multiple sets of black L2 and R2 buttons along with their metal springs.



Image: A top-down view of the ten L2 and R2 trigger buttons, clearly labeled, alongside the ten small metal springs.

SETUP AND INSTALLATION

Replacing the L2 and R2 triggers and springs requires disassembling your PS4 controller. This process requires careful handling and appropriate tools. Proceed with caution, as improper disassembly or reassembly may damage your controller. DollaTek is not responsible for any damage incurred during installation.

Tools Required:

- Small Phillips head screwdriver (PH00 or similar)
- Plastic prying tool (spudger)
- Tweezers (optional, for spring placement)

Installation Steps:

1. **Prepare Your Workspace:** Ensure you have a clean, well-lit area. Place a soft cloth or mat down to prevent scratching controller components.
2. **Remove Controller Screws:** Locate the four small Phillips head screws on the back of the PS4 controller. Carefully remove them and keep them in a safe place.
3. **Separate Controller Casing:** Using a plastic prying tool, gently pry open the controller casing. Start from the handles and work your way around the seam. Be extremely careful as the two halves are connected by a ribbon cable.
4. **Disconnect Ribbon Cable:** Once the casing is slightly open, carefully disconnect the ribbon cable connecting the two halves. This usually involves gently pulling it out of its connector.
5. **Remove Battery and Holder:** Disconnect the battery cable from the mainboard and remove the battery. Then, remove the plastic battery holder.
6. **Locate L2/R2 Triggers and Springs:** Identify the L2 and R2 trigger mechanisms. The springs are small metal coils located within these mechanisms.
7. **Remove Old Triggers and Springs:** Carefully remove the old L2 and R2 trigger buttons and their springs. Note their orientation for correct reinstallation.
8. **Install New Springs:** Place the new springs into their designated slots within the trigger mechanism. Tweezers can be helpful for this step.
9. **Install New Triggers:** Position the new L2 and R2 trigger buttons over the springs and into their correct places. Ensure they move freely and engage the springs properly.
10. **Reassemble Controller:** Reverse the disassembly steps. Reconnect the ribbon cable, place the battery holder and battery back, and carefully close the controller casing. Ensure all edges snap together properly before reinserting the four screws.
11. **Test Functionality:** After reassembly, connect your controller to your PS4 console and test the L2 and R2 buttons to ensure they function correctly.



Image: A visual guide indicating the location of the L2 and R2 trigger buttons on a disassembled PS4 controller, highlighting where the replacement parts are installed.

OPERATING

Once the DollaTek L2 R2 Trigger and Spring Replacement Kit is successfully installed, the L2 and R2 buttons on your PS4 controller will function as intended, providing responsive and tactile feedback for your gaming experience. These parts are designed to restore the original operational feel and performance of your controller's triggers.

MAINTENANCE

To ensure the longevity of your replacement triggers and springs, and the overall health of your PS4 controller, consider the following maintenance tips:

- **Keep Clean:** Regularly clean the exterior of your controller with a soft, dry cloth. Avoid using harsh chemicals or excessive moisture.
- **Avoid Force:** Do not apply excessive force to the trigger buttons, as this can lead to premature wear or damage to the internal mechanisms.
- **Proper Storage:** Store your controller in a clean, dry environment away from extreme temperatures and direct sunlight.

TROUBLESHOOTING

If you encounter issues after installing the replacement parts, consider the following troubleshooting steps:

- **Triggers Not Responding:** Ensure the triggers are correctly seated and the springs are properly installed. Reopen the controller and verify all connections, especially the ribbon cables, are secure.
- **Triggers Feel Loose/Stuck:** Check for any debris or misalignment of the trigger buttons or springs. Ensure the springs are not bent or improperly positioned.
- **Controller Not Powering On:** Double-check that the battery is correctly reconnected to the mainboard and that all internal ribbon cables are securely attached.
- **Buttons Not Registering:** If other buttons are also affected, ensure the main circuit board is properly seated and all ribbon cables are connected.

If problems persist, it may indicate a more complex issue or damage during the installation process. Consider seeking professional repair or contacting the seller for further assistance.

SPECIFICATIONS

Brand	DollaTek
Compatible Devices	Gaming Console (PS4 Controller)
Material	Kunststoff (Plastic)
Color	Schwarz (Black)
UPC	742548987893
ASIN	B07JK4J9TY

WARRANTY INFORMATION

Specific warranty details for the DollaTek L2 R2 Trigger and Spring Replacement Kit are not provided in this manual. For information regarding product warranty, please refer to the original purchase documentation or contact the retailer/seller directly.

SUPPORT

For technical support or further assistance with the DollaTek L2 R2 Trigger and Spring Replacement Kit, please contact the DollaTek customer service or the retailer from whom you purchased the product. Please have your purchase details and product information available when contacting support.