

Gardena 18547

Gardena CleverRoll M Metal Frost-Proof Hose Cart User Manual

INTRODUCTION

The Gardena CleverRoll M Metal Frost-Proof Hose Cart (Model 18547) is designed for efficient and convenient garden watering. This robust hose cart features a stable one-piece metal drum, durable aluminum poles, an angled hose connection to prevent kinking, and a foldable plastic crank for compact storage. It includes an 82 ft. GARDENA Flex hose, all necessary Original GARDENA System connection parts, and a cleaning sprayer nozzle, arriving largely pre-assembled for immediate use.

Key features include:

- **Compact Storage:** Features a foldable crank and adjustable handle for space-saving storage.
- **Kick&Stand:** A specially designed fold-out supporting foot ensures stability and prevents tipping during use.
- **Convenient Hose Guide:** An integrated guide ensures the hose is evenly rolled up onto the drum without manual assistance.
- **Maximum Water Flow:** The angled hose connection inside the reel prevents hose bending and kinking, ensuring consistent water flow.
- **Frost-Proof Durability:** Constructed with long-lasting, frost-proof materials for year-round reliability.



Figure 1: Gardena CleverRoll M Metal Frost-Proof Hose Cart.

SETUP INSTRUCTIONS

The Gardena CleverRoll M Hose Cart is designed for quick initial preparation. Follow these steps to get started:

1. **Unfold the Handle:** Extend the adjustable handle to a comfortable height for transport and use.
2. **Engage Kick&Stand:** Locate the orange supporting foot near the wheels and fold it out until it clicks into place. This provides stability and prevents the cart from tipping during operation.



Figure 2: Engaging the Kick&Stand for stability.

3. **Connect to Water Source:** Attach the included connection hose from the cart to your outdoor tap. Ensure all connections are secure to prevent leaks.



Figure 3: Connecting the hose to the cart.

4. **Attach Cleaning Nozzle:** Connect the cleaning sprayer nozzle to the free end of the 82 ft. Flex hose.

OPERATING INSTRUCTIONS

Using your Gardena CleverRoll M Hose Cart for watering is simple and efficient:

1. **Unwinding the Hose:** Pull the hose gently from the reel to the desired length. The integrated hose guide will assist in smooth, tangle-free unwinding.
2. **Watering:** Turn on your water tap. Use the cleaning nozzle to control the water flow and select your desired spray pattern. Water your garden as needed.



Figure 4: Watering the garden with the hose cart.

3. **Winding the Hose:** After use, turn off the water tap. Begin turning the crank handle to neatly roll the hose back onto the drum. The hose guide ensures the hose is layered evenly without requiring manual guidance.



Figure 5: Winding the hose onto the cart.



Figure 6: Close-up of the hose winding mechanism.

MAINTENANCE

Regular maintenance will help ensure the long-term performance and durability of your Gardena CleverRoll M Hose Cart.

- **Frost Protection:** While the cart is designed to be frost-proof, it is advisable to drain all water from the hose and nozzle before the first frost. Store the cart in a frost-free environment during winter months to prevent potential damage.
- **Cleaning:** Periodically clean the hose and nozzle to remove dirt, debris, and mineral deposits. Ensure the nozzle's spray holes are clear for optimal water distribution. Wipe down the cart frame and drum with a damp cloth as needed.
- **Storage:** For compact storage, fold the crank handle and adjust the main handle to its lowest position. The Kick&Stand can also be folded away. This design allows for easy storage in smaller spaces.



Figure 7: Hose cart folded for compact storage.

TROUBLESHOOTING

If you encounter issues with your Gardena CleverRoll M Hose Cart, refer to the following common problems and solutions:

Problem	Possible Cause / Solution
Low Water Flow	Check for kinks or twists in the hose. Ensure the angled hose connection on the reel is not bent or obstructed. Verify the water tap is fully open. Clean the nozzle if it appears clogged.
Hose Not Winding Evenly	Ensure the integrated hose guide is clean and free of debris. The guide is designed for automatic even winding; if issues persist, manually assist the hose during winding.
Cart Instability / Tipping	Ensure the Kick&Stand supporting foot is fully extended and securely engaged. Position the cart on a flat, stable surface during use.
Leaks at Connections	Check that all hose connections (to tap, cart, and nozzle) are tightened securely. Inspect O-rings and washers for wear and replace if necessary.

SPECIFICATIONS

- **Model Number:** 18547-20

- **Brand:** Gardena
- **Material:** Metal (Frame, Handle)
- **Product Dimensions (D x W x H):** 11.42" x 7.4" x 13.94"
- **Item Weight:** 4 Kilograms
- **Hose Length Included:** 82 ft. (GARDENA Flex hose)
- **Included Components:** Hose trolley set, 82 ft. GARDENA Flex hose, Original GARDENA System parts, connection parts, cleaning sprayer nozzle.
- **Special Features:** Compact, foldable, stable (with Kick&Stand), frost-proof, integrated hose guide, angled hose connection.
- **Number of Wheels:** 2
- **Required Assembly:** Yes (minimal initial setup)

WARRANTY AND SUPPORT

The Gardena CleverRoll M Metal Frost-Proof Hose Cart is backed by a **5-year manufacturer's warranty**, a testament to its quality and durable construction. This warranty covers defects in materials and workmanship under normal use.



Figure 8: 5-Year Manufacturer's Warranty.

For detailed warranty terms, product registration, or technical support, please visit the official Gardena website or contact their customer service department. You can find more information and contact details on the [Gardena Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question