

[Manuals.plus](#) /

› [BENEVE](#) /

› BENEVE S9-MOD Digital Sport Smartwatch User Manual

BENEVE s9-mod

BENEVE S9-MOD Digital Sport Smartwatch User Manual

Model: S9-MOD

[Introduction](#)

[Safety Information](#)

[Product Overview](#)

[Setup](#)

[Operation](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

1. INTRODUCTION

This manual provides comprehensive instructions for the BENEVE S9-MOD Digital Sport Smartwatch. This device is designed for active lifestyles, offering features such as remote camera control, pedometer, sleep monitoring, and IP68 water resistance. Please read this manual thoroughly before using your smartwatch to ensure proper operation and longevity.

MULTIPURPOSE FEATURES



Figure 1: BENEVE S9-MOD Smartwatch with its multipurpose features highlighted, including time display, step counter, call/SMS/SNS alert, alarm alert, Bluetooth data sync, distance counter, sleep quality monitor, calorie counter, remote control phone camera, find phone, and anti-lost function.

2. SAFETY INFORMATION

- **Water Resistance:** The smartwatch is IP68 rated for water resistance. This means it is protected against immersion in water up to 1.5 meters for up to 30 minutes. It is suitable for swimming and showering. **Do not press any buttons while the watch is submerged in water. Avoid exposure to hot water or steam, as this can compromise the water seal.**
- **Battery:** The device uses a replaceable CR2450 button battery. Ensure correct polarity when replacing. Keep batteries out of reach of children.
- **Temperature:** Avoid exposing the smartwatch to extreme temperatures (hot or cold) or direct sunlight for extended periods.
- **Cleaning:** Clean the device with a soft, dry cloth. Do not use abrasive cleaners or solvents.

IP67 Waterproof design

Wash hands,when the shower
can be worn, and effective to prevent cosmetics , sweat corrosion



Figure 2: The BENEVE S9-MOD Smartwatch demonstrating its IP68 water-resistant design, suitable for hand washing and showering.

Note: The image text incorrectly states IP67, but the product description confirms IP68.

3. PRODUCT OVERVIEW

Familiarize yourself with the physical components of your BENEVE S9-MOD smartwatch.



Figure 3: Front view of the BENEVE S9-MOD Smartwatch, displaying the digital time (10:15:00) and various icons. Visible buttons include START, RESET, LIGHT, and MODE.

3.1 Buttons and Functions

- **LIGHT Button:** Activates the backlight for improved visibility in low-light conditions.
- **MODE Button:** Cycles through different display modes (e.g., time, date, pedometer, stopwatch).
- **START Button:** Used to start/stop functions like the stopwatch or to confirm selections.
- **RESET Button:** Used to reset functions or navigate back in menus.



Figure 4: Side view of the BENEVE S9-MOD Smartwatch, clearly showing the textured buttons on the left and right sides of the watch case, and the durable TPU strap.

4. SETUP

4.1 Initial Power On

The smartwatch typically comes with a pre-installed battery. If the display is blank, press and hold the **LIGHT** button for a few seconds to activate the display. If it still doesn't turn on, the battery may need replacement (refer to Section 6.2).

4.2 App Installation and Pairing

To utilize all smart features, you need to pair your smartwatch with your smartphone via Bluetooth 4.0. The watch is compatible with iOS (iPhone 4S and iOS 8.0 or later) and Android (Android 4.3 or later) systems.

1. **Download the App:** Search for the official BENEVE smartwatch application in your smartphone's app store (Apple App Store for iOS, Google Play Store for Android).
2. **Enable Bluetooth:** On your smartphone, go to Settings and enable Bluetooth.

3. **Open the App:** Launch the downloaded BENEVE smartwatch application.
4. **Pair Device:** Follow the in-app instructions to search for and pair with your S9-MOD smartwatch. Ensure the smartwatch is within Bluetooth range of your phone.
5. **Grant Permissions:** Allow necessary permissions (e.g., notifications, location, camera access) for the app to function correctly.



Figure 5: The BENEVE S9-MOD Smartwatch connected via Bluetooth to a smartphone, demonstrating its remote camera control capability. The watch can trigger the phone's camera shutter.

4.3 Setting Time and Date

Once paired with your smartphone, the time and date on your smartwatch will typically synchronize automatically. If manual adjustment is needed:

1. Press the **MODE** button repeatedly until you reach the time/date setting mode.
2. Use the **START** and **RESET** buttons to adjust the values (hours, minutes, year, month, day).
3. Press **MODE** again to confirm and exit the setting mode.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

Use the **MODE** button to cycle through the main display screens: Time, Date, Pedometer, Distance, Calories, Stopwatch, and Alarm.

5.2 Activity Tracking (Pedometer, Distance, Calories)

The smartwatch continuously monitors your steps, calculates distance traveled, and estimates calories burned. These metrics are displayed on dedicated screens, accessible via the **MODE** button. For detailed historical data and analysis, refer to the companion smartphone application.

5.3 Sleep Monitoring

Wear the smartwatch during sleep to monitor your sleep patterns. The device tracks sleep duration and quality. Data can be viewed and analyzed in the smartphone application.

5.4 Remote Camera Control

After pairing with your smartphone and granting camera permissions, you can use your smartwatch as a remote shutter button for your phone's camera.

1. Open the camera application on your smartphone.
2. On the smartwatch, navigate to the remote camera mode (usually indicated by a camera icon).
3. Press the **START** button on the smartwatch to trigger the smartphone's camera shutter.

5.5 Call and Message Notifications

When connected to your smartphone, the smartwatch will vibrate and display notifications for incoming calls, SMS messages, and other app alerts (e.g., WeChat, QQ, email, news). Ensure notification permissions are enabled in the companion app.

5.6 Alarm Function

To set an alarm:

1. Press the **MODE** button until you reach the alarm setting screen.
2. Use the **START** and **RESET** buttons to adjust the alarm time.
3. Press **MODE** to confirm and activate the alarm.

5.7 Chronograph (Stopwatch)

To use the stopwatch function:

1. Press the **MODE** button until you reach the stopwatch screen.
2. Press **START** to begin timing.
3. Press **START** again to pause.
4. Press **RESET** to clear the time.

6. MAINTENANCE

6.1 Cleaning Your Smartwatch

Regular cleaning helps maintain the appearance and functionality of your device.

- Wipe the watch case and strap with a soft, slightly damp cloth.
- For stubborn dirt, use a mild soap solution and rinse thoroughly with clean water, then dry completely.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the materials.

6.2 Battery Replacement

The BENEVE S9-MOD uses a replaceable CR2450 button battery, offering a standby time of 6-12 months. When the battery is low, the display may dim or cease to function.

1. Carefully open the back cover of the smartwatch using a small screwdriver or appropriate tool.
2. Remove the old CR2450 battery.
3. Insert a new CR2450 battery, ensuring the positive (+) side faces up.
4. Securely close the back cover, ensuring the waterproof seal is properly seated.

Warning: Improper battery replacement may compromise the device's water resistance.

6.3 Storage

If storing the smartwatch for an extended period, ensure it is clean and dry. Store it in a cool, dry place away from direct sunlight and extreme temperatures.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Smartwatch does not turn on.	Battery is depleted or incorrectly installed.	Replace the CR2450 battery (refer to Section 6.2). Ensure correct polarity.
Cannot pair with smartphone.	Bluetooth is off, app not installed, or watch is out of range.	◦ Ensure Bluetooth is enabled on your phone. ◦ Download and install the correct BENEVE app. ◦ Keep the smartwatch and phone close during pairing. ◦ Restart both the phone and the smartwatch.
Notifications are not received.	App permissions not granted, or app not running in background.	◦ Check app permissions on your phone (notifications, background activity). ◦ Ensure the BENEVE app is running and connected. ◦ Verify notification settings within the BENEVE app.
Activity data (steps, distance) is inaccurate.	Improper wearing, or sensor interference.	◦ Wear the watch snugly on your wrist. ◦ Ensure your personal profile (height, weight) is accurate in the app.

8. SPECIFICATIONS

Feature	Detail
Model	S9-MOD
CPU	Dialog DA 14580
Display	1.1" Round Digital LCD
Case Material	Stainless Steel and Plastic
Strap Material	TPU
Water Resistance	IP68 (up to 1.5m for 30 minutes)
Operating System Compatibility	iOS 8.0+ (iPhone 4S and above), Android 4.3+
Bluetooth Version	BT4.0
Battery Type	Replaceable CR2450 Button Battery (550mAh)
Standby Time	6-12 Months
Vibration	Built-in Vibration Motor
Weight	80g
Dimensions	62 x 56 x 16.8 mm (2.45 x 2.2 x 0.67 inches)
Full Length (Strap Included)	250 mm (9.8 inches)

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided with your purchase or contact BENEVE customer service through their official website or the retailer where the product was purchased. Keep your proof of purchase for warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question