

## awei Y330

# AWEI Y330 Wireless Bluetooth Speaker Instruction Manual

## 1. INTRODUCTION

---

Thank you for choosing the AWEI Y330 Wireless Bluetooth Speaker. This manual provides essential information for the proper setup, operation, and maintenance of your device. Please read it carefully before use to ensure optimal performance and longevity.

The AWEI Y330 is a portable wireless speaker featuring Bluetooth connectivity, dual speaker units, FM radio, and TF card support. It is designed for outdoor use, offering stereo sound with a subwoofer effect.

## 2. PRODUCT OVERVIEW

---

Familiarize yourself with the components and controls of your AWEI Y330 speaker.

## SIMPLE KEY DESIGN

MASTER KEY SYMBOL DESIGN,EASY TO  
UNDERSTAND,MULTI-FUNCTION MODE



W I R E L E S S   B L U E T O O T H   O U T D O O R   S P E A K E R - Y 3 3 0

Image: Top view of the AWEI Y330 speaker, highlighting the control buttons and their functions. From left to right, buttons include: Volume Down / Last Song, Mode Switch, Play/Pause / Answer Call, Volume Up / Next Song, and Power On/Off.

### Package Contents:

- AWEI Y330 Wireless Bluetooth Speaker
- USB Charging Cable
- 3.5mm Audio Cable (AUX)
- User Manual

## 3. SETUP

### 3.1 Charging the Speaker

Before first use, fully charge the speaker. The built-in battery has a capacity of 1200mAh (3.7V).

1. Connect the provided USB charging cable to the speaker's charging port.
2. Connect the other end of the USB cable to a compatible USB power adapter (e.g., 5V/500mA) or a computer's USB port.
3. The charging indicator light will illuminate.
4. Charging typically takes 3-4 hours. The indicator light will change or turn off once charging is complete.



Image: The AWEI Y330 speaker shown with text indicating 'LARGE POWER LONG TIME', '1200mAh /3.7V' battery capacity, '3-4 H charge', and '4h playing time'.

### 3.2 Power On/Off

- To power on: Press and hold the **Power** button until you hear an audible prompt.
- To power off: Press and hold the **Power** button until the speaker turns off.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Bluetooth Mode

This mode allows wireless audio streaming from Bluetooth-enabled devices.

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by an audible prompt or LED). If not, press the **Mode** button to switch to Bluetooth mode.
2. Enable Bluetooth on your smartphone, tablet, or other device.
3. Search for available Bluetooth devices. You should see "AWEI Y330" in the list.
4. Select "AWEI Y330" to pair. Once paired, you will hear a confirmation sound.
5. You can now play audio from your device through the speaker.

### 4.2 AUX Mode

Connect external audio devices using the 3.5mm audio cable.

1. Connect one end of the 3.5mm audio cable to the AUX port on the speaker.
2. Connect the other end to the headphone jack or audio output of your external device.
3. Press the **Mode** button on the speaker until it enters AUX mode.
4. Play audio from your external device.

### 4.3 TF Card / U Disk Mode

Play audio files directly from a TF card or USB flash drive.

1. Insert a TF card into the designated slot or a USB flash drive into the USB port.
2. Press the **Mode** button to switch to TF card or U Disk mode. The speaker will automatically detect and play audio files.

### 4.4 FM Radio Mode

Listen to FM radio stations.

1. Press the **Mode** button to switch to FM radio mode.
2. To auto-scan for stations: Press and hold the **Play/Pause** button. The speaker will scan and save available stations.
3. To switch stations: Use the **Next Song** or **Last Song** buttons.

### 4.5 Call Functions

The speaker features a built-in HD microphone for hands-free calls when connected via Bluetooth.

- To answer an incoming call: Press the **Play/Pause / Answer Call** button once.
- To end a call: Press the **Play/Pause / Answer Call** button once during a call.
- To reject an incoming call: Press and hold the **Play/Pause / Answer Call** button.

### 4.6 Volume and Track Control

- Volume Up: Short press the **Volume Up** button.
- Volume Down: Short press the **Volume Down** button.

- Next Track: Long press the **Volume Up** button.
- Previous Track: Long press the **Volume Down** button.

## 5. MAINTENANCE

---

### 5.1 Cleaning

- Wipe the speaker with a soft, dry cloth.
- Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface.

### 5.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- If storing for an extended period, charge the battery every 3 months to maintain its lifespan.

### 5.3 Water Resistance

The AWEI Y330 speaker is designed to be waterproof. However, avoid submerging it in water for prolonged periods or exposing it to high-pressure water jets. Ensure the charging port cover is securely closed to maintain water resistance.

## 6. TROUBLESHOOTING

---

- **Speaker does not power on:**  
Ensure the battery is charged. Connect the speaker to a power source and try again.
- **Cannot connect via Bluetooth:**  
Ensure the speaker is in Bluetooth pairing mode. Turn off and on Bluetooth on your device. Move the speaker closer to your device (within 10 meters). Clear previous Bluetooth connections on your device and try pairing again.
- **No sound:**  
Check the volume levels on both the speaker and your connected device. Ensure the correct mode (Bluetooth, AUX, TF Card, FM) is selected.
- **FM radio reception is poor:**  
Move the speaker to an open area. The audio cable can sometimes act as an antenna; try connecting it even if not using AUX mode.
- **Speaker automatically turns off:**  
The battery might be low. Recharge the speaker.

## 7. SPECIFICATIONS

---



# LARGE POWER LONG TIME

Music can be played continuously for about 4 HOUR . The built-in battery capacity is 1200mAh /3.7V. The voice feedback function can report the remaining power, and send a reminder when charging is needed



5V /500mAh 3-4 H charge playing time 4H



W I R E L E S S   B L U E T O O T H   O U T D O O R   S P E A K E R • Y 3 3 0

Image: The AWEI Y330 speaker with text indicating 'Heavy Bass', 'Dual units', '6W Rated power', '2x52mm Full frequency magnetic boron unit', and '50x90mm Bass passive radiator unit'.

Feature	Specification
Model	Y330
Speaker Type	Subwoofer

Connectivity	Bluetooth V4.2, 3.5mm AUX, TF Card, U Disk
Transmission Distance	10 meters
Output Power	3W * 2 (Total 6W)
SNR (Signal-to-Noise Ratio)	85dB
Impedance	32 Ω
Frequency Response	100Hz - 1kHz
Battery Capacity	1200mAh, 3.7V
Charging Time	3-4 hours
Working Time	Up to 4 hours
Microphone	Yes, built-in HD microphone
Waterproof	Yes
Product Dimensions	5D x 19W x 8H Centimeters
Item Weight	0.7 Kilograms

## 8. WARRANTY AND SUPPORT



### 8.1 Warranty Information

The AWEI Y330 Wireless Bluetooth Speaker comes with a 6-month warranty from the date of purchase. This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

### 8.2 Customer Support

For technical assistance, warranty claims, or any questions regarding your AWEI Y330 speaker, please contact your retailer or the manufacturer's customer service department. Refer to the product packaging or the official AWEI website for contact details.

### Related Documents - Y330

	<a href="#">Awei T36 TWS Wireless Earbuds User Manual and Specifications</a> Comprehensive user manual for Awei T36 TWS wireless earbuds, covering setup, operation, features, technical specifications, safety precautions, warranty, and disposal guidelines.
	<a href="#">Awei T29 Pro Wireless Earbuds User Manual</a> User manual for the Awei T29 Pro True Wireless Stereo (TWS) earbuds, covering setup, pairing, operation, features, specifications, safety precautions, and warranty information.





Условия Акции «Подарки за покупки»  
в розничных магазинах Technodom  
в Республике Казахстан

1. Акция действует в розничных магазинах Technodom в Республике Казахстан.
2. Период Акции: с 5 января 2023 года по 16 января 2023 года включительно.
3. Магазины Акции принимают к учету, что товарная покупка на сумму от 10 000 (десяти тысяч) тенге каждой покупателю может получить 1 (один) из подарков указанных в **Приложении №1** к настоящему чеку.
4. Условия участия в Акции:
  - 4.1. В участие в акции имеют право все физические лица, граждане Республики Казахстан и достигшие возраста 18 лет;
  - 4.2. К участию не могут в данной Акции не участвовать: ТОО и ИП;
  - 4.3. Основным принципом в данной Акции не участвуют в случае, если один и тот же Покупатель совершил покупки 3 (три) и более раз в период действия Акции, по 1 (одному) и более подаркам покупки, приобретенной покупателем;
  - 4.4. Представителям компаний АО «Технодом», Унитарное (Технодом Сервис), членам их семей, представителям рекламных агентств, сотрудникам структурных, а также третьих лиц, участвующих в проведении промо акции, не могут быть выданы в данной акции;
  - 4.5. Товары, указанные в приложении 1 не могут быть подарены в Акции;
  - 4.6. Акция «Подарки за покупки» проводится параллельно с другими маркетинговыми акциями: «Высшая ставка», «Скины», «Поздравляем!» «Назад на выходные»;
  - 4.7. При покупке по скинному тегу, подарки предоставляются в магазин компаниями;
  - 4.8. Количество подарков ограничено: 3 (три) копии выбранной Покупателем подарка отсутствуют в рекламном материале. Подарки должны выдаваться другой подарком согласно выбранному количеству, который есть в наличии;
  - 4.9. Покупатель может <https://technodom.kz> участвовать в данной Акции;
  - 4.10. Покупка на сайте <https://technodom.kz> участвует в данной Акции только в случае, если клиент совершает покупку в любом розничном магазине в Республике Казахстан (оформлено).
5. Организатор данной Акции оставляет за собой право использования имени Победителей в рекламных целях, а также привлекать на дни участия в рекламных ролях, использовать фото и видео материалы;
- 5.1. Организатор вправе внести коррективы в Условия Акции в течение периода проведения Акции;
- 5.2. Участие в промо акции является бесплатным способом участия на мероприятии, инициированном организатором;
6. Консультации по условиям участия в данной Акции можно получить на директора, менеджера отдела маркетинга;
7. Условия возврата и обмена товара на Акции:
  - 7.1. При приобретении товара клиент, оформив возврат, не может использовать товар, участвовать в акции и программе, предоставляемая действующим законодательством РК;
  - 7.2. В случае, требующая Покупателя вернуть, стоимость Товара, приобретенного с участием Подарка, по окончании процедуры на нем действующим законодательством, Покупатель не может вернуть стоимость Товара, приобретенного с участием Подарка;
  - 7.3. В случае, если Покупатель возвращает Товар, не приобретя его с участием Подарка, то приобретенный с участием Подарка товар будет возвращен Покупателю по цене, согласно которой приобретен товар приобретший Товар. Указанное требование должно быть отражено в чеке.

[pdf]

Разин Ринат Подарки за покупки» в розничных магазинах Technodom 247425 Наушники вставные беспроводные Neo BS21 TWS Earbuds Black KF611197 BK 5XL 253218 Толстовка без молнии

Technopatriot Logo 20 hours ago — sup gift technodom kz under banners |||

Technodom 1. Technodom . 2. : 5 2023 16 2023 . 3. , 50 000 ... -7370A/HS M MK-7370A/HS XL NEK-005DB NEK-005R YB-W5BK Couples Winter Vests\_3XL X-game\_3Dv2\_Pink **Y330** Black MS-6792A/HS L MS-6792A/HS M KF611197-BK-XS KF611197-GR-XS KF611197-OR-XS KF611197-BK-...

lang:nl score:8 filesize: 956.65 K page\_count: 38 document date: 2023-01-05