Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

EQUSUPRO AOD01CA

EQUSUPRO 150ml Metal Ultrasonic Essential Oil Diffuser (Model AOD01CA) Instruction Manual

Introduction

Thank you for choosing the EQUSUPRO 150ml Metal Ultrasonic Essential Oil Diffuser. This device combines aromatherapy, humidification, ambient lighting, and decorative elements to enhance your living space. It features a 150ml water tank, quiet ultrasonic technology, and multiple light settings for a customizable experience.



Image: The EQUSUPRO 150ml Metal Ultrasonic Essential Oil Diffuser with an A-tree design.



Image: The EQUSUPRO Essential Oil Diffuser emitting a gentle mist, creating a serene atmosphere.

Safety Information

- Avoid direct skin contact with undiluted essential oils.
- Keep out of reach of children and pets.
- Do not open the oil diffuser cover when in use.
- Do not pour water or other liquid into the mist outlet vent.
- Do not move or tilt the oil diffuser during operation.
- Always dilute essential oil or liquid air freshener with water.
- Ensure proper ventilation during use.
- The diffuser will automatically shut off when the water runs out.

Package Contents

- AC Adaptor
- Essential Oil Diffuser Body
- User Manual

Setup

1. Remove the cover of the oil diffuser.
2. Fill the water tank with water below the 'Max' line.
3. Add 3-5 drops of essential oil.
4. Replace the cover securely.
5. Plug in the power adapter.



Image: The diffuser's compact size and mist modes (6 hours continuous, 12 hours intermittent).

Video: Official video demonstrating the EQUSUPRO 150ml metal tree oil diffuser in operation, showcasing its mist and light features.

Operating Instructions

Mist Control

The diffuser offers two mist modes:

- **Continuous Mist:** Press the Mist Button once for continuous mist, lasting up to 6 hours.
- **Intermittent Mist:** Press the Mist Button a second time for intermittent mist (30 seconds on, 30 seconds off), lasting up to 12 hours.
- Press the Mist Button a third time to turn off the mist function.

Light Control

The diffuser features 7 LED colors, each with bright and dim settings:

- Press the Light Button once to cycle through the 7 colors automatically.
- Press the Light Button again to fix it on your preferred color.
- Continue pressing to cycle through colors or adjust brightness (bright/dim).
- Press and hold the Light Button to turn off the light function.



Image: Detailed view of the diffuser's control buttons for light and mist functions.

Automatic Shut-Off

For safety and convenience, the diffuser will automatically shut off when the water level is too low or the tank is empty.

Quiet Operation

The advanced ultrasonic technology ensures whisper-quiet operation (less than 30dB), making it suitable for bedrooms, offices, or any space where minimal noise is desired.



Image: The diffuser operating quietly at 23dB, providing a calming mist and light for relaxation.



Image: The diffuser's versatile 4-in-1 functionality, including aromatherapy, humidification, night light, and decor.

Maintenance

Regular cleaning helps maintain optimal performance and extends the lifespan of your diffuser.

Cleaning Instructions

- After every 7 uses or 7 days, clean the middle hole of the water tank with a cotton swab.
- Ensure the diffuser is unplugged before cleaning.
- Do not use harsh detergents or abrasive materials.
- Wipe the exterior with a soft, damp cloth.
- Do not immerse the unit in water.

Troubleshooting

Problem	Possible Cause	Solution
No mist or weak mist	Insufficient water; water level too high; mist outlet blocked; unit dirty.	Add water to appropriate level; clean mist outlet; clean the unit.
No light	Light function turned off; power issue.	Press the Light Button to activate; check power connection.
Water leakage	Cover not properly secured; water over MAX line; unit tilted.	Ensure cover is tight; do not overfill; keep unit on a flat surface.

Specifications

Feature	Detail
Brand	EQUSUPRO
Model Name	OIL DIFFUSER
Model Number	AOD01CA
Capacity	150 ml
Runtime	6 hours (Continuous), 12 hours (Intermittent)
Power Source	Corded Electric
Wattage	12 watts
Light Source	LED (7 colors)
Noise Level	<30dB
Material	Metal
Dimensions (L x W x H)	3.6"L x 3.6"W x 6"H
Coverage Area	Up to 200 square feet
UPC	663250588263

Warranty & Support

EQUSUPRO stands behind its products with a 45-day money-back guarantee and a 24-month worry-free warranty. Each product undergoes safety and quality testing before shipping.
Our dedicated 24/7 customer service team is available to assist you with any questions or concerns, ensuring complete satisfaction. For further assistance, please visit the official EQUSUPRO store: EQUSUPRO Store.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B07JNMQBV4

More documents and user manuals: **https://manuals.plus/**