

[Manuals.plus](#) /

› [ANDHOT](#) /

› ANDHOT USB Type C Charger Instruction Manual (Model BP1805)

ANDHOT BP1805

ANDHOT USB Type C Charger Instruction Manual

Model: BP1805

INTRODUCTION

The ANDHOT 2 Port USB Adapter Wall Charger with 6FT USB C Fast Charging Cable Cord (Model BP1805) is designed to provide efficient and safe charging for a wide range of USB Type-C compatible devices. This manual provides essential information for the proper setup, operation, and maintenance of your charger.

WHAT'S IN THE BOX

- 1 x 2.1A Dual Port USB Wall Charger
- 1 x 6ft Type C Charging Cable


SAFETY INFORMATION

Please read and understand all safety instructions before using this product.

- This USB Type-C cable is designed exclusively for USB Type-C port devices. Ensure your device has a USB Type-C port before connecting.
- The charger features built-in safeguards to protect your devices against excessive current, overheating, and overcharging.
- Do not expose the charger or cable to liquids or extreme temperatures.
- Avoid disassembling the product. Unauthorized repairs may void the warranty and pose safety risks.
- Keep out of reach of children.

Advanced Safety Features

Excellent Multiprotectiondesign provides a total protection for youand your decvices.




Over-voltage
protection



Over-current
protection



Over-heat
protection



Short-circuit
protection



Over-charger
protection



Flame retardant
protection

The charger incorporates multiple safety features to protect your devices during charging.

SETUP

1. **Connect the USB-C Cable:** Insert the standard USB-A end of the 6ft USB-C charging cable into one of the two USB ports on the wall charger.
2. **Plug into Power:** Insert the wall charger into a standard electrical wall outlet (100V-240V).
3. **Connect to Device:** Insert the USB Type-C end of the cable into the charging port of your compatible device.
4. **Begin Charging:** Your device should now begin charging.



Connect the USB-C cable to your device and the wall charger, then plug the charger into a power outlet to begin charging.

OPERATING INSTRUCTIONS

Charging Your Device

Once properly set up, the charger will automatically detect your device and deliver an optimal charging speed of up to 2.1A when charging a single phone. The dual USB ports allow for simultaneous charging of two devices.

Data Transfer

The included USB Type-C cable supports fast data transfer speeds of up to 480Mbps, allowing you to sync files between your device and a computer when connected.

Universal Compatibility

This charger and cable are compatible with a wide range of USB Type-C enabled mobile devices, including various models from Samsung Galaxy, Google Pixel, Moto G series, LG Stylo, and OnePlus. Refer to the specifications section for a detailed list of

compatible devices.

UNIVERSAL COMPATIBILITY

Warm Tip:

The attached Charging Cord is USB Type Cable, Only for USB-C Port Device
Dual USB Wall Charger Perfect fits for all USB-enabled devices




The charger and cable are compatible with a wide range of USB Type-C devices.

MAINTENANCE

- **Cleaning:** Disconnect the charger from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the charger and cable. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger and cable in a cool, dry place away from direct sunlight and moisture when not in use.
- **Cable Care:** The nylon braided cable is designed for durability. Avoid sharp bends, kinks, or excessive pulling on the cable to prolong its lifespan. The reversible connector allows for easy plugging without worrying about orientation.

8X MORE DURABLE

Proven to be stronger than other USB-C cables.



The durable nylon braided cable is designed to withstand daily use.

TROUBLESHOOTING

• Device Not Charging:

- Ensure the wall charger is securely plugged into a working electrical outlet.
- Verify that the USB-C cable is firmly connected to both the charger and your device.
- Confirm that your device is compatible with USB Type-C charging.
- Try using a different USB port on the charger or a different wall outlet.
- Inspect the cable and charger for any visible damage.

• Slow Charging:

- Ensure your device supports fast charging.
- Avoid using your device heavily while it is charging.
- Disconnect and reconnect the cable and charger.
- If charging two devices simultaneously, the charging speed for each device may be reduced.

• **Charger Overheating:**

- Unplug the charger immediately.
- Ensure the charger is used in a well-ventilated area.
- Avoid covering the charger while in use.
- If overheating persists, discontinue use and contact customer support.

SPECIFICATIONS


Model Number	BP1805
Brand	ANDHOT
Charger Input	100V-240V (U.S. and World Standard)
Charger Output	5V/2.1A
Total USB Ports	2
Cable Length	6ft (1.8 meters)
Connector Type	USB Type C
Data Transfer Speed	480Mbps
Special Features	Automatic Off, Braided Cable, Fast Charging, Lightweight Design, Short Circuit Protection
Item Weight	0.176 ounces
Manufacturer	Shenzhen Putuo Technology Co.,Ltd

Ultra Compact Size

Ultra-portable design and dual ports are ideal for travel.

Size:40mm*35mm*37mm

Weight:33g



The charger features an ultra-compact size for portability.

WARRANTY INFORMATION

Specific warranty details for the ANDHOT USB Type C Charger (Model BP1805) are not provided in this manual. For comprehensive warranty information, please refer to the product packaging or contact ANDHOT customer support directly.

SUPPORT

For further assistance, technical support, or inquiries regarding your ANDHOT USB Type C Charger, please contact the manufacturer or visit the official ANDHOT store.

ANDHOT Store: [Visit the ANDHOT Store on Amazon](#)

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question