

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Kappesberg](#) /

› [Kappesberg E530 Double Wardrobe Instruction Manual](#)

## Kappesberg E530

# Kappesberg E530 Double Wardrobe with 6 Doors and 2 Internal Drawers - White

Instruction Manual

[Safety Information](#)

[Setup](#)

[Operating](#)

[Maintenance](#)

[Troubleshooting](#)

[Specifications](#)

[Warranty & Support](#)

## INTRODUCTION

Thank you for choosing the Kappesberg E530 Double Wardrobe. This manual provides essential information for the safe assembly, operation, and maintenance of your new wardrobe. Please read these instructions carefully before beginning assembly and keep them for future reference. Proper assembly and care will ensure the longevity and functionality of your product.

## SAFETY INFORMATION

Always prioritize safety during assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Adult Assembly Required:** This product must be assembled by adults. Keep children and pets away from the assembly area.
- **Use Proper Tools:** Ensure you have all necessary tools as specified in the assembly guide.
- **Check All Parts:** Before assembly, verify that all components are present and undamaged. Do not proceed with assembly if any parts are missing or damaged.
- **Stable Surface:** Assemble the wardrobe on a clean, flat, and stable surface to prevent scratching or damage.
- **Secure to Wall:** For safety and stability, it is highly recommended to secure the wardrobe to a wall using appropriate anti-tip hardware (not always included, check your package). This prevents tipping, especially in households with children.
- **Weight Limits:** Do not exceed the recommended weight limits for shelves and hanging rods. Overloading can cause structural failure.
- **Ventilation:** Ensure adequate ventilation when storing clothes to prevent mold or mildew.
- **Moving the Wardrobe:** If you need to move the assembled wardrobe, empty it first and move it carefully to prevent damage or injury.

## SETUP AND ASSEMBLY

---

The Kappesberg E530 wardrobe requires assembly. Please follow the detailed assembly instructions provided in the separate manufacturer's manual included with your product. The steps below provide a general overview.

### 1. Unpacking and Inspection

- Carefully open the packaging and remove all components.
- Check the parts list against the contents of the boxes to ensure all pieces are present.
- Inspect each part for any damage. Contact customer support immediately if any parts are damaged or missing.

### 2. Tools Required

Typically, you will need the following tools for assembly (may vary, refer to manufacturer's guide):

- Phillips head screwdriver
- Hammer (for dowels and back panel nails)
- Measuring tape
- Level

### 3. Assembly Steps (General)

1. Begin by assembling the base frame according to the manufacturer's instructions.
2. Attach the side panels and central dividers.
3. Install the back panel, ensuring it is square and secure.
4. Mount the internal shelves, hanging rods, and drawer slides.
5. Assemble the drawers and insert them into their respective slides.
6. Attach the doors, adjusting hinges for proper alignment and gap.
7. Install the handles on doors and drawers.
8. Place the wardrobe in its final desired location and secure it to the wall using anti-tip hardware if provided or purchased separately.



Figure 1: Exterior view of the Kappesberg E530 Double Wardrobe.

## OPERATING INSTRUCTIONS

---

This section details the proper use of your Kappesberg E530 wardrobe.

### Doors

- The wardrobe features 6 hinged doors. Open and close them gently using the provided handles.
- Avoid forcing the doors, especially if they feel stiff or misaligned. Adjust hinges if necessary (refer to assembly guide for hinge adjustment).

### Drawers

- The wardrobe includes 2 internal drawers with metallic slides. Pull them out smoothly using the handles.
- Do not overload the drawers. Distribute weight evenly.

### Shelves and Hanging Rods

- The wardrobe has 5 internal shelves and 2 hanging rods.
- Distribute weight evenly across shelves and hanging rods to prevent bowing or damage.

- Avoid placing excessively heavy items on any single shelf.



Figure 2: Interior organization of the Kappesberg E530 Double Wardrobe.

## MAINTENANCE AND CARE

---

Regular cleaning and proper care will help maintain the appearance and extend the life of your wardrobe.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Use a mild soap solution if necessary, then wipe dry immediately. Avoid abrasive cleaners, harsh chemicals, or excessive moisture, as these can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent dust buildup.
- **Spills:** Clean up spills immediately to prevent staining or damage to the MDP material.
- **Sunlight:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration over time.
- **Humidity:** Maintain a stable room temperature and humidity level. Extreme fluctuations can affect wood-based materials.
- **Hardware:** Periodically check all screws and fittings to ensure they are tight. Retighten if necessary to maintain structural integrity.

## TROUBLESHOOTING

---

Here are solutions to common issues you might encounter with your wardrobe.

### Wardrobe is Wobbly

- **Check Fasteners:** Ensure all screws, bolts, and cam locks are fully tightened.
- **Level Surface:** Verify that the wardrobe is on a flat, level surface. Use shims under the feet if the floor is uneven.
- **Wall Anchoring:** Confirm that the anti-tip hardware is securely installed and anchored to the wall.

### Doors Do Not Align or Close Properly

- **Hinge Adjustment:** Most hinges have adjustment screws to move the door up/down, left/right, and in/out. Refer to the assembly manual for specific hinge adjustment instructions.
- **Squareness:** Ensure the wardrobe frame is square. A non-square frame can cause door misalignment.

### Drawers Stick or Do Not Slide Smoothly

- **Check Slides:** Ensure the drawer slides are correctly installed and aligned on both the drawer and the wardrobe frame.
- **Obstructions:** Remove any items that might be obstructing the drawer's path.
- **Lubrication:** A small amount of silicone spray or paraffin wax can be applied to the drawer slides to improve smoothness.
- **Overloading:** Reduce the weight in the drawer if it is overloaded.

## PRODUCT SPECIFICATIONS

---

Model	E530
Brand	Kappesberg
Type	Double Wardrobe (Casal)
Color	White
Material	MDP (Medium Density Particleboard), Engineered Wood
Finish	Matte (Fosco)
Number of Doors	6
Number of Internal Drawers	2
Number of Shelves	5
Number of Hanging Rods	2
Overall Dimensions (H x W x D)	217 cm x 220 cm x 47 cm (Approx. 85.4 in x 86.6 in x 18.5 in)
Weight Capacity	Up to 80 kg (176 lbs)

Assembly Required	Yes
-------------------	-----

## WARRANTY AND SUPPORT

---

### Warranty Information

This Kappesberg E530 wardrobe comes with a **3-month warranty** against manufacturing defects. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal household use.

The warranty does not cover:

- Damage caused by improper assembly or installation.
- Damage from misuse, abuse, neglect, or accidents.
- Normal wear and tear.
- Damage from unauthorized repairs or modifications.

For full warranty terms and conditions, please refer to the documentation provided with your purchase or contact Kappesberg customer service.

### Customer Support

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Kappesberg customer support. Contact information can typically be found on the manufacturer's website or in the packaging materials.

When contacting support, please have your product model (E530) and proof of purchase readily available.